

# **DATA BOOK**

# INVERTER WALL MOUNTED TYPE RESIDENTIAL AIR-CONDITIONERS

Wi-Fi model


(Split system, air to air heat pump type)

SRK20ZTX-WA/SRC20ZTX-WA SRK25ZTX-WA/SRC25ZTX-WA SRK35ZTX-WA/SRC35ZTX-WA

## **CONTENTS**

1. SPE	CIFICATIONS	2
2. EXT	ERIOR DIMENSIONS	5
(1)	Indoor units	5
(2)	Outdoor units	6
(3)	Remote control	7
3. ELE	CTRICAL WIRING	10
(1)	Indoor units	10
(2)	Outdoor units	11
4. NOIS	SE LEVEL	12
5. PIPI	NG SYSTEM	24
6. RAN	GE OF USAGE & LIMITATIONS	25
7. CAP	ACITY TABLES	27
8. APP	LICATION DATA	28
(1)	Installation of indoor unit	28
(2)	Installation of outdoor unit	32
(3)	Safety precautions in handling air-conditioners with flammable refrigerant	36
9. OPT	ION PARTS	40
(1)	Wired remote control (RC-EX3A, RC-E5)	40
(2)	Interface kit (SC-BIKN2-E)	55
(3)	Superlink E board (SC-ADNA-E)	59
10. TE	CHNICAL INFORMATION	61
11. RE	FERENCE	64

## ■ How to read the model name



## 1. SPECIFICATIONS

			Model		ZTX-WA		
Item				Indoor unit SRK20ZTX-WA	Outdoor unit SRC20ZTX-WA		
Power source	e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz		
	Nominal cooling capacity (	range)	kW	2.0 ( 0.9 (Min	.) - 3.5 (Max.))		
	Nominal heating capacity (	range)	kW	2.7 ( 0.9 (Min.) - 7.6 (Max.))			
	Heating capacity (H2)		kW	_			
	Max heating capacity			4.6 / 3.9 ( -1	5°C / -20°C )		
	Cooling			0.32 ( 0.1	6 - 0.77 )		
	Power consumption	Heating	1	0.47 ( 0.1	7 - 2.31)		
		Heating (H2)	kW	-	<del>-</del>		
	Max power consumption	, ,	1	2.	54		
		Cooling		1.7 / 1.6 / 1.6 (2	220/ 230/ 240 V )		
	Running current	Heating	Α	,	220/ 230/ 240 V )		
Operation	Inrush current, max current			,	x. 14.5		
data	,	Cooling			36		
	Power factor	Heating	- %		3		
	EER	Cooling			25		
		Heating	-		74		
	COP	Heating (H2)	-		_		
		Cooling		52			
	Sound power level		-	53	57		
		Heating	4D(A)				
	Sound pressure level	Cooling	dB(A)	Hi: 38 Me: 31 Lo: 24 ULo: 19	43		
		Heating		Hi: 40 Me: 33 Lo: 25 ULo: 19	45		
	Silent mode sound pressur			_	Cooling: 33 / Heating: 38		
	ensions (Height × Width × De	epth)	mm	305 × 920 × 220	640 × 800 (+71) × 290		
Exterior appearance (Equivalent color)				Fine snow Munsell: ( 8.0Y 9.3 / 0.1 ), RAL: 9003	Stucco white Munsell: ( 4.2Y 7.5 / 1.1 ), RAL: 7004		
Net weight			kg	13.0	45.0		
Compressor type & Quantity				_	RMT5113SWE11 (Twin rotary type) x 1		
Compressor motor (Starting method)			kW	_	0.75 (Inverter driven)		
Refrigerant oil (Amount, type)			L	_	0.45 ( DIAMOND FREEZE MB75 )		
Refrigerant (Type, amount, pre-charge length)			kg	R32 1.25 in outdoor unit (Incl. th	ne amount for the piping of 15m)		
Heat exchanger				Louver fins & inner grooved tubing	M fins & inner grooved tubing		
Refrigerant of	control			Capillary tubes + Elec	tronic expansion valve		
Fan type & C				Tangential fan × 1	Propeller fan × 1		
	Starting method)		W	42 × 1 ( Direct drive )	62 × 1 ( Direct drive )		
,	otal iling memoral	Cooling		Hi: 10.7 Me: 8.6 Lo: 5.8 ULo: 4.8	31.0		
Air flow		Heating	m³/min	Hi: 14.2 Me: 10.4 Lo: 7.2 ULo: 5.6	31.0		
Available ex	ternal static pressure	i iodaig	Pa	0	0		
Outside air i	· · · · · · · · · · · · · · · · · · ·		1 4	Not possible	_		
	ality / Quantity			Polypropylene net ( Washable ) × 2	_		
	ration absorber			Rubber sleeve ( for fan motor )	Rubber sleeve ( for fan motor & compressor		
Electric heat				— Defrost heater 230V 110			
Electric fleat	Remote control						
Operation				Wireless remote control			
controlt	Room temperature control			Microcomputer thermostat  RUN: Green , TIMER: Yellow , ECO: Blue			
	Operation display						
Safety equip				Frost protection, Serial signal error prote	ction, Overcurrent protection, ection, Indoor fan motor error protection, ure control), Cooling overload protection		
	Refrigerant piping size (O.I	D)	mm	Liquid line: φ 6.35 ( 1/4"	Gas line: φ 9.52 ( 3/8" )		
	Connecting method			Flare connection	Flare connection		
1	Attached length of piping		m	Liquid line: 0.81 / Gas line: 0.74	_		
Installation	Insulation for piping			Necessary ( Both s	ides ), independent		
data	Refrigerant line (one way) le	ength	m	- 1	x.25		
	Vertical height diff. between		m		/ Max.15 ( Outdoor unit is lower )		
Drain hose			<u> </u>	Hose connectable (VP16)	Hole size $\phi$ 20 × 15 pcs.		
Drain numn	max lift height		mm		=		
	led breaker size		A		20		
			A		.2		
,	ed rotor ampere)	a mumah as	A				
Interconnect	ing wires Size × Cor	e number	-	` •	le ) / Terminal block ( Screw fixing type )		
IP number			-	IPX0	IPX4		
	N connecting			Standard equipment	_		
Standard ac	cessories			Mounting kit, Clean filter ( Allergen clear filter x 1	I, Photocatalytic washable deodorizing filter × 1		
Option parts				Interface kit ( SC-BIKN2-E ) (Cannot be used with wireless LAN)	_		
				·	I.		

Notes (1) The data are measured at the following conditions.

The pipe length is 5m.

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7°C	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

(2) This air-conditioner is manufactured and tested in conformity with the ISO.

(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions. (4) Select the breaker size according to the own national standard.

			Model	SRK25	ZTX-WA			
Item				Indoor unit SRK25ZTX-WA	Outdoor unit SRC25ZTX-WA			
Power source	e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz			
	Nominal cooling capacity (ra	inge)	kW	2.5 ( 0.9 (Min	.) - 3.8 (Max.))			
	Nominal heating capacity (ra	inge)	kW	3.2 ( 0.9 (Min.) - 7.8 (Max.))				
	Heating capacity (H2)		kW	_				
	Max heating capacity		kW	4.8 / 4.3 ( -15°C / -20°C )				
	Cooling			0.45 ( 0.1	6 - 0.91 )			
	Power consumption	Heating	kW	0.59 ( 0.1	7 - 2.45 )			
		Heating (H2)		-	_			
	Max power consumption				70			
	Running current	Cooling		2.2 / 2.1 / 2.0 ( 2	20 / 230 / 240 V )			
Operation	Training current	Heating	Α	2.8 / 2.7 / 2.6 ( 2	20 / 230/ 240 V )			
data	Inrush current, max current				x. 14.5			
	Power factor	Cooling	- %		3			
		Heating	,,,		5			
	EER	Cooling			56			
	COP	Heating			42			
		Heating (H2)						
	Sound power level	Cooling		54	55			
		Heating		55	57			
	Sound pressure level	Cooling	dB(A)	Hi: 39 Me: 33 Lo: 25 ULo: 19	44			
		Heating		Hi: 41 Me: 34 Lo: 27 ULo: 19	45			
	Silent mode sound pressure			_	Cooling: 35 / Heating: 39			
	ensions (Height × Width × Dep	oth)	mm	305 × 920 × 220	640 × 800 (+71) × 290			
Exterior appearance (Equivalent color)				Fine snow Munsell: ( 8.0Y 9.3 / 0.1 ), RAL: 9003	Stucco white Munsell: ( 4.2Y 7.5 / 1.1 ), RAL: 7004			
Net weight			kg	13.0	45.0			
Compressor type & Quantity				_	RMT5113SWE11( Twin rotary type ) × 1			
Compressor motor (Starting method)			kW	_	0.75 (Inverter driven)			
Refrigerant oil (Amount, type)			L	_	0.45 ( DIAMOND FREEZE MB75 )			
Refrigerant (Type, amount, pre-charge length)			kg	,	ne amount for the piping of 15m)			
Heat exchanger				Louver fins & inner grooved tubing	M fins & inner grooved tubing			
Refrigerant of				· · ·	tronic expansion valve			
Fan type & C	· · · · · · · · · · · · · · · · · · ·			Tangential fan x 1	Propeller fan x 1			
Fan motor (S	Starting method)		W	42 × 1 ( Direct drive )	62 × 1 ( Direct drive )			
Air flow		Cooling Heating	m³/min	Hi: 11.7 Me: 9.6 Lo: 6.4 ULo: 4.8 Hi: 14.8 Me: 11.0 Lo: 7.8 ULo: 5.4	31.0 31.0			
Available ext	ternal static pressure		Pa	0	0			
Outside air ir	ntake			Not possible	_			
Air filter, Qua	ality / Quantity			Polypropylene net (Washable) × 2	_			
Shock & vibr	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)			
Electric heat	er			<ul><li>Defrost heater 230V 110</li></ul>				
Operation	Remote control			Wireless remote control				
controlt	Room temperature control			•	er thermostat			
	Operation display			RUN: Green , TIMEF	R: Yellow , ECO: Blue			
Safety equip				Frost protection, Serial signal error prote Heating overload protection ( High press	ction, Overcurrent protection, ection, Indoor fan motor error protection, ure control), Cooling overload protection			
	Refrigerant piping size ( O.D	)	mm	Liquid line: φ 6.35 ( 1/4" )				
	Connecting method			Flare connection	Flare connection			
Installation	Attached length of piping		m	Liquid line: 0.81 / Gas line: 0.74	_			
data	Insulation for piping				ides), independent			
	Refrigerant line (one way) ler		m		x.25			
	Vertical height diff. between	U/U and I/U	m	`	/ Max.15 ( Outdoor unit is lower )			
Drain hose				Hose connectable (VP16)	Hole size $\phi$ 20 × 15 pcs.			
Drain pump, max lift height			mm	_				
	led breaker size		A		0			
	ed rotor ampere)		Α		.7			
Interconnect	ing wires Size × Core	number		, ,	le ) / Terminal block ( Screw fixing type )			
IP number				IPX0	IPX4			
	N connecting		-	Standard equipment				
Standard ac	cessories		-		, Photocatalytic washable deodorizing filter × 1)			
Option parts				Interface kit ( SC-BIKN2-E ) (Cannot be used with wireless LAN)	_			

## Notes (1) The data are measured at the following conditions.

The pipe length is 5m.

Item	Indoor air t	Indoor air temperature		temperature	Standards
Operation	DB	WB	DB	WB	Staridards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7°C	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

<sup>(2)</sup> This air-conditioner is manufactured and tested in conformity with the ISO.

<sup>(3)</sup> Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions. (4) Select the breaker size according to the own national standard.

			Model	SRK35	ZTX-WA			
Item				Indoor unit SRK35ZTX-WA	Outdoor unit SRC35ZTX-WA			
Power source	e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz			
	Nominal cooling capacity (ra	inge)	kW	3.5 ( 0.9 (Min	.) - 4.5 (Max.))			
	Nominal heating capacity (ra	inge)	kW	4.3 ( 0.9 (Min.) - 8.0 (Max.))				
	Heating capacity (H2)		kW					
	Max heating capacity		kW	5.0 / 4.4 ( -15°C / -20°C )				
	Cooling			0.74 ( 0.1	6 - 1.18)			
	Power consumption	Heating	kW	0.87 ( 0.1	7 - 2.50)			
		Heating (H2)		-	_			
	Max power consumption				75			
	Running current	Cooling		`	20 / 230 / 240 V )			
Operation		Heating	Α	`	20 / 230 / 240 V )			
data	Inrush current, max current				x. 14.5			
	Power factor	Cooling	- %	-	6			
		Heating			3			
	EER	Cooling			73			
	COP	Heating			94			
		Heating (H2)						
	Sound power level	Cooling		57	59			
		Heating		57	58			
	Sound pressure level	Cooling	dB(A)	Hi: 43 Me: 35 Lo: 26 ULo: 19	47			
		Heating	-	Hi: 42 Me: 35 Lo: 28 ULo: 19	47			
	Silent mode sound pressure			_	Cooling: 38 / Heating: 43			
	ensions (Height × Width × Dep	oth)	mm	305 × 920 × 220	640 × 800 (+71) × 290			
Exterior appearance (Equivalent color)				Fine snow Munsell: ( 8.0Y 9.3 / 0.1 ), RAL: 9003	Stucco white Munsell: ( 4.2Y 7.5 / 1.1 ), RAL: 7004			
Net weight			kg	13.0	45.0			
Compressor type & Quantity				_	RMT5113SWE11 (Twin rotary type) × 1			
Compressor motor (Starting method)			kW	_	0.90 (Inverter driven)			
Refrigerant oil (Amount, type)			L	_	0.45 ( DIAMOND FREEZE MB75 )			
Refrigerant (Type, amount, pre-charge length)			kg	,	ne amount for the piping of 15m)			
Heat exchanger				Louver fins & inner grooved tubing	M fins & inner grooved tubing			
Refrigerant of	· · · · · · · · · · · · · · · · · · ·			· · ·	tronic expansion valve			
Fan type & C				Tangential fan × 1	Propeller fan × 1			
Fan motor (S	Starting method)	10 11	W	42 × 1 ( Direct drive )	62 × 1 (Direct drive)			
Air flow		Cooling Heating	m³/min	Hi: 13.2 Me: 10.3 Lo: 7.0 ULo: 4.8 Hi: 15.3 Me: 11.8 Lo: 8.6 ULo: 5.6	35.8 31.0			
Available ext	ernal static pressure		Pa	0	0			
Outside air ir	ntake			Not possible	_			
Air filter, Qua	lity / Quantity			Polypropylene net (Washable) × 2	_			
Shock & vibr	ation absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)			
Electric heat	er			<ul><li>Defrost heater 230V 110</li></ul>				
Operation	Remote control			Wireless remote control				
controlt	Room temperature control			•	er thermostat			
	Operation display				R: Yellow , ECO: Blue			
Safety equip				Frost protection, Serial signal error prote Heating overload protection ( High press	ction, Overcurrent protection, ection, Indoor fan motor error protection, ure control), Cooling overload protection			
	Refrigerant piping size ( O.D	)	mm	Liquid line: φ 6.35 ( 1/4" )				
	Connecting method			Flare connection	Flare connection			
Installation	Attached length of piping		m	Liquid line: 0.81 / Gas line: 0.74				
data	Insulation for piping	41-	<u> </u>		ides), independent			
	Refrigerant line (one way) ler		m		x.25			
	Vertical height diff. between	U/U and I/U	m	`	/ Max.15 ( Outdoor unit is lower )			
Drain hose				Hose connectable (VP16)	Hole size φ 20 × 15 pcs.			
Drain pump, max lift height  Recommended breaker size			mm	_				
			A		0			
	ed rotor ampere)		A		.1			
Interconnect	ing wires Size × Core	number	-	, ,	le ) / Terminal block ( Screw fixing type )			
IP number	I assessation		-	IPX0	IPX4			
	N connecting		-	Standard equipment  Mounting bit Clean filter / Allergen clear filter y 1	Photocotolytic washable deadering filter : 4 \			
Standard ac	CESSOTIES		-		, Photocatalytic washable deodorizing filter × 1 )			
Option parts	Option parts			Interface kit ( SC-BIKN2-E ) (Cannot be used with wireless LAN)	_			

#### Notes (1) The data are measured at the following conditions.

The pipe length is 5m.


( )			5			mo pipo iongario omi
	Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation		DB	WB	DB	WB	Standards
Cooling		27°C	19°C	35°C	24°C	ISO5151-T1
Heating		20°C	_	7°C	6°C	ISO5151-H1
Heating (H	2)	20°C	_	2°C	1°C	ISO5151-H2

<sup>(2)</sup> This air-conditioner is manufactured and tested in conformity with the ISO.(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.(4) Select the breaker size according to the own national standard.

## 2. EXTERIOR DIMENSIONS

## (1) Indoor units

Models SRK20ZTX-WA, 25ZTX-WA, 35ZTX-WA



Unit:mm

#### (2) Outdoor units

Models SRC20ZTX-WA, 25ZTX-WA, 35ZTX-WA

Service space

Outlet

 $\mathbb{C}^2$ 

 $\stackrel{\downarrow}{\sim}$ Inlet

 $\Gamma$ 

180 Open 80 Open  $\geq$ 280 Open 80 250

Open

280

Open 100 250

 $\sqsubseteq$ 7 L3 4

Ħ

Minimum installation space

protrude more than 15mm.

(3) If the unit is installed in the location where there is a possibility of strong winds, place the unit such that the direction of air from the

outlet gets perpendicular to the wind direction.

(4) Leave 200mm or more space above the unit.
(5) The wall height on the outlet side should be 1200mm or less.
(6) The model name label is attached on the right side of the unit.

(1) The unit must not be surrounded by walls on the four sides.
(2) The unit must be fixed with anchor bolts. An anchor bolt must not Size φ9.52(3/8") (Flare) φ6.35(1/4") (Flare) M10-12 × 4 places  $\phi$  20 × 15 places *ο*04  $\circ$ Service valve connection (liquid side) Service valve connection (gas side) 33.5 Pipe/cable draw-out hole Drain discharge hole 148.4 Anchor bolt hole Terminal block മ 3.138 590 24.3 312.5 14.8 മ ပ 9.68 25 25 25 45.5 4.91 9.4.5 17.9 71.2 Center of gravity Ш 46.6 50.6 201 12 161 2-12X16 Slot hole 800 Center of gravity 510 520.6 520 462.3 405.3 327.3 327.3 249.3 188.3 68 38.6 Ш 54.6 Ш 11.6 9.25 12.4 5.17 43.5 50 079 6.68

RCT000Z040


9.06


142 580

## (3) Remote control

## (a) Wireless remote control

Unit : mm







# (b) Wired remote control (Option parts) Interface kit (SC-BIKN2-E) is required to use the wired remote control.

#### **Model RC-EX3A**

# Dimensions (Viewed from front)



## Installation space



## • Do not install the remote control at following places.

- (1) It could cause break-down or deformation of remote control.
  - · Where it is exposed to direct sunlight
  - Where the ambient temperature becomes 0 °C or below, or 40 °C or above
  - · Where the surface is not flat
  - · Where the strength of installation area is insufficient
- (2) Moisture may be attached to internal parts of the remote control, resulting in a display failure.
  - · Place with high humidity where condensation occurs on the remote control
  - · Where the remote control gets wet
- (3) Accurate room temperature may not be detected using the temperature sensor of the remote control.
  - Where the average room temperature cannot be detected
  - Place near the equipment to generate heat
  - · Place affected by outside air in opening/closing the door
  - · Place exposed to direct sunlight or wind from air-conditioner
  - Where the difference between wall and room temperature is large
- (4) When you are using the automatic grille up and down panel in the IU, you may not be able to confirm the up and down motion.
  - · Where the IU cannot be visually confirmed

#### When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.

It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.


The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.

#### R/C cable:0.3mm<sup>2</sup> x 2 cores

When the cable length is longer than 100m, the max size for wires used in the R/C case is 0.5mm². Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

≦ 200m	0.5mm <sup>2</sup> × 2 cores
≦ 300m	0.75mm <sup>2</sup> × 2 cores
≦ 400m	1.25mm² × 2 cores
≤ 600m	2.0mm <sup>2</sup> × 2 cores

Adapted RoHS directive



## Wiring specifications

(1) If the prolongation is over 100m, change to the size below.

But, wiring in the remote control case should be under 0.5mm². Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

Length	Wiring thickness
100 to 200m	0.5mm <sup>2</sup> × 2 cores
Under 300m	0.75mm <sup>2</sup> × 2 cores
Under 400m	1.25mm <sup>2</sup> × 2 cores
Under 600m	2.0mm <sup>2</sup> × 2 cores


PJZ000Z295

## 3. ELECTRICAL WIRING

## (1) Indoor units


Models SRK20ZTX-WA, 25ZTX-WA, 35ZTX-WA

Description	Connector											
Item	CNE	CNF	CNG	CNO	CNL	CNM	CNP	CNS	CNU	CNX	CN≺	CNZ



## (2) Outdoor units

#### Models SRC20ZTX-WA, 25ZTX-WA, 35ZTX-WA




# 4. NOISE LEVEL

# (1) Sound power level Model SRK20ZTX-WA

(Indoor unit)


(maoor arm)								
Model	SRK20ZTX-WA							
Noise	Cooling	52 dB(A)						
level	Heating	53 dB(A)						

Condition	ISO5151 T1/H1
MODE	Rated capacity value (Hi)



(Outdoor unit)

Model	SRC20ZTX-WA	
Noise	Cooling	55 dB(A)
level	Heating	57 dB(A)




#### **Model SRK25ZTX-WA**

(Indoor unit)


(1114001 0		
Model	SRK25ZTX-WA	
Noise	Cooling	54 dB(A)
level	Heating	55 dB(A)

Condition	ISO5151 T1/H1	
MODE	Rated capacity value (Hi)	



(Outdoor unit)

`	,	
Model	SRC25ZTX-WA	
Noise	Cooling	55 dB(A)
level	Heating	57 dB(A)




#### **Model SRK35ZTX-WA**

(Indoor unit)


1	`		-
	Model	SF	RK35ZTX-WA
	Noise	Cooling	57 dB(A)
	level	Heating	57 dB(A)

Condition	ISO5151 T1/H1
MODE	Rated capacity value (Hi)



(Outdoor unit)

( 0 0.10.0	, o ,		
Model	SF	SRC35ZTX-WA	
Noise	Cooling	59 dB(A)	
level	Heating	58 dB(A)	



#### (2) Sound pressure level

## (a) Rated capacity value Model SRK20ZTX-WA


(Indoor unit)

Model	SI	RK20ZTX-WA
Noise	Cooling	38 dB(A)
level	Heating	40 dB(A)

Condition	ISO5151 T1/H1
MODE	Rated capacity value (Hi)

## ■Mike position







## (Outdoor unit)

(		
Model	SRC20ZTX-WA	
Noise	Cooling	43 dB(A)
level	Heating	45 dB(A)

●Mike position: at highest noise level in position as mentioned below Distance from front side 1m





#### **Model SRK25ZTX-WA**

(Indoor unit)


Model	SI	RK25ZTX-WA
Noise	Cooling	39 dB(A)
level	Heating	41 dB(A)

Condition	ISO5151 T1/H1
MODE	Rated capacity value (Hi)

■Mike position




× ---- Cooling, O — Heating



#### (Outdoor unit)

(	/	
Model	SRC25ZTX-WA	
Noise	Cooling	44 dB(A)
level	Heating	45 dB(A)

 Mike position: at highest noise level in position as mentioned below Distance from front side 1m



#### **Models SRK35ZTX-WA**


(Indoor unit)

Model	SRK35ZTX-WA	
Noise	Cooling	43 dB(A)
level	Heating	42 dB(A)

Condition	ISO5151 T1/H1	
MODE	Rated capacity value (Hi)	

Mike position






## (Outdoor unit)

`		
Model	SRC35ZTX-WA	
Noise	Cooling	47 dB(A)
level	Heating	47 dB(A)

 Mike position: at highest noise level in position as mentioned below Distance from front side 1m



#### (b) Each fan speed mode Condition ISO5151 T1/H1 (Indoor unit) MODE Me Model SRK20ZTX-WA Noise Cooling 31 dB(A) Mike position level Heating 33 dB(A) Mike position (Center & low points) × ---- Cooling, O — Heating 70 70 N70 60 60 N60 Sound pressure level (dB) 50 50 (Standard 2×10-5 Pa) N50 40 40 N40 30 30 N30 20 20 N20 10 10 0 0 125 250 500 1000 2000 4000 8000 63 Mid octave band frequency (Hz) (Indoor unit) **MODE** Lo Model SRK20ZTX-WA Mike position Cooling 24 dB(A) Noise level Heating 25 dB(A) Mike position (Center & low points) - Heating 70 70 N70 60 60 N60 Sound pressure level (dB) 50 50 (Standard 2×10-5 Pa) N50 40 40 N40 30 30 N30 20 20 N20 10 10 0 63 125 250 500 1000 2000 4000 8000 Mid octave band frequency (Hz)


#### (Indoor unit)

Model	SRK20ZTX-WA	
Noise	Cooling	19 dB(A)
level	Heating	19 dB(A)

Condition	ISO5151 T1/H1
MODE	ULo

## ■Mike position







#### (Outdoor unit)

(00:000	G. 1 . 1 . 1 . 7	
Model	SF	RC20ZTX-WA
Noise	Cooling	33 dB(A)
level	Heating	38 dB(A)

Mike position: at highest noise level in position as mentioned below
 Distance from front side 1m

MODE	Silent






#### (Indoor unit)

Model	SRK25ZTX-WA	
Noise	Cooling	19 dB(A)
level	Heating	19 dB(A)

Condition	ISO5151 T1/H1
MODE	ULo

## ■Mike position







#### (Outdoor unit)

( 0 0.10.00.	- C	
Model	SF	RC25ZTX-WA
Noise	Cooling	35 dB(A)
level	Heating	39 dB(A)

 Mike position: at highest noise level in position as mentioned below Distance from front side 1m

MODE	Silent






## (Indoor unit)

Model	SRK35ZTX-WA							
Noise	Cooling	19 dB(A)						
level	Heating	19 dB(A)						

Condition	ISO5151 T1/H1
MODE	ULo

## ■Mike position






#### (Outdoor unit)

( 0 0.10.00.	G. 1 . 1 . 1 . 7	
Model	SF	RC35ZTX-WA
Noise	Cooling	38 dB(A)
level	Heating	43 dB(A)


 Mike position: at highest noise level in position as mentioned below Distance from front side 1m

MODE	Silent



# 5. PIPING SYSTEM

## Models SRK20ZTX-WA, 25ZTX-WA, 35ZTX-WA



# 6. RANGE OF USAGE & LIMITATIONS


Model Item	SRK20, 25, 35ZTX-WA
Indoor return air temperature (Upper, lower limits)	Cooling operation : Approximately 18 to 32°C DB Heating operation : Approximately 10 to 30°C DB (Refer to the selection chart)
Outdoor air temperature (Upper, lower limits)	Cooling operation : Approximately -15 to 46°C DB Heating operation : Approximately -25 to 24°C DB (Refer to the selection chart)
Refrigerant line (one way) length	Max. 25m
Vertical height difference between outdoor unit and indoor unit	Max. 15m (Outdoor unit is higher) Max. 15m (Outdoor unit is lower)
Power source voltage	Rating ±10%
Voltage at starting	Min. 85% of rating
Frequency of ON-OFF cycle	Max. 10 times/h (Inching prevention 3-5 minutes)
ON and OFF interval	Min. 3 minutes

## Selection chart

Correct the cooling and heating capacity in accordance with the conditions as follows. The net cooling and heating capacity can be obtained in the following way.

Net capacity = Capacity shown on specification × Correction factors as follows

## (1) Coefficient of cooling and heating capacity in relation to temperatures



#### (2) Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way piping length between the indoor and outdoor units.

Piping length [m]	7	10	15	20	25
Cooling	1.0	0.99	0.975	0.965	0.95
Heating	1.0	1.0	1.0	1.0	1.0


## (3) Correction relative to frosting on outdoor heat exchanger during heating

In additions to the foregoing corrections (1), (2) the heating capacity needs to be adjusted also with respect to the frosting on the outdoor heat exchanger.

Air inlet temperature of outdoor unit in °CWB	-20	-15	-10	-9	-7	-5	-3	-1	1	3	5 or more
Adjustment coefficient	0.95	0.95	0.95	0.94	0.93	0.91	0.88	0.86	0.87	0.92	1.00

#### How to obtain the cooling and heating capacity

Example : The net cooling capacity of the model SRK35ZTX-WA with the piping length of 15m, indoor wet-bulb temperature at  $19.0^{\circ}$ C and outdoor dry-bulb temperature  $35^{\circ}$ C is



## 7. CAPACITY TABLES

## Models SRK20ZTX-WA/SRC20ZTX-WA

Cooling mode	(kW)
--------------	------

	1	i					Indo	or air t	omnor	turo						
	Outdoor	21°0	DR.	23°0	DDB	26°0	DDB	27°C		_	DDB	31%	CDB	33%	DB	
Air flow	air temperature		CWB	_	CWB	_	18°CWB		19°CWB		20°CWB		22°CWB		24°CWB	
	°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	
	10	2.25	2.14	2.36	2.24	2.45	2.32	2.49	2.36	2.53	2.40	2.60	2.47	2.67	2.54	
	12	2.21	2.10	2.32	2.20	2.41	2.29	2.45	2.33	2.50	2.37	2.58	2.45	2.65	2.52	
	14	2.17	2.06	2.28	2.16	2.38	2.26	2.42	2.30	2.47	2.34	2.55	2.42	2.62	2.49	
	16	2.13	2.02	2.24	2.12	2.34	2.22	2.39	2.27	2.43	2.31	2.52	2.39	2.59	2.46	
	18	2.08	1.98	2.19	2.08	2.30	2.19	2.35	2.23	2.40	2.28	2.49	2.36	2.56	2.44	
	20	2.04	1.94	2.15	2.04	2.26	2.15	2.31	2.20	2.36	2.24	2.45	2.33	2.53	2.41	
	22	1.99	1.89	2.10	2.00	2.22	2.11	2.28	2.16	2.32	2.21	2.42	2.30	2.50	2.38	
	24	1.94	1.85	2.05	1.95	2.18	2.07	2.24	2.12	2.28	2.17	2.38	2.26	2.47	2.34	
Hi	26	1.90	1.80	2.01	1.91	2.14	2.03	2.20	2.09	2.24	2.13	2.35	2.23	2.43	2.31	
10.7	28	1.85	1.75	1.96	1.86	2.09	1.99	2.15	2.05	2.20	2.09	2.31	2.19	2.40	2.28	
(m³/min)	30	1.79	1.70	1.90	1.81	2.05	1.94	2.11	2.01	2.16	2.05	2.27	2.16	2.36	2.24	
	32	1.74	1.65	1.85	1.76	2.00	1.90	2.07	1.96	2.12	2.01	2.23	2.12	2.32	2.21	
	34	1.69	1.60	1.80	1.71	1.95	1.85	2.02	1.92	2.07	1.97	2.19	2.08	2.28	2.17	
	35	1.66	1.58	1.77	1.68	1.93	1.83	2.00	1.90	2.05	1.94	2.17	2.06	2.26	2.15	
	36	1.63	1.55	1.74	1.65	1.90	1.81	1.98	1.88	2.02	1.92	2.15	2.04	2.24	2.13	
	38	1.58	1.50	1.68	1.60	1.85	1.76	1.93	1.83	1.98	1.88	2.11	2.00	2.20	2.09	
	40	1.52	1.44	1.63	1.55	1.80	1.71	1.88	1.79	1.93	1.83	2.06	1.96	2.16	2.05	
	43	1.43	1.36	1.54	1.46	1.72	1.64	1.81	1.72	1.85	1.76	1.99	1.89	2.09	1.99	
	46	1.34	1.27	1.44	1.37	1.64	1.56	1.73	1.64	1.77	1.69	1.92	1.83	2.02	1.92	

Air flow	Outdoor air temperature	Indoor air temperature									
	°CWB	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB					
	-25	1.21	1.17	1.12	1.09	1.05					
	-20	1.44	1.40	1.35	1.32	1.28					
	-15	1.66	1.63	1.59	1.55	1.52					
	-10	1.88	1.85	1.82	1.78	1.74					
Hi	-5	2.04	2.01	1.97	1.94	1.91					
14.2	0	2.13	2.10	2.07	2.04	2.01					
(m³/min)	5	2.72	2.69	2.67	2.62	2.58					
	6	2.76	2.73	2.70	2.67	2.63					
	10	2.94	2.91	2.89	2.85	2.82					
	15	3.20	3.17	3.14	3.11	3.08					
	20	3.43	3.41	3.39	3.35	3.32					

## Models SRK25ZTX-WA/SRC25ZTX-WA

Cooling mode (kW)

- (	k	V	V

	Outdoor		Indoor air temperature												
Air flow	air	21°C	DDB	23°0	CDB	26°0	CDB	27°0	DB	28°C	CDB	31°0	CDB	33°0	CDB
All llow	temperature	14°C	CWB	16°0	CWB	18°C	CWB	19°C	CWB	20°C	CWB	22°C	CWB	24°C	CWB
	°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
	10	2.82	2.68	2.95	2.78	3.06	2.90	3.11	2.92	3.16	2.89	3.26	3.04	3.34	2.97
	12	2.77	2.63	2.90	2.75	3.01	2.86	3.07	2.91	3.12	2.88	3.22	3.03	3.31	2.96
	14	2.71	2.58	2.85	2.71	2.97	2.82	3.03	2.87	3.08	2.86	3.18	3.02	3.28	2.95
	16	2.66	2.53	2.80	2.66	2.92	2.78	2.98	2.83	3.04	2.85	3.15	2.99	3.24	2.94
	18	2.60	2.47	2.74	2.60	2.88	2.73	2.94	2.79	2.99	2.83	3.11	2.95	3.20	2.93
	20	2.55	2.42	2.68	2.55	2.83	2.68	2.89	2.75	2.95	2.80	3.07	2.91	3.17	2.92
	22	2.49	2.37	2.63	2.50	2.78	2.64	2.84	2.70	2.90	2.76	3.02	2.87	3.13	2.90
	24	2.43	2.31	2.57	2.44	2.72	2.59	2.80	2.66	2.85	2.71	2.98	2.83	3.08	2.89
Hi	26	2.37	2.25	2.51	2.38	2.67	2.54	2.74	2.61	2.80	2.66	2.93	2.79	3.04	2.88
11.7	28	2.31	2.19	2.44	2.32	2.61	2.48	2.69	2.56	2.75	2.61	2.89	2.74	3.00	2.85
(m³/min)	30	2.24	2.13	2.38	2.26	2.56	2.43	2.64	2.51	2.70	2.56	2.84	2.70	2.95	2.80
	32	2.18	2.07	2.31	2.20	2.50	2.37	2.58	2.46	2.64	2.51	2.79	2.65	2.90	2.76
	34	2.11	2.00	2.25	2.13	2.44	2.32	2.53	2.40	2.59	2.46	2.74	2.60	2.85	2.71
	35	2.08	1.97	2.21	2.10	2.41	2.29	2.50	2.38	2.56	2.43	2.71	2.58	2.83	2.69
	36	2.04	1.94	2.18	2.07	2.38	2.26	2.47	2.35	2.53	2.40	2.69	2.55	2.80	2.66
	38	1.97	1.87	2.11	2.00	2.32	2.20	2.41	2.29	2.47	2.35	2.63	2.50	2.75	2.61
	40	1.90	1.81	2.03	1.93	2.25	2.14	2.35	2.23	2.41	2.29	2.58	2.45	2.70	2.56
	43	1.79	1.70	1.92	1.83	2.15	2.04	2.26	2.15	2.32	2.20	2.49	2.37	2.61	2.48
	46	1.68	1.59	1.81	1.72	2.05	1.95	2.16	2.05	2.22	2.11	2.40	2.28	2.53	2.40

Н	leat	ting	mod	ie (	н	U)
	Icai	iiig	HIOC	10 (		U)

Air flow	air temperature	Indoor air temperature					
	°CWB	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB	
	-25	1.43	1.39	1.33	1.29	1.24	
[	-20	1.70	1.66	1.60	1.57	1.52	
	-15	1.97	1.93	1.88	1.84	1.80	
	-10	2.23	2.19	2.16	2.10	2.06	
Hi	-5	2.41	2.38	2.33	2.30	2.27	
14.8	0	2.53	2.49	2.45	2.42	2.38	
(m³/min)	5	3.22	3.19	3.17	3.10	3.06	
[	6	3.27	3.24	3.20	3.16	3.12	
[	10	3.48	3.45	3.42	3.38	3.34	
	15	3.79	3.75	3.73	3.69	3.65	
	20	4.07	4.04	4.02	3.97	3.94	

## Models SRK35ZTX-WA/SRC35ZTX-WA

Outdoor

Cooling mode (kW)

- 1	Heating mode (H	HC)				(kW)		
flow	Outdoor air temperature	Indoor air temperature						
	°CWB	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB		
	0.5	4.00	4.00	4 70	474	1.07		

Air flow	air	21°0	CDB	23°0	DB	26°0	DDB	27°0	DDB	28°C	DB	31°0	DB	33°0	CDB
Air ilow	temperature	14°C	CWB	16°C	WB	18°C	CWB	19°C	CWB	20°C	WB	22°C	CWB	24°C	CWB
	°CDB	TC	SHC												
	10	3.94	3.47	4.13	3.42	4.28	3.59	4.35	3.55	4.43	3.51	4.56	3.65	4.68	3.56
	12	3.87	3.43	4.06	3.38	4.22	3.56	4.29	3.52	4.37	3.48	4.51	3.64	4.63	3.55
	14	3.80	3.40	3.99	3.35	4.16	3.53	4.24	3.50	4.31	3.46	4.46	3.62	4.59	3.53
	16	3.72	3.37	3.91	3.32	4.09	3.51	4.18	3.47	4.25	3.44	4.40	3.60	4.54	3.52
	18	3.65	3.33	3.84	3.29	4.03	3.48	4.11	3.45	4.19	3.42	4.35	3.58	4.49	3.50
	20	3.57	3.29	3.76	3.25	3.96	3.45	4.05	3.43	4.13	3.39	4.29	3.56	4.43	3.49
	22	3.49	3.26	3.68	3.22	3.89	3.43	3.98	3.40	4.06	3.37	4.23	3.55	4.38	3.47
	24	3.40	3.21	3.59	3.18	3.81	3.40	3.91	3.38	3.99	3.34	4.17	3.53	4.32	3.45
Hi	26	3.32	3.15	3.51	3.14	3.74	3.37	3.84	3.35	3.92	3.32	4.11	3.50	4.26	3.43
13.2	28	3.23	3.07	3.42	3.11	3.66	3.34	3.77	3.32	3.85	3.29	4.04	3.48	4.20	3.42
(m³/min)	30	3.14	2.98	3.33	3.07	3.58	3.30	3.70	3.29	3.78	3.27	3.98	3.46	4.13	3.40
` ′	32	3.05	2.90	3.24	3.03	3.50	3.27	3.62	3.26	3.70	3.23	3.91	3.44	4.06	3.37
	34	2.95	2.81	3.14	2.99	3.41	3.24	3.54	3.23	3.62	3.20	3.84	3.41	4.00	3.35
	35	2.91	2.76	3.10	2.94	3.37	3.20	3.50	3.22	3.58	3.19	3.80	3.40	3.96	3.34
	36	2.86	2.72	3.05	2.90	3.33	3.16	3.46	3.20	3.54	3.18	3.76	3.38	3.92	3.33
	38	2.76	2.62	2.95	2.80	3.24	3.08	3.38	3.17	3.46	3.15	3.69	3.36	3.85	3.30
	40	2.66	2.53	2.85	2.70	3.15	2.99	3.29	3.13	3.37	3.12	3.61	3.34	3.78	3.28
	43	2.51	2.38	2.69	2.56	3.01	2.86	3.16	3.00	3.24	3.07	3.49	3.30	3.66	3.25
	46	2.35	2.23	2.53	2.40	2.87	2.73	3.03	2.88	3.11	2.95	3.36	3.20	3.54	3.21

Indoor air temperature

Air flow	Outdoor air temperature	Indoor air temperature						
	°CWB	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB		
	-25	1.92	1.86	1.78	1.74	1.67		
	-20	2.29	2.23	2.16	2.11	2.05		
	-15	2.65	2.59	2.53	2.48	2.42		
	-10	2.99	2.94	2.90	2.83	2.77		
Hi	-5	3.24	3.20	3.13	3.10	3.05		
15.3	0	3.40	3.35	3.29	3.25	3.20		
(m³/m in)	5	4.33	4.28	4.26	4.17	4.11		
	6	4.40	4.35	4.30	4.25	4.19		
	10	4.68	4.63	4.60	4.54	4.49		
	15	5.09	5.04	5.01	4.95	4.91		
	20	5.47	5.42	5.40	5.34	5.29		

Notes(1) These data show average statuses.

Depending on the system control, there may be ranges where the operation is not conducted continuously.

These data show the case where the operation frequency of a compressor is fixed.

(2) Capacities are based on the following conditions.

Corresponding refrigerant piping length:5m

Level difference of Zero.

(3) Symbols are as follows.

TC: Total cooling capacity (kW)

SHC: Sensible heat capacity (kW)

HC: Heating capacity (kW)

## 8. APPLICATION DATA

(1) Installation of indoor unit

RLF012A219

Model SRK20.25.35ZTX-WA R32 REFRIGERANT USED

This installation manual deals with an indoor unit installation only. For an outdoor unit installation, refer to page 32.

#### SAFETY PRECAUTIONS

- · Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation. If unusual

Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation. If unusual tion work in order to protect yourself.
 The precautionary items mentioned below are distinguished into two levels, [AWARNING] and [ACAUTION].
 WARNING indicates a potentially hazardous situation which, if not avoided, can result in serious consequences such as death or severe injury.
 CAUTION indicates a potentially hazardous situation which, if not avoided, can result in personal injury or property damage.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.

Be sure to use only for residential purpose.

If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse, etc., it can malfunction.

Installation must be carried out by the qualified installer completely in accordance with the installation manual.

Installation by an unqualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury.

Be sure to wear protective goggles and gloves while performing installation work.

Improper safety measures can result in personal injury.

Use the original accessories and the specified components for the installation.

Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury.

Do not install the unit near the location where leakage of flammable gases can occur. If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.

when installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISO5149) in the event of leakage. If refrigerant density exceeds the limit, consult the dealer and install the ventilation system. Otherwise lack of oxygen can occur resulting in serious accident.

Install the unit in a location where unit will remain stable, horizontal and free of any vibration transmission.

of any vibration transmission.
Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.

Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.

Do not run the unit with removed panels or protections.
Touching rotating equipment, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shock.

This unit is designed specifically for R32.
Using any other refrigerant can cause unit failure and personal injury.

Do not vent R32 into atmosphere.
R32 is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 675.

Make sure that no air enters the refrigerant circuit when the unit is installed and removed.

If air enters the refrigerant circuit, the pressure in the refrigerant circuit will become too high, which can cause burst and personal injury.

can cause burst and personal injury.

Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.

Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and personal injury.

Be sure to connect both liquid and gas connecting pipes properly before operating the compressions.

erating the compressor. Do not open the liquid and gas service valves before completing piping work,

and evacuation.

If the compressor is operated when connecting pipes are not connected and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in

Be sure to tighten the flare nuts to specified torque using the torque wrench. Tightening flare nuts with excess torque can cause burst and refrigerant leakage after a long period.

During pump down work, be sure to stop the compressor before closing service valves and removing connecting pipes. If the connecting pipes are removed when the compressor is in operation and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure result-

In the connecting pipes are removed when the compressor is in operation and service varies are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.

In the event of refrigerant leakage during installation, be sure to ventilate the working area properly.

If the refrigerant comes into contact with naked flames, poisonous gases will be produced.

Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations.

Incorrect installation can cause electric shock, fire or personal injury.

Make sure that earth leakage breaker and circuit breaker of appropriate capacities are installed.

Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate breakers can cause electric shock, personal injury or property damage.

Be sure to switch off the power source in the event of installation, maintenance or service. If the power source is not switched off, there is a risk of electric shock, unit failure or personal injury.

Be sure to tighten the cables securely in terminal block and relieve the cables properly to prevent overloading the terminal blocks.

Losse connections or cable mountings can cause anomalous heat production or fire.

Do not process, splice or modify the power cable, or share the socket with other power plugs.

other power plugs.

Improper power cable or power plug can cause fire or electric shock due to poor connection, insufficient insulation or over-current.

Do not perform any change in protective device or its setup condition yourself. Changing protective device specifications can cause electric shock, fire or burst.

Be sure to clamp the cables properly so that they do not touch any internal

component of the unit.

If cables touch any internal component, it can cause overheating and fire.

If capies touch any internal component, it can cause overneating and life.

Be sure to install service cover properly.

Improper installation can cause electric shock or fire due to intrusion of dust or water.

Be sure to use the prescribed power and connecting cables for electrical work.

Using improper cables can cause electric leak or fire.

This appliance must be connected to main power source by means of a cir-

This appliance must be connected to main power source by means of a circuit breaker or switch with a contact separation of at least 3 mm. Improper electrical work can cause unit failure or personal injury.

Be sure to connect the power source cable with power source properly. Improper connection can cause intrusion of dust or water resulting in electric shock or fire.

Do not turn ON the wireless LAN communication near automatic control equipment such as an automatic door or fire-alarm device. It may cause an accident due to malfunction of equipment.

Do not turn ON the wireless LAN communication in a hospital, etc. where the use of wireless devices is prohibited.

use of wireless devices is prohibited.
It may cause malfunction of medical equipment due to a wireless device.
Do not turn ON the wireless LAN communication near a person with a cardiac pacemaker or implanted defibrillator. It may cause malfunction of a medical device

#### **⚠** CAUTION

Take care when carrying the unit by hand.
If the unit weight is more than 20 kg, it must be carried by two or more persons.
Do not carry the unit by the plastic straps. Always use the carry handle.
Do not install the outdoor unit in a location where insects and small animals can inhabit.

Do not install the outdoor unit in a location where insects and small animals can inhabit Insects and small animals can enter the electrical parts and cause damage resulting in fire or personal injury. Instruct the user to keep the surroundings clean.

If the outdoor unit is installed at height, make sure that there is enough space for installation, maintenance and service.

Insufficient space can result in personal injury due to falling from the height.

Do not install the unit near the location where neighbours are bothered by noise or air generating from the unit.

It can affect surrounding environment and cause a claim.

Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere. It can cause corrosion of heat exchanger and damage to plastic parts.

Do not install the unit close to the equipment that generates electromagnetic waves and/or high-harmonic waves.

waves and/or high-harmonic waves.

Equipment such as inverters, standby generators, medical high frequency equipment and telecommunication equipment can affect the system, and cause malfunctions and breakdowns.

The system can also affect medical equipment and telecommunication equipment, and obstruct its

function or cause jamming.

Do not turn ON the wireless LAN communication near another wireless de-

vice, microwave, cordless phone, fax machine, etc. It may cause malfunction of wireless device.

- Do not install the unit in the locations where:

Do not install the unit in the locations where:

 There are heat sources nearby.
 Unit is directly exposed to rain or sunlight.
 There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.
 Unit is directly exposed to oil mist and steam such as kitchen.
 Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate.
 Drain water cannot be discharged properly.
 TV set or radio receiver is placed within 1 m.
 Height above sea level is more than 1000 m.
 It can cause performance degradation, corrosion and damage of components, unit malfunction and fire.

 Dispose of all packing materials properly.
 Packing materials contain nails and wood which can cause personal injury.
 Keep the polybag away from children to avoid the risk of suffocation.
 Do not put anything on the outdoor unit.
 Object may fall causing property damage or personal injury.
 Do not touch the aluminum fin of the outdoor unit.
 Aluminium fin temperature is high during heating operation. Touching fin can cause burn.
 Do not touch any refrigerant pipe with your hands when the system is in operation. During operation the refrigerant pipe with your hands when the system is in operation.
 Do not touch the refrigerant pipe with your hands when the system is in operation.
 Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.
 The isolator should be locked in OFF state in accordance with EN60204-1.


#### 1. ACCESSORIES AND TOOLS


	Standard accessories (supplied with indoor unit)							
(1)	Installation board	#11:00 P # 20 pag (12)	1 pc.	(5)	Wood screws (for remote control holder φ3.5 × 16mm)	Section 1	2 pcs	
(2)	Remote control		1 pc.	(6)	Batteries [R03 (AAA, Micro) 1.5 V]	B	2 pcs	
(3)	Remote control holder		1 pc.	(7)	Air-cleaning filters		2 pcs	
(4)	Tapping screws (for installation board φ4 × 25mm)	<u>O</u> _	5 pcs.	(8)	Insulation (#486 50 × 100 t3)		1 pc.	

٦	Locally procured parts						
+	(a)	Sleeve (1 pc.)					
	(b)	Sealing plate (1 pc.)					
-	(c)	Inclination plate (1 pc.)					
	(d)	Putty					
4	(e)	Connecting cable					
	(f)	Drain hose (extension hose)					
	(g)	Piping cover (for insulation of connection piping)					
	(h)	Clamp and screw (for finishing work)					
	(i)	Electrical tape					

Tools for	Tools for installation Work						
Phillips headed driver	Pipe cutter						
Knife	Hole core drill (65mm in diameter)						
Saw	Wrench key (Hexagon) [4mm]						
Tape measure	Flaring tool set*						
Torque wrench	Gas leak detector*						
(14.0-62.0 N·m (1.4-6.2 kgf·m))	Pipe bender						
Plier	Flare adjustment gauge						
* Designed specifically for R32 or R410							


#### 2. SELECTING INSTALLATION LOCATION 6.5cm minimum from the ceiling (In the case of less than 10 cm, there is a possibility of performance degradation.) After getting customer's approval, select installation location according to following guidelines. 1. Indoor unit 7. Indoor unit Where there is no obstruction to the air flow and where the cooled and heated air can be evenly distributed. A solid place where the unit or the wall will not vibrate. A place where there will be enough space for servicing. (Where space mentioned on the right side can be secured.) Where it is easy to conduct widen and spiring work 10cm minimum from the wall Where it is easy to conduct wiring and piping work. A place where unit is not directly exposed to sunlight or street light. A place where thin is not enterly exposed to surright or street light. A place where it can be easily drained. A place separated at least 1 m away from the television or the radio. (To prevent interference to images and sounds.) A place where this unit is not affected by the high frequency equipment or electric equipment. Avoid installing this unit in place where there is much oil mist. A place where there is no electric equipment or household. Install the indoor unit on the wall where the height from the floor to the bottom of the unit is more than 180 cm. 111cm more than 180 cm. $\bullet$ A place where the radio waves can reach when using the wireless LAN communication œ. 2. Remote control Remote control holder where the air-conditioner can receive the signal surely during operating the remote A place where the air-conditioner can receive the signar suring spansary operations of control. A place where it is not affected by the TV, radio etc. Do not place where it is exposed to direct sunlight or near heat devices such as a stove. Wood screws





Gutter .

#### 6. FORMING PIPING AND DRAIN HOSE 1. Forming piping Piping is possible in the right, rear, downward, left, left rear or left downward direction Forming of piping • Hold the bottom of the Taping of the exterior Tape only the portion that goes through the wall. Always tape the wiring piping and fix direction before stretching it Sufficient care must be taken not to damage and shaping it. with the piping. the panels when connecting pipes. 2. Drain change procedures (1) Remove the screw and drain hose. (2) Remove the drain cap by hand or pliers. (3) Insert the drain cap which was removed at procedure (2) securely using a hexagonal wrench etc. (4) Install the drain hose and screw securely. (1) (3) Left downward Left hand side piping Right hand side piping Piping in the left rear direction Piping in the right rear direct **⚠** CAUTION Incorrect installation of drain hose and cap can cause water leakage Piping in the right dire



#### 9. CONNECTING PIPING WORK

#### 1. Preparation of connecting pipe

7. DRAINAGE WORK Arrange the drain hose in a down
Avoid the following drain piping.

1.1 Selecting connecting pipe
Select connecting pipe according to the following table.

coloct confidenting pipe according to the fellowin					
	Model SRK20/25/35				
Gas pipe	φ9.52				
Liquid pipe	φ6.35				

- Pipe wall thickness must be greater than or equal to 0.8mm.
  Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30)

- 1.2 Cutting connecting pipe
  (1) Cut the connecting pipe to the required length with pipe cutter.
  (2) Hold the pipe downward and remove the burrs. Make sure that no foreign material enters the pipe.
  (3) Cover the connecting pipe ends with the tape.

#### 2. Piping work

- 2.1 Flaring pipe
  (1) Take out flare nuts from the service valves of indoor unit and engage them onto connecting pipes.
  (2) Flare the pipes according to table and figure shown below.
  Flare dimensions for R32 are different from those for conventional refrigerant.
  Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the dimension B with a flare adjustment gauge.








	Copper pipe	B [Rigid (clutch) type]					
	outer diameter	R32	Conventional				
	φ6.35	0-0.5	1.0-1.5				
	φ9.52	0-0.5					

. , .	•
Service valve size (mm)	Tightening torque (N·m)
φ6.35 (1/4")	14-18
φ9.52 (3/8")	34-42




#### **⚠** CAUTION


· Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage · Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant

- 3. Heating and condensation prevention
  (1) Dress the connecting pipe (both liquid and gas pipes) with insulation to prevent it from heating and dew (1) Dress the connecting pipe (botin liquid and yeap pipes) minimized minimi

Pour water to the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
 When extended drain hose is present inside the room, insulate it securely with heat insulator available in the market.

Since this air-conditioner is designed to collect dew drops on the rear surface to the drain pan, do not install the connecting wire above the gutter.





80


Pipe assembly (h)Screv

# NOTE

Locations where relative humidity exceeds 70 %, both liquid and gas pipes need to be dressed with 20 mm or thicker heat insulation materials

- Improper insulation can cause condensate(water) formation during cooling operation.
   Condensate can leak or drip causing damage to household property.
   Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating operation. It can cause cable deterioration and personal injury.

- 4. Finishing work
  (1) Make sure that the exterior portion of connecting pipes, connecting cable and (1) wake sure that the exterior point on commercing pieps, connecting cable and drain hose is wrapped properly with tape. Shape the connecting pieps to match with the contours of the pipe assembly route. (2) Fix the pipe assembly with the wall using clamps and screws. Pipe assembly should be anchored every 1.5 m or less to isolate the vibration. (3) Install the service cover securely. Water may enter the unit if service cover is not installed properly, resulting in unit malfunction and failure.



## **⚠ WARNING**

# To avoid the risk of fire or explosion, the flared connection must/shall be installed outdoors. Reusable mechanical connectors and flared joints are not allowed indoors.

#### **⚠** CAUTION

Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations.

# 10. HOW TO OPEN, CLOSE, REMOVE AND INSTALL THE AIR INLET PANEL

Pull the air inlet panel at both ends of lower part and release latches, then pull up the panel until you feel resistance. (The panel stops at approx. 60° open position)

#### 2. Close

Hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the

**3. Removing**Open the panel by 80° (as shown in the right illustration) and then pull it forward.

4. Installing
Insert the panel arm into the slot on the front
panel from the position shown in right illustration,
hold the panel at both ends of lower part, lower
it downward slowly, then push it slightly until the
latch works.

#### NOTE

When carrying out maintenance, handle the air inlet panel with care.

# Approx. 80°

#### 13. INSTALLING TWO AIR-CONDITIONERS IN THE **SAME ROOM**

In case two air-conditioners are installed in the same room, apply this setting so that one unit can be operated with only one remote control.

#### Setting one remote control

- (1) Slide and take out the cover and batteries.(2) Cut the switching line next to the battery with wire
- cutters.
  (3) Set the batteries and cover again


- Setting one indoor unit

  (1) Turn off the power source and turn it on after 1 minute.

  (2) Send the signal by pressing the ACL switch on the remote control that was set according to the procedure described on the above side.
- (3) Check that the reception buzzer sound "Peep" is emitted from the indoor unit. Since the signal is sent about 6 seconds after the ACL switch is pressed, point the remote control to the indoor unit for a while.

#### NOTE

If no reception buzzer is emitted, restart the setting from the




# 11. HOW TO REMOVE AND INSTALL THE SIDE AND FRONT PANEL

#### 1. Side panel (R/L)

1.1 Removing
(1) Remove the 2 screws.
(2) Remove the 3 latches and then side panel can be removed.

- 1.2 Installing
  (1) Cover the unit with the side panel and fix 3 latches.
- (2) Secure the side panel with the 2 screws




#### 2. Front panel

- 2.1 Removing
  (1) Remove the side panel (R/L), the air inlet panel, the air filters and the bottom panel.
  (2) Remove the 3 screws.
- (3) Remove the 4 upper latches and then front panel can be removed.

- panel can be removed.

  2.2 Installing
  (1) Cover the unit with the front panel and fix 4 upper latches.
  (2) Secure the front panel with the 3 screws.
  (3) Install the bottom panel, the side panel (R/L), the air inlet panel and the air filters.




#### 12. INSTALLING REMOTE CONTROL

#### Mount the batteries

- (1) Slide and take out the cover of backside.
  (2) Mount the batteries [R03 (AAA, Micro), × 2 pieces] in the body property.
  (Fit he poles with the indication marks + & -)
  (3) Set the cover again.


- Do not use new and old batteries together.
  In case the unit is not operated for a long time, take out the batteries



## Installing remote control holder

- (1) Select the place where the unit can receive
- signals.
  (2) Fix the holder to pillar or wall with wood

# Do not mix old and new batteries, or batteries of different types (manganese/alkaline).



#### 14. TERMINAL CONNECTION FOR AN INTERFACE

adapter

This unit is standardly equipped with a wireless LAN adapter.

To install wired remote control, Superlink etc., interface kit is needed. When using the interface kit, the wireless LAN function cannot be used

- When using the interface kit, the wireless LAN (1) Turn off the power source.

  (2) Remove the air inlet panel, bottom panel and side panel (R).

  (3) Remove the control cover. (Remove the screw.)

  (4) There is a terminal (respectively marked with CNS) on the indoor unit PCB. Disconnect the harness from the CNS terminal. Remove the wireless LAN adapter from the control box, and pull out the wireless LAN adapter harness from the wireless from the wire

After that, install the wireless LAN adapter in


After that, install the wireless LAN adapter in the control box.
While connecting an interface, connect to the CNS terminal securely with the connection harness supplied with an option "Interface connection kit SC-BIKN2-E" and fasten the connection harness onto the indoor control box with the clamp and screw supplied with the kit. (5) Interface kit

Hook to fix the "interface kit" to the 2


latches on side panel (L). For more details, refer to the user's manual of "Interface connection kit SC-BIKN2-F"

#### NOTE

Make sure that the disconnected connector does not touch the internal parts of the unit.







#### 15. PUMP DOWN WORK

For the environmental protection, be sure to pump down when relocating or disposing of the unit. Pump down is the method of recovering refrigerant from the indoor unit in the outdoor unit before the connecting pipes are removed from the unit. When pump down is carried out, forced cooling operation is needed.

#### Forced cooling operation

Turn off the power source and turn it on again after 1 minute. The air inlet panel and flap open and close

(2) After the air inlet panel closes, press the ON/OFF button continuously for at least 5 seconds. Then operation will start.

For the detail of pump down, refer to the installation manual of



#### 16. INSTALLATION CHECK AND TEST RUN

After finishing the installation work, check the following points again before turning on the power. Conduct a test run and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

Before test run

Before test run, check following points.			
	Power source voltage complies with the rated voltage of air-conditioner.		
	Earth leakage breaker and circuit breaker are installed.		
	Power cable and connecting cable are securely fixed to the terminal block.		
	Both liquid and gas service valves are fully open.		
	No gas leaks from the joints of the service valves.		
	Indoor and outdoor side pipe joints have been insulated.		
	Hole on the wall is completely sealed with putty.		
	Drain hose and cap are installed properly.		
	Screw of the terminal cover is tightened securely.		

Test run
Chack following points during test run.

Check following points during tool run.		
Indoor unit receives signal of remote control.		
Air-conditioning operation is normal.		
There is no abnormal noise.		
Water drains out smoothly.		
Display of remote control is normal.		

## After test run

Aiter test run	
Explain the operating and maintenance methods to the user according to the user's manual.	
Keep this installation manual together with user's manual.	

#### NOTE

During restart or change in operation mode, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not malfunction.

#### (2) Installation of outoor unit

RWC012A079

Model SRC20.25.35ZTX-WA R32 REFRIGERANT USED

This installation manual deals with an outdoor unit installation only. For an indoor unit installation, refer to page 28.

#### **SAFETY PRECAUTIONS**

#### **⚠ WARNING**

- Be sure to use only for residential purpose. If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse, etc., it can malfunction.

  Installation must be carried out by the qualified installer completely in accordance with the installation manual.

  Installation by an ungualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury.

  Be sure to wear protective goggles and gloves while performing installation work. Improper safety measures can result in personal injury.

  Use the original accessories and the specified components for the installation. Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury.

  Do not install the unit near the location where leakage of flammable gases can occur. If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.
- When installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISO5149) in the event of leakage.

  If refrigerant density exceeds the limit, consult the dealer and install the ventilation system.
- Otherwise lack of oxygen can occur resulting in serious accident.

  Install the unit in a location where unit will remain stable, horizontal and free
- of any vibration transmission.

  Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.

  Do not run the unit with removed panels or protections.
- Touching rotating equipment, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shock.

- trapment, burn or electric shock.

  This unit is designed specifically for R32.

  Using any other refrigerant can cause unit failure and personal injury.

  Do not vent R32 into atmosphere.
  R32 is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 675.

  Make sure that no air enters the refrigerant circuit when the unit is installed and reproved. and removed.

  If air enters the refrigerant circuit, the pressure in the refrigerant circuit will become too high, which
- can cause burst and personal injury.
- can cause burst and personal injury. **Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.**Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and personal injury. **Be sure to connect both liquid and gas connecting pipes properly before op-**
- erating the compressor.
- Do not open the liquid and gas service valves before completing piping work,
- and evacuation.

  If the compressor is operated when connecting pipes are not connected and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.
- burst or personal injury. **Be sure to tighten the flare nuts to specified torque using the torque wrench.**Tightening flare nuts with excess torque can cause burst and refrigerant leakage after a long period.

- Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation work in order to protect yourself.

  The precautionary items mentioned below are distinguished into two levels, [AWARNING] and ACAUTION]

  WARNING Indicates a potentially hazardous situation which, if not avoided, can result in serious consequences such as death or severe injury.

  CAUTION Indicates a potentially hazardous situation which, if not avoided, can result in personal injury or property damage.

  Both mention the important items to protect your health and safety. Therefore, strictly follow them by any means.

  Be sure to confirm no operation problem on the equipment after completing the installation. If unusual noise can be heard during the test run, consult the dealer.

  Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.

  Be sure to keep the installation manual together with user's manual at a place where it is easily accessible to the user any time. Moreover, ask the user to hand the manuals to a new user, whenever required. Jury or property damage.

  - During pump down work, be sure to stop the compressor before closing service valves and removing connecting pipes.

    If the connecting pipes are removed when the compressor is in operation and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury. In the event of refrigerant leakage during installation, be sure to ventilate the working area properly.

    If the refrigerant comes into contact with naked flames, poisonous gases will be produced. Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations. Incorrect installation can cause electric shock, fire or personal injury.

    Make sure that earth leakage breaker and circuit breaker of appropriate ca-

  - Make sure that earth leakage breaker and circuit breaker of appropriate ca-
  - pacities are installed.

    Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate
  - breakers can cause electric shock, personal injury or property damage.

    Be sure to switch off the power source in the event of installation, maintenance or service.

    If the power source is not switched off, there is a risk of electric shock, unit failure or personal injury.

  - Be sure to tighten the cables securely in terminal block and relieve the ca-bles properly to prevent overloading the terminal blocks. Loose connections or cable mountings can cause anomalous heat production or fire. Do not process, splice or modify the power cable, or share the socket with

  - other power plugs.

    Improper power cable or power plug can cause fire or electric shock due to poor connection, insufficient insulation or over-current.

    Do not perform any change in protective device or its setup condition yourself.

  - Changing protective device specifications can cause electric shock, fire or burst.

    Be sure to clamp the cables properly so that they do not touch any internal component of the unit.

    If cables touch any internal component, it can cause overheating and fire.

    Be sure to install service cover properly.

    Improper installation can cause electric shock or fire due to intrusion of dust or water

  - Improper installation can cause electric shock or fire due to intrusion of dust or water.

    Be sure to use the prescribed power and connecting cables for electrical work.

    Using improper cables can cause electric leak or fire.

    This appliance must be connected to main power source by means of a circuit breaker or switch with a contact separation of at least 3mm.

    Improper electrical work can cause unit failure or personal injury.

    Be sure to connect the power source cable with power source properly.

    Improper connection can cause intrusion of dust or water resulting in electric shock or fire.

    Do not turn ON the wireless LAN communication near automatic control equipment such as an automatic door or fire-alarm device.

    It may cause an accident due to mailuricition of fequipment
  - It may cause an accident due to malfunction of equipment.

    Do not turn ON the wireless LAN communication in a hospital, etc. where the
  - use of wireless devices is prohibited.

    It may cause malfunction of medical equipment due to a wireless device.

    Do not turn ON the wireless LAN communication near a person with a cardiac pacemaker or implanted defibrillator.

    It may cause malfunction of a medical device.

# **↑** CAUTION

- Take care when carrying the unit by hand.

  If the unit weight is more than 20kg, it must be carried by two or more persons. Do not carry the unit by the plastic straps. Always use the carry handle.
- Do not install the outdoor unit in a location where insects and small animals can inhabit.

  Insects and small animals can enter the electrical parts and cause damage resulting in fire or personal injury. Instruct the user to keep the surroundings clean.
- If the outdoor unit is installed at height, make sure that there is enough space for installation, maintenance and service.

  Insufficient space can result in personal injury due to falling from the height.

- Do not install the unit near the location where neighbours are bothered by noise or air generating from the unit.

  It can affect surrounding environment and cause a claim.

  Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere.

  It can cause corrosion of heat exchanger and damage to plastic parts.

  Do not install the unit close to the equipment that generates electromagnetic waves and/or high harmonic waves.
- waves and/or high-harmonic waves.

  Equipment such as inverters, standby generators, medical high frequency equipment and telecommunication equipment can affect the system, and cause malfunctions and breakdowns.
- The system can also affect medical equipment and telecommunication equipment, and obstruct its
- function or cause jamming. Do not turn ON the wireless LAN communication near another wireless device, microwave, cordless phone, fax machine, etc. It may cause malfunction of wireless device.

- Do not install the unit in the locations where:

- Do not install the unit in the locations where:

   There are heat sources nearby.

  Unit is directly exposed to rain or sunlight.

   There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.

   Unit is directly exposed to oil mist and steam such as kitchen.

   Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate.

   Drain water cannot be discharged properly.

   TV set or radio receiver is placed within 1 m.

   Height above sea level is more than 1000 m.

  It can cause performance degradation, corrosion and damage of components, unit malfunction and fire.

  Dispose of all packing materials properly.

  Packing materials contain nails and wood which can cause personal injury.

  Keen the polybrag away from children to avoid the risk of suffication.

- Keep the polybag away from children to avoid the risk of suffocation.

- Keep the polybag away from children to avoid the risk of suffocation.

  Do not put anything on the outdoor unit.

  Object may fall causing property damage or personal injury.

  Do not touch the aluminum fin of the outdoor unit.

  Aluminium fin temperature is high during heating operation. Touching fin can cause burn.

  Do not touch any refrigerant pipe with your hands when the system is in operation.

  During operation the refrigerant pipes become extremely hot or extremely cold depending on the operating condition. Touching pipes can cause personal injury like burn (hot/cold).

  Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.

  The isolator should be locked in OFF state in accordance with EN60204-1.

#### 1. ACCESSORIES AND TOOLS

Locally procured parts Tools for installation work			
(a) Anchor bolt (M10-M12) × 4 pcs.	Phillips head driver	Spanner wrench	Vacuum pump*
(b) Putty	Knife	Torque wrench [14.0-62.0 N•m (1.4-6.2 kgf•m)]	Gauge manifold *
	l		, ,
(c) Electrical tape	Saw	Wrench key (Hexagon) [4mm]	Charge hose *
(d) Connecting pipe	Tape measure		Vacuum pump adapter*
(e) Connecting cable			(Anti-reverse flow type)
(f) Power cable	Pipe cutter	Flare adjustment gauge	Gas leak detector *
(g) Clamp and screw (for finishing work) *Designed specifically for R32 of			ned specifically for R32 or R410A

#### 2. OUTDOOR UNIT INSTALLATION

- Note as a unit designed for R32

   Do not use any refrigerant other than R32. R32 will rise to pressure about 1.6 times higher than that of a conventional refrigerant. A cylinder containing R32 has a light blue indication mark on the top.

   Do not use a charge cylinder. The use of a charge cylinder will cause the refrigerant composition to charge, which results in performance degradation.

   In charging refrigerant, always take it out from a cylinder in the liquid phase.

   All indoor units must be models designed exclusively for R32. Check connectable indoor unit models in a catalog, etc. (A wrong indoor unit, if connected into the system, will impair proper system operation)

#### 1. Haulage

- Naways carry or move the unit with two or more persons.
   The right hand side of the unit as viewed from the front (outlet side) is heavier. A person carrying the right hand side must take care of this fact. A person carrying the left hand side must hold the handle provided on the front panel of the unit with his right hand and the corner column section of the unit with his left hand.



#### **⚠** CAUTION

When a unit is hauled, take care of its gravity center position which is shifted towards right hand side. If the unit is not hauled properly, it can go off balance and fall resulting in serious injury.

- Selecting the installation location
   Select the suitable installation location where:
   Unit will be stable, horizontal and free of any vibration transmission.
- There is no obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.
- There is enough space for service and maintenance of unit.
  Neighbours are not bothered by noise or air generating from the unit.
  Outlet air of the unit does not blow directly to animals or plants.
  Drain water can be discharged properly.
- There is no risk of flammable gas leakage.
- There are no other heat sources nearby.
  Unit is not directly exposed to rain or sunlight.
  Unit is not directly exposed to oil mist and steam.
- Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will not generate or accumulate.
- · Unit is not directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere. No TV set or radio receiver is placed within 1m.
- Unit is not affected by electromagnetic waves and/or high-harmonic waves generated by other equipments.
   Strong wind does not blow against the unit outlet.
- Heavy snowfalls do not occur (If installed, provide proper protection to avoid snow accumulation).

#### NOTE

If the unit is installed in the area where there is a possibility of strong wind or snow accumulation, the following measures are required.


 Place the unit with its outlet side facing the wall.
 Place the unit such that the direction of air from the outlet gets perpendicular to the wind direction. tion.






#### (2) Location of snow accumulation

- Install the unit on the base so that the bottom is higher than snow cover surface
- Install the unit under eaves or provide the roof on



#### 3. Installation space

There must be 1m or larger space between the unit and the wall in at least 1 of the 4 sides. Walls surrounding the unit from 4 sides is not acceptable. The wall height on the outlet side should be 1200 mm or less. Refer to the following figure and table for details.



				(111111)
Example insta	allation I	II	III	IV
L1	Open	280	280	180
L2	100	75	Open	Open
L3	100	80	80	80
L4	250	Open	250	Open

#### NOTE

When more than one unit are installed side by side, provide a 250mm or wider interval between them


## **↑** CAUTION

When more than one unit are installed in parallel directions, provide sufficient inlet space so that short-circuiting may not occur.

#### 4. Installation

- Install the unit on a flat level base.

  While installing the unit, keep space and fix the unit's legs with 4 anchor bolts as shown in the figure below. The protrusion of an anchor bolt from the foundation surface must be kept within 15mm.




#### **⚠** CAUTION

- Install the unit properly so that it does not fall over during earthquake, strong wind, etc.

  Make sure that unit is installed on a flat level base. Installing unit on uneven base may result in unit


Do not block the drain holes when installing the outdoor unit.



#### 3. PREPARATION FOR WORK


#### 1. Removing service cover

w. Slide service cover downwards and remove it



#### 2. Removing terminal cover

and take out terminal cover




#### 4. CONNECTING PIPING WORK

#### 1. Restrictions on unit installation

Abide by the following restrictions on unit installation. Improper installation can cause compressor failure or performance degradation

Dimensional restrictions	
SRC20/25/35	
25m or less	
15m or less	



\* Outdoor unit installation position can be higher as well as lower than the indoor unit installation position

#### 2. Preparation of connecting pipe

2.1 Selecting connecting pipe
Select connecting pipe according to the following table

	SRC20/25/35
Gas pipe	φ9.52
Liquid pipe	φ6.35

Pipe wall thickness must be greater than or equal to 0.8mm.
 Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30)

#### NOTE


If it is required to reuse the existing connecting pipe system, refer to 5. UTILIZATION OF EXISTING PIPE.

- 2.2 Cutting connecting pipe
  (1) Cut the connecting pipe to the required length with pipe cutter.
  (2) Hold the pipe downward and remove the burrs. Make sure that no foreign material enters the pipe.

#### 3. Piping work

Check that both liquid and gas service valves are fully closed.

Carry out the piping work with service valves fully closed.



3.1 Flaring pipe


(1) Take out flare nuts from the service valves of outdoor unit and engage them onto connecting pipes.

(2) Flare the pipes according to table and figure shown below.

Flare dimensions for R32 are different from those for conventional refrigerant.

Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the dimension B with a flare adjustment gauge.





Copper pipe	B [Rigid (clutch) type]		
outer diameter	R32	Conventional	
φ6.35	0-0.5	1.0-1.5	
φ9.52	0-0.5	1.0-1.5	

3.2 Connecting pipes
(1) Connect pipes on both liquid and gas sides.
(2) Tighten nuts to specified torque shown in the table bel

( ) 3		
Service valve size (mm)	Tightening torque (N·m)	
φ6.35 (1/4")	14-18	
φ9.52 (3/8")	34-42	



Do not hold the valve cap area with a spanne

#### **⚠** CAUTION

Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage.
 Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant leakage.

#### 4. Evacuation

- (1) Connect vacuum pump to gauge manifold. Connect charge hose of gauge manifold to service port of outdoor unit.
- of outdoor unit.

  (2) Run the vacuum pump for at least one hour after the vacuum gauge shows -0.1 MPa (-76 cm Hg).

  (3) Confirm that the vacuum gauge indicator does not rise even if the system is left for 15 minutes or more. Vacuum gauge indicator will rise if the system has moisture left inside or has a leakage point. Check the system for the leakage point. Check the system for the leakage point is found, repair it and return to (1) again.

  (4) Close the Handle Lo and stop the vacuum pump.

  Keep this state for a few minutes to make sure that the compound pressure gauge pointer does not
- swing back.
- (5) Remove valve caps from liquid service valve and gas service valve (6) Turn the liquid service valve's rod 90 degree counterclockwise with a hexagonal wrench key to open
- Close it after 5 seconds, and check for gas leakage
- Close it after 5 seconds, and check for gas leakage.


  Using soapy water, check for gas leakage from indoor unit's flare and outdoor unit's flare and valve rods.

  Wipe off all the water after completing the check.

  (7) Disconnect charging hose from gas service valve's service port and fully open liquid and gas service valves. (Oo not attempt to turn valve rod beyond its stop.)

  (8) Tighten service valve caps and service port cap to the specified torque shown in the table below.

Service valve size (mm)	Service valve cap tightening torque (N·m)	Service port cap tightening torque (N·m)
ø6.35 (1/4")	20-30	10-12
ø9.52 (3/8")	20-30	10-12



#### **⚠** CAUTION

To prevent vacuum pump oil from entering into the refrigerant system, use a counterflow prevention adapter.

#### 5. Additional refrigerant charge

Additional refrigerant charge is required only when connecting pipe length exceeds 15m. 
5.1 Calculating additional refrigerant charge 
Additional refrigerant charge can be calculated using the formula given below. 
Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } × 20 (g/m)

#### NOTE

- If additional refrigerant charge calculation result is negative, there is no need to remove the refrigerant.
   If refrigerant recharge is required for the unit with connecting pipe length 15m or shorter, charge the
- factory charged amount as shown in the table below.
- The maximum refrigerant charge amount is designed as shown in the table below

	SRC20/25/35
The factory refrigerant charge amount (kg)	1.25
The maximum refrigerant charge amount (kg)	1.45

#### 5.2 Charging refrigerant

- 5.2 Charging refrigerant (1) Charge the R32 refrigerant in liquid phase from service port with both liquid and gas service valves shut. Since R32 refrigerant must be charged in the liquid phase, make sure that refrigerant is discharged from the cylinder in the liquid phase all the time.
  (2) When it is difficult to charge a required refrigerant amount, fully open both liquid and gas service valves and charge refrigerant, while running the unit in the cooling mode. When refrigerant is charged with the unit being run, complete the charge operation within 30 minutes.
  (3) Write the additional refrigerant charge calculated from the connecting pipe length on the label attached on the service cover.


#### **△** CAUTION

• Running the unit with an insufficient quantity of refrigerant for a long time can cause unit malfunction.

Do not charge more than the maximum refrigerant amount. It can cause unit malfunction

#### 5. UTILIZATION OF EXISTING PIPE





## NOTE


Consult with our distributor in the area, if you need to recover refrigerant and charge it again.

- (2) Clean the existing pipe system according to the procedure given below.
- (2) Clean the existing pipe system according to the procedure given below.
  (a) Carry out forced cooling operation of existing unit for 30 minutes.
  For 'Forced cooling operation' refer to the indoor unit installation manual.
  (b) Stop the indoor fan and carry out forced cooling operation for 3 minutes (Liquid return).
  (c) Close the liquid service valve of the outdoor unit and carry out pump down operation (Refer to 6. PUMP DOWN).
  (d) Blow with nitrogen gas. If discolored refrigeration oil or any foreign matter is discharged by the blow, wash the pipe system or install a new pipe system.
  (3) Remove the flare nuts from the existing pipe system. Go back to 4.CONNECTING PIPING WORK and proceed to step 2.2 Cutting connecting pipe.

- Do not use the old flare nuts (of existing unit). Make sure that the flare nuts supplied with the (new) outdoor unit are used.
   If the flared / compression connection to the indoor unit is located inside the house / room then this pipework can't be reused.

#### 6. PUMP DOWN

- (1) Connect charge hose of gauge manifold to service port of outdoor unit.
   (2) Close the liquid service valve with hexagonal wrench key.
   (3) Fully open the gas service valve with hexagonal wrench key.
   (4) Carry out forced cooling operation (For forced cooling operation procedure, refer to indoor unit installation manual).
   (5) When the low pressure gauge becomes 0.01 MPa, close the gas service valve and stop forced cooling operation.



#### 7. ELECTRICAL WIRING WORK

#### **⚠ WARNING**

- Make sure that all the electrical work is carried out in accordance with the national or regional electrical standards.

  Make sure that the earth leakage breaker and circuit breaker of appropriate capacities are installed
- (Refer to the table given below).

  Do not turn on the power until the electrical work is completed.

  Do not turn on condensive capacitor for power factor improvement under any circums (It does not improve power factor. Moreover, it can cause an abnormal overheat according to the condensive condensive condensive condensive condensive condensity of the condensity condensity

#### Breaker specifications

Model	Phase	Earth leakage breaker	Circuit breaker
SRC20/25/35		Leakage current: 30 mA, 0.1sec or less	Over current: 20 A

#### Main fuce enecification

wain ruse specification				
Model	Specification	Parts No.	Code on LABEL, WIRING	
SRC20/25/35	250 V 20 A	SSA564A136A	F4	

#### 1. Preparing cable

- 1. Preparing cable
  1. Selecting cable
  2. Select the power source cable and connecting cable in accordance with the specifications mentioned below.


  (a) Power source cable
  3. cores\* 2.5mm\* or more, conformed with 60245 IEC57
  When selecting the power source cable, length, make sure that voltage drop is less than 2%.

  If the wire length gets longer, increase the wire diameter.

  (b) Connecting cable
  4 cores\* 1.5mm\*, conformed with 60245 IEC57
  \* 1 Earth wire is included (Yellow/Green).

  (2) Arrange each wire length as shown below.

  Make sure that each wire is stripped 10mm from the end.



(3) Attach round crimp-type terminal to each wire as shown in the below. Select the size of round crimp-type terminal after considering the specifications of terminal block and wire diameter



Power source cable and connecting cable must conform to the specifications mentioned in the manual Using cables with wrong specifications may result in unit malfunction.

- 2. Connecting cable

  (1) Remove the service cover and the terminal cover.

  (2) Connect the cables according to the instructions and figures given below.

  (a) Connect the earth wire of power source cable.

  An earth wire must be connected before connecting the other wires of power source cable.


  Keep the earth wire longer than the remaining two wires of power source cable.

  (b) Connect the remaining two wires (N and L) of power source cable.


  (c) Connect the wires of connecting cable. Make sure that for each wire, outdoor and indoor side terminal numbers match.

  (3) Fasten the cables properly with cable clamps so that no external force may work on terminal connections. Moreover, make sure that cables do not touch the piping, etc. When cables are connected, make sure that all electrical components within the electrical component box are free of loose connector coupling or terminal connection.





<SRC20/25/35>



#### 8. FINISHING WORK


#### 1. Heating and condensation prevention

- 1. Treatming aris Condensation prevention
  (1) Dress the connecting piese (both liquid and gas pipes) with insulation to prevent it from heating and dew condensation. Use the heat insulating material which can withstand 120°C or higher temperature. Make sure that insulation is wrapped tightly around the pipes and no gap is let between them.

  (2) Wrap the refrigerant piping of indoor unit with indoor unit heat insulation using tape.


  (3) Cover the flare-connected joints (indoor side) with the indoor unit heat insulation and wrap it with an insulation pad (standard accessory provided with indoor unit).

  (4) Wrap the connecting pipes, connecting cable and drain hose with the tape.



- 2. Finishing work (1) Make sure that the exterior portion of connecting pipes, connecting cable and drain hose is wrapped properly with tape. Shape the connecting pipes to match with the contours of the pipe assembly route. (2) Fix the pipe assembly with the wall using clamps and screws. Pipe assembly should be anchored every 1.5m or less to isolate the vibration.

  (3) Install the terminal cover and the service cover securely. Water may enter the unit if service cover is not installed properly, resulting in unit malfunction and failure.



#### NOTE

ere relative humidity exceeds 70%, both liquid and gas pipes need to be dressed with 20mm or thicker heat insulation materials

- Improper insulation can cause condensate (water) formation during cooling operation.
   Condensate can leak or drip causing damage to household property.
   Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating operation. It can cause cable deterioration and personal injury.

#### **⚠** CAUTION

Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations.

#### 9. INSTALLATION TEST CHECK POINTS

After finishing the installation work, check the following points again before turning on the power. Conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properties of the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit installation manual) and ensure the conduct test run (Refer to indoor unit

Power source voltage complies with the rated voltage of air-conditioner. Farth leakage breaker and circuit breaker are installed. Power cable and connecting cable are securely fixed to the terminal block Both liquid and gas service valves are fully open.

eny.				
No gas leaks from the joints of the service valves.				
Indoor and outdoor side pipe joints have been insulated.				
Drain hose (if installed) is fixed properly.				
Screw of the terminal cover and the service cover are tightened properly.				

#### Safety precautions in handling air-conditioners with flammable refrigerant

RSA012A090D 🚖

#### R32 REFRIGERANT USED



This equipment uses flammable refrigerants. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.



There is information included in the user's manual and/or installation manual



The user's manual should be read carefully.

A service personnel should be handing this equipment with reference to the installation manual.

- · This safety precaution sheet is for R32 refrigerant. If you want to know the type of refrigerant in the unit, check the label attached to the outdoor unit.
- The precautionary items mentioned below are distinguished into two levels, \( \bar{\text{L}} \) WARNING and \( \bar{\text{L}} \) CAUTION

MARNING: Wrong installation would cause serious consequences such as injuries or death.

⚠ CAUTION : Wrong installation might cause serious consequences depending on circumstances.

#### ⚠ WARNING

- Strict compliance of the domestic laws must be
- observed when disposing the appliance. Do not use means to accelerate the defrost operation process or to clean, other than those recommended by the manufacturer.
- · The appliance shall be stored in a room without continuously operating ignition sources (for example open flames, an operating gas appliance or an operating electric heater).
- · Do not pierce or burn
- Be aware that refrigerants may not contain an
- The ducts connected to an appliance shall not contain a potential ignition source.

#### ⚠ CAUTION

#### 1. General

- That the installation of pipe-work shall be kept to a
- That pipe-work shall be protected from physical damage.
- That compliance with national gas regulations shall be observed.
- That mechanical connections shall be accessible for maintenance purposes
- Keep any required ventilation openings clear of obstruction.
- Servicing shall be performed only as recommended by the manufacturer.
- Equipment piping in the occupied space shall be installed in such a way to protect against accidental damage in operation and service.
- Precautions shall be taken to avoid excessive vibration or pulsation to refrigerating piping
- Protection devices, piping and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris.
- Provision shall be made for expansion and contraction of long runs of piping.
- Piping in refrigerating systems shall be so designed and installed to minimize the likelihood hydraulic shock damaging the system.
- The indoor equipment and pipes shall be securely mounted and guarded such that accidental rupture of equipment cannot occur from such events as moving furniture or reconstruction activities.
- Instructions for wiring to external zoning dampers and/or mechanical ventilation, to ensure that upon detection of a leak, the zoning dampers are driven fully open and additional mechanical ventilation is
- For appliances using A2L refrigerants, connected via an air duct system to one or more rooms, the supply and return air shall be directly ducted to the space. Open areas such as false ceilings shall not be used as a return air duct.
- The following information requirements apply for enhanced tightness refrigerating systems using A2L
- Where safety shut off valves are specified, the minimum room area may be determined based on the maximum amount of refrigerant that can be leaked as determined in GG.12.2. (IEC 60335-2-40:2018)
- Where safety shut off valves are specified, the location of the valve in the refrigerating system relative to the occupied spaces shall be as described in GG.12.1.(IEC 60335-2-40:2018)

#### (2. Unventilated areas

- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- If the refrigerant charge amount in the system is ≥1.84 kg, an unventilated area where the appliance is installed shall be so constructed that should any refrigerant leak, it will not stagnate so as to create a fire or explosion hazard.

#### (3. Qualification of workers

The staff in servicing operations must hold the national qualification or other relevant qualifications.

#### (4. Information on servicing)

- 4.1 Checks to the area
- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised.
- For repair to the refrigerating system, 4.2 to 4.6 shall be completed prior to conducting work on the system.
- 4.2 Work procedure
- Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.
- 4.3 General work area
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
- · Work in confined spaces shall be avoided.
- 4.4 Checking for presence of refrigerant
- · The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe
- 4.5 Presence of fire extinguisher
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

- 4.6 No ignition sources
- No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space.
  Prior to work taking place, the area around the
- equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- "No Smoking" signs shall be displayed.
- 4.7 Ventilated area
- . Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- 4.8 Checks to the refrigerating equipment
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed
- If in doubt consult the manufacturer's technical department for assistance
- The following checks shall be applied to installations using flammable refrigerants:
  - the actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed:
- the ventilation machinery and outlets are
- operating adequately and are not obstructed; if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

#### **⚠** CAUTION

#### 4.9 Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate
- temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.
- · Initial safety checks shall include:
- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding

#### 5. Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
  - This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that the apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres
- Replacement parts shall be in accordance with the manufacturer's specifications

#### (6. Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. Intrinsically safe components are the only types that
- can be worked on while live in the presence of a flammable atmosphere.

  The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer.
- Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them

#### Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans

#### (8. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.
- Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.
- Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

#### NOTE

Examples of leak detection fluids are

- bubble method.
- fluorescent method agents.
- If a leak is suspected, all naked flames shall be removed/extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak
- Removal of refrigerant shall be according to Item 9.

#### 9. Removal and evacuation

- When breaking into the refrigerant circuit to make repairs - or for any other purpose - conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is followed since flammability is a consideration. The following procedure shall be adhered to:
- - remove refrigerant;
  - purge the circuit with inert gas (option for A2L);
  - evacuate (option for A2L);
- purge with inert gas (option for A2L);
- open the circuit by cutting or brazing.
   The refrigerant charge shall be recovered into the
- correct recovery cylinders.
- For appliances containing flammable refrigerants other than A2L refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants.
- This process may need to be repeated several times Compressed air or oxygen shall not be used for
- purging refrigerant systems.
- For appliances containing flammable refrigerants, other than A2L refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system.
- When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation is

#### ( 10. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed.
  - Ensure that contamination of different refrigerants does not occur when using charging equipment Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in
  - Cylinders shall be kept in an appropriate position according to the instructions
  - Ensure that the refrigerating system is earthed
  - prior to charging the system with refrigerant. Label the system when charging is complete (if not already).
  - Extreme care shall be taken not to overfill the
- refrigerating system.

  Prior to recharging the system, it shall be pressure-
- tested with the appropriate purging gas.

  The system shall be leak-tested on completion of charging but prior to commissioning
- A follow up leak test shall be carried out prior to leaving the site.

#### (11. Decommissioning)

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant.
- It is essential that electrical power is available before the task is commenced.
- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that:
- mechanical handling equipment is available, if required, for handling refrigerant cylinders;
- all personal protective equipment is available and being used correctly;
- the recovery process is supervised at all times by a competent person;
- recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
  g) Start the recovery machine and operate in
- accordance with instructions
- h) Do not overfill cylinders. (No more than 80 %volume liquid charge).
  Do not exceed the maximum working pressure of
- the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.

#### 12. Labelling

- Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed.
- For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

#### **A** CAUTION

#### 13. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
  Ensure that the correct number of cylinders for
- Ensure that the correct number of cylinders fo holding the total system charge is available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants.

- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
   Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
   Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- refrigerant does not remain within the lubricant.

  The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.

#### 14. Other safety precautions

- A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts.
- Flammable refrigerant used, refrigerant tubing protected or enclosed to avoid mechanical damage (IEC/EN 60335-2-40).
- Tubing protected to extent that it will not be handled or used for carrying during moving of product (IEC/ EN 60335-2-40).
- Flammable refrigerant used, low temperature solder alloys, such as lead/tin alloys, not acceptable for pipe connections (IEC/EN 60335-2-40).
- Do not use flare nut indoor which is locally procured.

#### Selection of installation location for the indoor unit

• Minimum installation area for indoor unit

#### **⚠** CAUTION

The indoor unit shall be installed in a room with minimum installation area or more according to the refrigerant charge amount (factory refrigerant charge + additional refrigerant charge).

For factory refrigerant charge, refer to the outdoor unit label model name or installation sheet.

For additional refrigerant charge, refer to the outdoor unit installation sheet.

- If the refrigerant charge amount in the system is < 1.84 kg, there are no additional minimum floor area requirements.
- If the refrigerant charge amount in the system is  $\geqq$  1.84 kg, you need to comply with additional minimum floor area requirements as described in the following table.
- For further details regarding the installation location of indoor unit, refer to technical manual.




Figure 1. Minimum installation area (A min) graph

Table 1. Minimum installation area (A min) table

	Minimum installation area [m²]				
Refrigerant charge amount [kg]	Wall mounted units H=1.8 m	Ceiling mounted units H=2.2 m	Floor standing units H=0.6 m*		
1.00					
1.10					
1.20					
1.30					
1.40		No requirements			
1.50					
1.60					
1.70					
1.80					
1.84	4.44	3.64	28.82		
1.90	4.59	3.76	30.73		
2.00	4.83	3.95	34.05		
2.10	5.07	4.15	37.54		
2.20	5.31	4.35	41.20		
2.30	5.55	4.55	45.03		
2.40	5.80	4.74	49.03		
2.50	6.04	4.94	53.20		
2.60	6.40	5.14	57.54		
2.70	6.90	5.34	62.05		
2.80	7.42	5.53	66.73		
2.90	7.96	5.73	71.58		

	Mini	mum installation area	[m²]
Refrigerant charge amount [kg]	Wall mounted units H=1.8 m	Ceiling mounted units H=2.2 m	Floor standing units H=0.6 m*
3.00	8.52	5.93	76.60
3.10	9.09	6.12	81.79
3.20	9.69	6.49	87.16
3.30	10.30	6.90	92.69
3.40	10.94	7.32	98.39
3.50	11.59	7.76	104.26
3.60	12.26	8.21	110.31
3.70	12.95	8.67	116.52
3.80	13.66	9.15	122.90
3.90	14.39	9.63	129.45
4.00	15.14	10.13	136.18
4.10	15.90	10.65	143.07
4.20	16.69	11.17	150.14
4.30	17.49	11.71	157.37
4.40	18.31	12.26	164.77
4.50	19.15	12.82	172.35
4.60	20.01	13.40	180.09
4.70	20.89	13.99	188.01
4.80	21.79	14.59	196.09
4.90	22.71	15.20	204.35
5.00	23.65	15.83	212.78

\*For floor standing units, the value of installation height (H) is considered 0.6 m to comply to IEC 60335-2-40:2018 Clause GG.2.

#### 9. OPTION PARTS

(1) Wired remote control
(a) Model RC-EX3A

PJZ012A171 🛕

## 1) Safety precautions

Please read this manual carefully before starting installation work to install the unit properly. Every one of the followings is important information to be observed strictly.

<b>∆</b> WARNING	Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc.
<b>∴</b> CAUTION	Failure to follow these instructions properly may cause injury or property damage.

It could have serious consequences depending on the circumstances.

The following pictograms are used in the text.



Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, this manual should be given to a new owner.

## **MARNING**

- Consult your dealer or a professional contractor to install the unit.

  Improper installation made on your own may cause electric shocks, fire or dropping of the unit.
- Installation work should be performed properly according to this installation manual.

Improper installation work may result in electric shocks, fire or break-down.

- Be sure to use accessories and specified parts for installation work.
  Use of unspecified parts may result in drop, fire or electric shocks.
- Install the unit properly to a place with sufficient strength to hold the weight.

If the place is not strong enough, the unit may drop and cause injury.

Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.

Power source with insufficient and improper work can cause electric shock and fire.


Shut OFF the main power source before starting electrical work. Otherwise, it could result in electric shocks, break-down or malfunction.

Do not modify the unit.
It could cause electric shocks, fire, or break-down.

# Be sure to turn OFF the power circuit breaker before repairing/ inspecting the unit.

Repairing/inspecting the unit with the power circuit breaker turned ON could cause electric shocks or injury.

#### **!** WARNING





It could cause electric shocks, fire, or break-down.

Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.

Improper connections or fixing could cause heat generation, fire, etc.

## Seal the inlet hole for remote control cable with putty.

If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

If dew or water enters the unit, it may cause screen display anomalies.

## When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.

It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.

The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.

Do not leave the remote control with its upper case removed.

If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

## **ACAUTION**

## Do not install the remote control at following places.

- (1) It could cause break-down or deformation of remote control.
  - Where it is exposed to direct sunlight
  - Where the ambient temperature becomes 0 °C or below, or 40 °C or above
  - Where the surface is not flat
  - · Where the strength of installation area is insufficient
- (2) Moisture may be attached to internal parts of the remote control, resulting in a display failure.
  - Place with high humidity where condensation occurs on the remote control
  - Where the remote control gets wet
- (3) Accurate room temperature may not be detected using the temperature sensor of the remote control.
  - · Where the average room temperature cannot be detected
  - Place near the equipment to generate heat
  - Place affected by outside air in opening/closing the door
  - Place exposed to direct sunlight or wind from air-conditioner
  - Where the difference between wall and room temperature is large

To connect to a personal computer via USB, use the dedicated software.

Do not connect other USB devices and the remote control at the same time.

It could cause malfunction or break-down of the remote control/personal computer.

## 2) Accessories & prepare on site

Following parts are provided.

Accessories R/C main unit, wood screw ( φ 3.5 × 16) 2 pcs., Quick reference

Following parts are arranged at site. Prepare them according to the respective installation procedures.

Item name	Q'ty	Remark
Switch box For 1 piece or 2 pieces (JIS C 8340 or equivalent)	1	
Thin wall steel pipe for electric appliance directly on a wall. (JIS C 8305 or equivalent)	As required	These are not required when installing directly on a wall.
Lock nut, bushing (JIS C 8330 or equivalent)	As required	
Lacing (JIS C 8425 or equivalent)	As required	Necessary to run R/C cable on the wall
Putty	Suitably	For sealing gaps
Molly anchor	As required	
R/C cable (0.3mm <sup>2</sup> × 2 pcs.)	As required	See right table when longer than 100m.

When the cable length is longer than 100m, the max size for wires used in the R/C case is 0.5mm². Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

≦ 200m	0.5mm <sup>2</sup> × 2 cores
≦ 300m	0.75mm <sup>2</sup> × 2 cores
≦ 400m	1.25mm <sup>2</sup> × 2 cores
≦ 600m	2.0mm <sup>2</sup> × 2 cores

## 3) Installation place


Secure the installation space shown in the figure.

For the installation method, "embedding wiring" or "exposing wiring" can be selected.

For the wiring direction, "Backward", "Upper center" or "Upper left" can be selected.

Determine the installation place in consideration of the installation method and wiring direction.


#### Installation space



## 4) Installation procedure

Perform installation and wiring work for the remote control according to the following procedure.

Dimensions (Viewed from front)



To disassemble the R/C case into the upper and lower pieces after assembling them once


· Insert the tip of flat head screwdriver or the like in the recess at the lower part of R/C and twist it lightly to remove. It is recommended that the tip of the screwdriver be wrapped with tape to avoid damaging the case.

Take care to protect the removed upper case from moisture or dust.

#### In case of embedding wiring


(When the wiring is retrieved "Backward")

① Embed the switch box and the R/C wires beforehand. Seal the inlet hole for the R/C wiring with putty




② When wires are passed through the bottom case, fix the bottom case at 2 places on the switch box.

Switch box for 1 pc.



Switch box for 2 pcs.





- ③ Connect wires from X and Y terminals of R/C to X and Y terminals of indoor unit. R/C wires (X, Y) have no polarity. Fix wires such that the wires will run around the terminal screws on the top case of R/C.
- 4 Install the upper case with care not to pinch wires of R/C.

#### Cautions for wire connection

Use wires of no larger than 0.5mm<sup>2</sup> for wiring running through the remote control case. Take care not to pinch the sheath.

Tighten by hand  $(0.7\ N\cdot m\ or\ less)$  the wire connection. If the wire is connected using an electric driver, it may cause failure or deformation.






#### In case of exposing wiring


(When the wiring is taken out from the "upper center" or "upper left" of R/C)

1) Cut out the thin wall sections on the cases for the size of wire.


When taking the wiring out from the upper center, open a hole before separating the upper and bottom cases. This will reduce risk of damaging the PCB and facilitate subsequent work.


When taking the wiring out from the upper left, take care not to damage the PCB and not to leave any chips of cut thin wall inside.





- ② Fix the bottom R/C case on a flat surface with two wood screws.
- ③ In case of the upper center, pass the wiring behind the bottom case. (Hatched section)
- 4 Connect wires from X and Y terminals of R/C to X and Y terminals of indoor unit. R/C wires (X, Y) have no polarity. Fix wires such that the wires will run around the terminal screws on the top case of R/C.
- (5) Install the top case with care not to pinch wires of R/C.
- 6 Seal the area cut in 1 with putty.






## 5) Main/Sub setting when more than one remote control are used

Up to two units of R/C can be used at the maximum for 1 indoor unit or 1 group.

One is main R/C and the other is sub R/C.

Operating range is different depending on the main or sub R/C.



R/C operation			Main	Sub
Run/Stop, Change set temp., Change flap direction, Auto swing, Change fan speed operations			0	0
High power operation, Energy-saving operation			0	0
Silent mode control			0	×
Useful Individual flap control			0	×
functions	Anti draft se	etting	0	×
	Timer		0	0
	Favorite se	tting	0	0
	Weekly tim	er	0	×
	Home leave	e mode	0	×
	External ve	ntilation	0	0
	Select the language		0	0
	Silent mode control			×
Energy-saving setting			0	×
Filter	Filter sign r	eset	0	0
User setting	Initial settings		0	0
	Administrator settings	Permission/ Prohibition setting	0	×
		Outdoor unit silent mode timer	0	×
		Setting temp. range	0	×
		Temp increment setting	0	×
		Set temp. display	0	0
		R/C display setting	0	0
		Change administrator password	0	0
		F1/F2 function setting	0	0

Installation   Installation   Settings   Installation   Installation   Settings   Installation				○ : operable ×: n		
Settings   Company information					Main	Sub
Test run			Installati	on date	0	×
Static pressure adjustment Change auto-address Address setting of main IU IU back-up function Motion sensor setting  R/C function Main/Sub of R/C Return air temp. R/C sensor ox R/C sensor adjustment Operation mode C/PF Fan speed External input Upper/lower flap control Ventilation setting Auto fan speed  IU settings Service & Maintenance Maintenance IU settings Service & Operation data Error display Reset periodical check Saving IU settings Service Saving IU settings	setting	settings		y information	0	0
Change auto-address			Test run		0	×
Address setting of main IU			Static pressure adjustment			×
Address setting of main IU						×
Motion sensor setting				0	×	
R/C function settings			IU back-	0	×	
Return air temp.			Motion s	ensor setting	0	×
R/C sensor			Main/Su	b of R/C	0	0
R/C sensor		settings	Return a	nir temp.	0	×
Operation mode  *C / °F  Fan speed  External input  Upper/lower flap control  Left/right flap control  ×  Ventilation setting  Auto-restart  Auto temp. setting  Auto fan speed  **IU settings  Service & Maintenance  **IU address  Next service date  Operation data  **Error display  Display/erase  anomaly data  Reset periodical check  Saving IU settings  Service & CPU reset  **Operation data					0	×
Fan speed			R/C sen	sor adjustment	0	×
Fan speed			Operation	n mode	0	×
External input  Upper/lower flap control  Left/right flap control  Ventilation setting  Auto-restart  Auto temp. setting  Auto fan speed  Service & Maintenance    U address			°C / °F		0	×
Upper/lower flap control			Fan spe	0	×	
Left/right flap control			External	0	×	
Ventilation setting			Upper/lo	0	×	
Auto-restart			Left/righ	0	×	
Auto temp. setting Auto fan speed  IU settings  Service & Maintenance  Meximum Service date  Operation data  Error display  Error display  Saving IU settings  Seet periodical check  Saving IU settings  Special Erase IU address  CPU reset  Auto temp. setting  ×  Next service date  ○ ×  ○ Operation data  ×  Error display data  Reset periodical check  ○ Saving IU settings  ×  CPU reset  ○ ×			Ventilation	0	×	
Auto fan speed			Auto-res	0	×	
IU settings			Auto ten	0	×	
Service & Maintenance  Maintenance  Next service date  Operation data  Error   Error history   Oisplay/erase   anomaly data   Reset periodical check   Osaving IU settings   Oxaving IU settings   Oxaving IU settings   Oxaving IV settings   Oxa			Auto fan	0	×	
Maintenance         Next service date         ×           Operation data         ×           Error display         Error history         >           Display/erase anomaly data         ×           Reset periodical check         >           Saving IU settings         ×           Special         Erase IU address         ×           CPU reset         >		IU settings		0	×	
Operation data  Error display Display/erase anomaly data Reset periodical check					0	0
Error display   Error history   O   O   Display/lerase anomaly data   Reset periodical check   O   Saving IU settings   O   x   Special settings   CPU reset   O   O		Maintenance	Next service date		0	×
display Display/erase anomaly data Reset periodical check  Saving IU settings  X Special Erase IU address  Settings CPU reset  O  X  X  X  X  X  X  X  X  X  X  X  X			Operation data		0	×
Reset periodical check   O					0	0
Reset periodical check   O			display	Display/erase anomaly data	0	×
Special Erase IU address × settings CPU reset ○				Reset periodical check	0	0
Special Erase IU address × settings CPU reset ○					0	×
			Special	Erase IU address	0	×
			settings	CPU reset	0	0
				Restore of default setting	0	×
Touch panel calibration O				Touch panel calibration	0	0
Indoor unit capacity display O ×			Indoor u	nit capacity display	0	×

#### **Advice: Connection to personal computer**


It can be set from a personal computer via the USB port (mini-B).

Connect after removing the cover for USB port of upper case.

Replace the cover after use.

Special software is necessary for the connection.


For details, view the web site.



#### Advice: Initializing of password

Administrator password (for daily setting items) and service password (for installation, test run and maintenance) are used.

- The administrator password at factory default is "0000". This setting can be changed (Refer to User's Manual).
  - If the administrator password is forgotten, it can be initialized by holding down the [F1] and [F2] switches together for five seconds on the administrator password input screen.
- Service password is "9999", which cannot be changed.
   When the administrator password is input, the service password is also accepted.



## PJA012D730/B

#### (b) Model RC-E5

Read together with indoor unit's installation manual.

#### **MARNING**

Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.

Loose connection or hold will cause abnormal heat generation or fire.

Make sure the power source is turned off when electric wiring work.
Otherwise, electric shock, malfunction and improper running may occur.



#### **ACAUTION**

- Do not install the remote control at the following places in order to avoid malfunction.
  - (1) Places exposed to direct sunlight (4) H
    - (4) Hot surface or cold surface enough to generate condensation (5) Places exposed to oil mist or steam directly
  - (2) Places near heat devices(3) High humidity places
- (6) Uneven surface



Do not leave the remote control without the upper case.


In case the upper cace needs to be detached, protect the remote control with a packaging box or bag in order to keep it away from water and dust.



Accessories	Remote control, wood screw (φ3.5×16) 2 pieces
Prepare on site	Remote control cord (2 cores) the insulated thickness in 1mm or more.
	[In case of embedding cord] Erectrical box, M4 screw (2 pieces)
	[In case of exposing cord] Cord clamp (if needed)

#### Installation procedure


- Open the cover of remote control, and remove the screw under the buttons without fail.
- ② Remove the upper case of remote control. Insert a flat-blade screwdriver into the dented part of the upper part of the remote control, and wrench slightly.





#### [In case of embedding cord]

3 Embed the erectrical box and remote control cord beforehand.

Prepare two M4 screws (recommended length is 12-16mm) on site, and install the lower case to erectrical box. Choose either of the following two positions in fixing it with screws.








- Connect the remote control cord to the terminal block. Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y). (X and Y are no polarity)
- Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.

#### [In case of exposing cord]


- 3 You can pull out the remote control cord from left upper part or center upper part. Cut off the upper thin part of remote control lower case with a nipper or knife, and grind burrs with a file etc.
- ④ Install the lower case to the flat wall with attached two wooden screws.



5 Connect the remote control cord to the terminal block.

Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y). (X and Y are no polarity)

Wiring route is as shown in the right diagram depending on the pulling out direction.



The wiring inside the remote control case should be within 0.3mm² (recommended) to 0.5mm². The sheath should be peeled off inside the remote control case.

The peeling-off length of each wire is as below.

Pulling out from upper left	Pulling out from upper center
X wiring: 215mm	X wiring : 170mm
Y wiring: 195mm	Y wiring: 190mm



- Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.
- In case of exposing cord, fix the cord on the wall with cord clamp so as not to slack.

#### Installation and wiring of remote control


- ① Wiring of remote control should use 0.3mm<sup>2</sup> × 2 cores wires or cables. (on-site configuration)
- ② Maximum prolongation of remote control wiring is 600m.

If the prolongation is over 100m, change to the size below.

But, wiring in the remote control case should be under 0.5mm<sup>2</sup>. Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

#### Master/ slave setting when more than one remote controls are used

A maximum of two remote controls can be connected to one indoor unit (or one group of indoor units.)



Set SW1 to "Slave" for the slave remote control. It was factory set to "Master" for shipment.

Note: The setting "Remote control sensor enabled" is only selectable with the master remote control in the position where you want to check room temperature.

The air-conditioner operation follows the last operation of the remote control regardless of the master/ slave setting of it.

#### The indication when power source is supplied

When power source is turned on, the following is displayed on the remote control until the communication between the remote control and indoor unit settled.

At the same time, a mark or a number will be displayed for two seconds first.

This is the software's administration number of the remote control, not an error cord.



When remote control cannot communicate with the indoor unit for half an hour, the below indication will appear

Check wiring of the indoor unit and the outdoor unit etc.



#### The range of temperature setting

When shipped, the range of set temperature differs depending on the operation mode as below.

Heating: 16-30°C (55-86°F)

Except heating (cooling, fan, dry, automatic): 18-30°C (62-86°F)

#### ●Upper limit and lower limit of set temperature can be changed with remote control.

Upper limit setting: valid during heating operation. Possible to set in the range of 20 to 30°C (68 to 86°F). Lower limit setting: valid except heating (automatic, cooling, fan, dry) Possible to set in the range of 18 to 26°C (62 to 79°F).

When you set upper and lower limit by this function, control as below.

 When @TEMP RANGE SET, remote control function of function setting mode is "INDN CHANGE" (factory setting), [ If upper limit value is set ]

During heating, you cannot set the value exceeding the upper limit.

[ If lower limit value is set ]

During operation mode except heating, you cannot set the value below the lower limit.

2. When ② TEMP RANGE SET, remote control function of function setting mode is "NO INDN CHANGE" [If upper limit value is set ]

During heating, even if the value exceeding the upper limit is set, upper limit value will be sent to the indoor unit. But, the indication is the same as the temperature set.

[ If lower limit value is set ]

During except heating, even if the value lower than the lower limit is set, lower limit value will be sent to the indoor unit. But, the indication is the same as the temperature set.

#### How to set upper and lower limit value


1. Stop the air-conditioner, and press (SET) and (MODE) button at the same time for over three seconds .


The indication changes to "FUNCTION SET ▼".

- 2. Press ▼ button once, and change to the "TEMP RANGE ▲ " indication.
- 3. Press (SET) button, and enter the temperature range setting mode.
- 4. Select "UPPER LIMIT ▼" or "LOWER LIMIT ▲" by using ▲ ▼ button.
- 5. Press (SET) button to fix.
- 6. When "UPPER LIMIT ▼" is selected (valid during heating)
  - ① Indication: "  $\bigcirc \lor \land$  SET UP"  $\rightarrow$  "UPPER 30°C  $\lor$ "
  - ② Select the upper limit value with temperature setting button \( \subseteq \) \( \subseteq \). Indication example: "UPPER 26°C ∨ ∧" (blinking)
  - ③ Press ◯ (SET) button to fix. Indication example: "UPPER 26°C" (Displayed for two seconds)

    After the fixed upper limit value displayed for two seconds, the indication will return to "UPPER LIMIT ▼".
- 7. When "LOWER LIMIT ▲" is selected (valid during cooling, dry, fan, automatic)
  - ① Indication: " $\bigcirc$   $\lor \land$  SET UP"  $\rightarrow$  "LOWER 18°C  $\land$ "
  - ② Select the lower limit value with temperature setting button  $\boxed{\lor}$   $\boxed{\land}$ . Indication example: "LOWER 24°C  $\lor$   $\land$ " (blinking)
  - ③ Press (SET) button to fix. Indication for example: "LOWER 24°C" (Displayed for two seconds)
    After the fixed lower limit value displayed for two seconds, the indication will return to "LOWER LIMIT ▼".
- 8. Press ON/OFF button to finish.

previous screen.





#### The functional setting

The initial nation setting for typical using is performed automatically by the indoor unit connected, when remote control and indoor unit are connected.

As long as they are used in a typical manner, there will be no need to change the initial settings.

If you would like to change the initial setting marked "C", set your desired setting as for the selected item. The procedure of functional setting is shown as the following diagram.

[Flow of function setting] Record and keep the setting Consult the technical data etc. for each control details It is possible to finish above setting on the way, and unfinished change of setting is unavailable.

" ": Initial settings

" ": Automatic criterion Stop air-conditioner and press


O.(SET) + O.(MODE) buttons
at the same time for over three seconds

Note 1: The initial setting marked \* \* is decided by connected indoor and outdoor unit, and is automatically defined as following table. Note 1: The initial s Function No. Remote control function02 Remote control function06 Remote control function07 Remote control function13 ndoor and outdoor unit, and is automatically defined as f Model 
"Auto-RIN" mode selectable indoor unit. Indoor unit without "Auto-RIN" mode Indoor unit without "Auto-RIN" mode Indoor unit with two or three step of air flow setting Indoor unit with automatically swing lower Indoor unit without automatically swing lower Indoor unit with three step of air flow setting Indoor unit with three step of air flow setting Indoor unit with two step of air flow setting Indoor unit with two step of air flow setting Item AUTO RUN SET Indoor unit with only one of air flow setting 

					No. are indicated only whe	en	Note2: Fan setting of "HI		2.18		
N ▼ (Remote control fu	nction)		(Indoor unit function) I/U FUNCTION	plural indoo	r units are connected.		Fan tap		oor unit air flow se		
Function				1/1000 A   3	Function O2 FAN SPEED SET	setting	<u> </u>	20ml - 20ml - 20ml - 20ml			
TO 1 TO SOME ESP SET	setting			I/U001 \$	UZ [PHN SPEED SET	STANDARD ×	FAN STANDARD	UH - Hi - Me - Lo	Hi - Me - Lo	Hi - Lo	Hi - N
	.6MØESP VALID	0	Validate setting of ESP:External Static Pressure	I/U002 \$		HIGH SPEED 1 ×	SET   HIGH	UH - UH - Hi - Me	UH - Hi - Me	UH - Me	UH-
02 AUTO RUN SET	EQMM EST INVALID		Invalidate setting of ESP	I/U003 \$ I/U004 \$	03 IFILTER SIGN SET	HIGH SPEED 2	SPEED1, 2			011 1110	011
UZ [IIDTO NON OLI ]	AUTO RUN ON	*	i		OS ILICIONOCOLO I	INDICATION OFF		ome indoor unit is "HIGH	SPEED.		
03 MIZIZI TEMP SW	AUTO RUN OFF	*	Automatical operation is impossible			TYPE 1 O	The filter sign is indicated at The filter sign is indicated at	ter running for 180 hours.			
	S⊠⊠ VALID S⊠⊠ INVALID	0	To set other indoor			TYPE 3	The filter sign is indicated at	ter running for 1000 hours	i.		
04 EE MODE SW	-5⊠⊠ INVALID	_	Temperature setting button is not working AIR CON No. button allows you to go ba			TYPE 4	The filter sign is indicated at compulsion after 24 hours.	ter running for 1000 hours	, then the indoor ur	nit will be stop	ped by
04 LEE HODE OW	응답 VALID 응답 INVALID	10	unit selection scree		04 ⇒. POSITION	_	If you change the indoor fun	ction "04 > POSITION"			
05 TO ON/OFF SW	⊕© INVALID		Mode button is not working (for example: I/U 0			4POSITION STOP O	you must change the remote	e control function "14 ≫ ~	POSITION * accordi	ingly.	
05   V 014 01 1 0W	⊕ © VALID	To	1			FREE STOP	You can select the louver st The louver can stop at any	op position in the tour. position.			
06 M FAN SPEED SW	⊕⊕ INVALID	_	On/Off button is not working		05 EXTERNAL INPUT	LEVEL INPUT					
OP I FEET LHIM OLECTO OWI	& SEE VALID	1 **				PULSE INPUT					
en Inter Course ou 1	⊕⊠ INVALID	*	Fan speed button is not working		06 (nastumianassumannum						
07 🖾 LOUVER SW	© ¥ALID	- X	i			INVALID O	Permission/prohibition contr	nl of operation will be valid	4		
	⊕E⊒ INVALID	*	Louver button is not working	*	07 EMERGENCY STOP				-		
08 @ TIMER SW	Lesion valin	10	i			INVALID O	With the VRF series, it is us	ad to aton all indeed units	announted with the		constituence
	ලම VALID ලම INVALID	ľ	Timer button is not working			THILLD	When stop signal is inputed				
09 SENSOR SET	SENSOR OFF	10	Remote thermistor is not working.								
	SENSOR ON	Ľ	Remote thermistor is working.			OFFSET +3.0%	To be reset for producing +3	3.0°C increase in temperat	ure during heating.		
	■SENSOR +3.0% ■SENSOR +2.0%	+	Remote thermistor is working, and to be set for producing +3.0°C increase in Remote thermistor is working, and to be set for producing +2.0°C increase in	temperature.	08 I № SP OFFSET	OFFSET +2,05 OFFSET +1,05	To be reset for producing +2	2.0°C increase in temperat	ure during heating.		
	SENSOR +1.0℃		Remote thermistor is working, and to be set for producing +1.0°C increase in	temperature.	U6 [ M or Urraci ]	NO OFFSET O	To be reset for producing +1	i.u C increase in temperat	ure during neating.		
	■SENSOR -1.0℃		Remote thermistor is working, and to be set for producing -1.0°C increase in the set of the section of the sect	temperature.		OFFSET +2.0%					
	■SENSOR -2.0% ■SENSOR -3.0%	+	Remote thermistor is working, and to be set for producing -2.0°C increase in I Remote thermistor is working, and to be set for producing -3.0°C increase in I	temperature. temperature.		0FFSET +1.55	To be reset producing +2.0° To be reset producing +1.5°				
10 AUTO RESTART					09 RETURN AIR TEMP	OFFSET + 1.0%	To be reset producing +1.0°	C increase in return air ter	mperature of indoor	unit.	
	INVALID VALID	0	ł			NO OFFSET O	To be reset producing -1.0°		and the second second		
11 VENT LINK SET			i			OFFSET - 1.5%	To be reset producing -1.0 ( To be reset producing -1.5)	Dincrease in return air ten Dincrease in return air ten	nperature of indoor	unit. unit.	
	NO VENT	10	In case of Single split series, by connecting ventilation device to C	'NT of the	10   X: FAN CONTROL	OFFSET -2.05	To be reset producing -2.0°0	C increase in return air ten	nperature of indoor	unit.	
	VENT LINK		indoor printed circuit board (in case of VRF series, by connecting it	it to CND of the	TO TAX THE CONTINUE T	LOW FAN SPEED	When heating thermostat is	OFF, fan speed is low spe	ed.		
	VENT LINK		indoor printed circuit board), the operation of ventilation device is	linked with the		SET FAN SPEED	When heating thermostat is	OFF, fan speed is set spe	ed.		
		+	operation of indoor unit. In case of Single split series, by connecting ventilation device to CNT of the i	indoor printed		INTERMITTENCE	When heating thermostat is	OFF, fan speed is operate	ed intermittently.		
	NO VENT LINK		circuit board (in case of VRF series, by connecting it to CND of the indoor pri	inted circuit		FAN OFF	When heating thermostat is When the remote thermistor	OFF, the fan is stopped.	ant automatically		
12 TEMP RANGE SET		_	board), you can operate /stop the ventilation device independently by	J(VENT) button.			Do not set "FAN OFF" when	the indoor unit's thermisto	or is working.		
	INDN CHANGE	То	If you change the range of set temperature, the indication of set te	emperature			Change of indoor heat exch			and the state of	
	NO INDN CHANGE	+	will vary following the control.  If you change the range of set temperature, the indication of set te		11 FROST PREVENTION TEMP	TTEMP HTGH	Change of Indoor heat exch	anger temperature to start	trost prevention co	introi.	
		•	will not vary following the control, and keep the set temperature.	imperature		TEMP HIGH TEMP LOW					
13 I/U FAN	HI-MID-LO	T*	Air flow of fan becomes the three speed of Satt - Satt - Satt or sattl - Satt	त्वा-क्षता-क्षता ±	12 PROST PREVENTION CONTROL		Working only with the Single	enlit sorios			
		×	Air flow of fan becomes the two speed of ***********************************				To control frost proportion	the indoor fan tap is raised	I.		
	HI-LO					FAN CONTROL ON	TO CONTROL HOSE PREVENDING				
	HI-MID	- ×	Air flow of fan becomes the two speed of *ant - *ant).			FAN CONTROL ON FAN CONTROL OFF	To control flost prevention,				
		*	Air flow of fan becomes the two speed of & ant - & ant ]. Air flow of fan is fixed at one speed.		13 DRAIN PUMPLINK		Drain pump is run during co	oling and dry.			
14   ≶≂ POSITION	HI-MID	*	Air flow of fan becomes the two speed of *ant - *ant).	*		\$6 O	Drain pump is run during co	oling and dry.			
14 동구 POSITION	HI-NID I FAN SPEED		Air flow of fan becomes the two speed of **ad-**ad]. Air flow of fan is fixed at one speed.  If you change the remote control function "14 *>POSITION", you must change the indoor function "04 *>POSITION" according! You can select the louver stop position in the four.	*	13 DRAIN PUMPLINK	\$Ó □ \$ÓAND% \$ÓAND%AND≅	Drain pump is run during co	oling and dry. oling, dry and heating. oling, dry, heating and fan			
	HE-MID I FAN SPEED		Air flow of fan becomes the two speed of **et -*ets1. Air flow of fan is fixed at one speed. If you change the remote control function "14 %—POSITION", you must change the indoor function "04 %—POSITION" according	*		\$0 \$0 AND % \$0 AND % \$0 AND %	Drain pump is run during co Drain pump is run during co Drain pump is run during co Drain pump is run during co	oling and dry. oling, dry and heating. oling, dry, heating and fan oling, dry and fan.			
14   <- POSITION   15   NODEL TYPE	HI-HID 1 FAN SPEED 4POSLITION STOP FREE STOP		Air flow of fan becomes the two speed of **ad-**ad]. Air flow of fan is fixed at one speed.  If you change the remote control function "14 *>POSITION", you must change the indoor function "04 *>POSITION" according! You can select the louver stop position in the four.	*	13 DRAIN PUMPLINK	\$0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Drain pump is run during co Drain pump is run during co Drain pump is run during co Drain pump is run during co After cooling is stopped is C After cooling is stopped is C	oling and dry. oling, dry and heating. oling, dry, heating and fan oling, dry and fan.  IFF, the fan does not perfo FF, the fan perform extra	orm extra operation.	n hour.	
15 MODEL TYPE	HE-MID 1 FAN SPEED 4POSITION STOP FREE STOP	10	Air flow of fan becomes the two speed of **ad-**ad]. Air flow of fan is fixed at one speed.  If you change the remote control function "14 *>POSITION", you must change the indoor function "04 *>POSITION" according! You can select the louver stop position in the four.	*	13 DRAIN PUMPLINK	\$0 AND XX SO AND	Drain pump is run during co Drain pump is run during co Drain pump is run during co Drain pump is run during co After cooling is stopped is C After cooling is stopped is C After cooling is stopped is C	oling and dry. oling, dry and heating. oling, dry, heating and fan oling, dry and fan. iFF, the fan does not performe xtra. iFF, the fan perform extra.	orm extra operation. operation for half an operation for an ho	n hour. ur.	
	HI-HID 1 FAN SPEED  4POSITION STOP FREE STOP HEAT PUNP COOLING ONLY	O	Air flow of fan becomes the two speed of **ard -**ard J. Air flow of fan is fixed at one speed.  If you change the remote control function "14 *>¬PISSITION", you must change the indoor function "04 *>¬PISSITION" accordingly You can select the louver stop position in the four.  The louver can stop at any position.	y. × × × × × × × × × × × × × × × × × × ×	13   DRAIN PUMPLINK	\$0 AND \$0	Drain pump is run during co Drain pump is run during co After cooling is stopped is C After cooling is stopped is C After cooling is stopped is C After cooling is stopped is C	oling and dry. oling, dry and healing. oling, dry, heating and fan oling, dry and fan. oling, dry and fan.  IFF, the fan does not perfor  FF, the fan perform extra  FF, the fan perform extra	orm extra operation. operation for half a operation for an ho operation for six ho	n hour. ur. urs.	
15 MODEL TYPE	HI_HID 1 FAN SPEED  4POSTTION STOP FREE STUP HEAT PUMP COOLING ONLY INDIVIDUAL	10	Air flow of fan becomes the two speed of **art -**art J. Air flow of fan is fixed at one speed If you change the remote control function **14 *>¬¬¬PISITION**, you must change the indoor function **04 *>¬¬PISITION** accordingl You can select the louver stop position in the four. The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit beard fror infoor unit will be operated independently according to the input	ly.  **  **  **  **  **  **  **  **  **	13   DRAIN PUMPLINK	SO O SO O O O O O O O O O O O O O O O O	Drain pump is run during co Drain pump is run during co Drain pump is run during co Drain pump is run during co After cooling is stopped is G After cooling is stopped is G After cooling is stopped is G After cooling is stopped or h	oling and dry. oling, dry and heating. oling, dry, heating and fan oling, dry heating and fan oling, dry and fan. IFF, the fan forom extra FFF, the fan perform extra teating thermostal is OFF,	orm extra operation. operation for half a operation for an ho operation for six ho the fan does not pe	n hour. ur. urs. erform extra o	
15 NODEL TYPE  16 EXTERNAL CONTROL SET	HI-HID 1 FAN SPEED  4POSITION STOP FREE STOP HEAT PUNP COOLING ONLY	O	Air flow of fan becomes the two speed of **ard -**ard J. Air flow of fan is fixed at one speed.  If you change the remote control function "14 *>¬PISSITION", you must change the indoor function "04 *>¬PISSITION" accordingly You can select the louver stop position in the four.  The louver can stop at any position.	ly.  * m external, the * from external. I units which	13   DRAIN PUMPLINK	SO ONDES SO ONDES SO ONDES SO ONDES SO ONDES NO REMINING OS HUR I HOUR NO REMINING OS HUR FOR HUNING OS HUR VICTORIAN	Drain pump is run during co Drain pump is stopped is G After cooling is stopped is G After cooling is stopped or After heating is stopped or After heating is stopped or After heating is stopped or Drain pump descriptions.	oling and dry. oling, dry and heating. oling, dry heating and fan oling, dry heating and fan oling, dry and fan.  IFF, the fan perform extra.	orm extra operation. operation for half at operation for an hot operation for six ho the fan does not pe the fan perform ext the fan perform ext	n hour. ur. urs. erform extra o ra operation fo ra operation fo	or half an or two hou
15 MODEL TYPE	HI-HID 1 FAN SPEED  4POSITION STOP FREE STOP HEAT PUMP COOLING ONLY INDIVIDUAL FOR ALL UNITS	O	Air flow of fan becomes the two speed of *Ard -*Ard J. Air flow of fan is fixed at one speed.  If you change the remote control function "14 *□ POSITION", you must change the indoor function "04 *□ POSITION" accordingly You can select the louver stop position in the four.  The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit board froi indoor unit will be operated independently according to the input If you input signal into CnT of the indoor printed circuit board from stemal, a	ly.  **  **  **  **  **  **  **  **  **	13 ORAIN PUMP LINK  14 © FAN REMAINING	\$0 ADDS \$0 ADD	Drain pump is run during co Drain pump is run during co Drain pump is run during co Drain pump is run during co After cooling is stopped is C After cooling is stopped is C After cooling is stopped of a After heating is stopped or After heating is stopped or	oling and dry. oling, dry and heating. oling, dry heating and fan oling, dry heating and fan oling, dry and fan.  IFF, the fan forom extra.  IFF, the fan perform extra.  IFF, the fan perform extra.  Leating thermostat is OFF, leating the	orm extra operation. operation for half at operation for an hot operation for six ho the fan does not pe the fan perform ext the fan perform ext	n hour. ur. urs. erform extra o ra operation fo ra operation fo	or half an or two hou
15 NODEL TYPE  16 EXTERNAL CONTROL SET	HI_HID 1 FAN SPEED  4POSTTION STOP FREE STUP HEAT PUMP COOLING ONLY INDIVIDUAL	O	Air flow of fan becomes the two speed of Nat -NatJ. Air flow of fan is fixed at one speed. If you change the remote control function "14 ≤¬¬PGSITION", you must change the indoor function "04 ⟨¬¬PGSITION" accordingly You can select the louvers top position in the four. The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit board fror indoor unit will be operated independently according to the input If you input this CNT of the indoor printed circuit board from external, according to the input If you input this CNT of the indoor printed circuit board from external, according to the input If you input this CNT of the indoor printed circuit board from external, according to the input In normal working indication, indoor unit temperature is indicated in In normal working indication, indoor unit temperature is indicated in	ly.  **  **  **  **  **  **  **  **  **	13   DRAIN PUMPLINK	SO ONDES SO ONDES SO ONDES SO ONDES SO ONDES NO REMINING OS HUR I HOUR NO REMINING OS HUR FOR HUNING OS HUR VICTORIAN	Drain pump is run during co Drain pump is run during co Aftler coolling is stopped is G Aftler coolling is stopped is G Aftler coolling is stopped as G Aftler healing is stopped or Aftler healing is stopped or healing is stopped is stopped or healing is stopped is stopped is stopped or heal	oling and dry.  oling, dry and heating,  oling, dry, heating and fan  oling, dry, heating and fan  oling, dry and fan.  FFF, the fan does not perform extra  FFF, the fan perform extra  refer, the fan perform extra  seating thermostat is OFFF,  seating thermostat is OFFF,  seating thermostat is OFFF,  seating thermostat is OFFF,	orm extra operation. operation for half at operation for an hot operation for six ho the fan does not pet the fan perform ext the fan perform ext	n hour. ur. urs. erform extra o ra operation fo ra operation fo tra operation f	or half an or two hou or six hou
15   MODEL TYPE  16   EXTERNAL CONTROL SET    17   ROOF TERP IMMONITION SET	HI-HID I FAN SPEED  4POST TION STOP FREE STOP HEAT PUMP LODULING ONLY INDIVIOUAL FOR ALL UNITS  INDICATION OFF	O	Air flow of fan becomes the two speed of **art -**art J. Air flow of fan is fixed at one speed If you change the remote control function "14 *>¬PISSITION", you must change the indoor function "04 *>¬PISSITION", you can select the louver stop position in the four. The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit board from indoor unit will be operated independently according to the input If you input of Off of the indoor printed circuit board from external, a connect to the same remote control are operated according to the input	ly.  **  **  **  **  **  **  **  **  **	13 ORAIN PUMP LINK  14 © FAN REMAINING	DO O O O O O O O O O O O O O O O O O O	Drain pump is run during co Drain pump is run during co After cooling is stopped is C After cooling is stopped at After cooling is stopped at C After heating is stopped or I After heating is stopped or I After heating is stopped or During heating is stopped or During heating is stopped or I During heating is stopped or I	oling and dry, oling, dry and healing, oling, dry, healing and lan oling, dry, healing and lan oling, dry and fan.  FFF, the fan does not perfor FFF, the fan perform extra- seating thermostat is OFF, eating thermostat is OFF, eating thermostat is OFF, eating thermostat is OFF, eating thermostat is OFF,	orm extra operation. operation for half at operation for an hot operation for six ho the fan does not pet the fan perform ext the fan perform ext	n hour. ur. urs. erform extra o ra operation fo ra operation fo tra operation f	or half an or two hou or six hou
15   NODEL TYPE  16   EXTERNAL CONTROL SET	FIL-HUD  J FAN SPEED  APASSITION STOP FREE STOP  HEAT FUP  LINDIVIDUAL FOR ALL UNITS  INDICATION ON  INDICATION ON	O	Air flow of fan becomes the two speed of Nat -NatJ. Air flow of fan is fixed at one speed. If you change the remote control function "14 ≤¬¬PGSITION", you must change the indoor function "04 ⟨¬¬PGSITION" accordingly You can select the louvers top position in the four. The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit board fror indoor unit will be operated independently according to the input If you input this CNT of the indoor printed circuit board from external, according to the input If you input this CNT of the indoor printed circuit board from external, according to the input If you input this CNT of the indoor printed circuit board from external, according to the input In normal working indication, indoor unit temperature is indicated in In normal working indication, indoor unit temperature is indicated in	ly.  **  **  **  **  **  **  **  **  **	13 ORAIN PUMP LINK  14 © FAN REMAINING	GO O GO ONDOS GO ONDO	Drain pump is run during co Drain pump is run during co Aller cooling is stopped is Galler cooling is stopped in Galler handing is stopped or Aller handing is stopped or Aller handing is stopped in Galler handing is stopped in Galler handing is stopped in Galler handing is stopped or Maller handing is stopped or Maller handing is stopped or Galler handing is stopped	oling and dry.  oling, dry and heating,  oling, dry, heating and lan  oling, dry, heating and lan  oling, dry and fam.  FF. the lan foces not perfor  FF. the lan perform extra ref.  FF. the lan perform extra ref.  FF. the lan perform extra ref.  FF. the lan perform extra seating hermostal is OFF.  eating hermostal is OFF.  heating thermostal is OFF.  heating thermostal is OFF.	orm extra operation operation for half at operation for an ho operation for six ho the fan does not proform ext the fan perform ext the fan perform ext the fan perform ext F, the fan perform in	n hour. ur. urs. erform extra o ra operation for ra operation for tra operation for tra operation for	or half an or two hou or six hou eration fo
15   MODEL TYPE  16   EXTERNAL CONTROL SET    17   ROOF TERP IMMONITION SET	FIL-MID I FAN SPEED  APISSTION STOP FREE STOP INFA FIMP DOOLING ONLY INDIVIDUAL	O	Air flow of fan becomes the two speed of Nat -NatJ. Air flow of fan is fixed at one speed. If you change the remote control function "14 ≤¬¬PGSITION", you must change the indoor function "04 ⟨¬¬PGSITION" accordingly You can select the louvers top position in the four. The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit board fror indoor unit will be operated independently according to the input If you input this CNT of the indoor printed circuit board from external, according to the input If you input this CNT of the indoor printed circuit board from external, according to the input If you input this CNT of the indoor printed circuit board from external, according to the input In normal working indication, indoor unit temperature is indicated in In normal working indication, indoor unit temperature is indicated in	y.  m external, the ≯ from external, il units which t from external.  stead of air flow.	13 [DRAIN PURPLINK]  14 [© FAN REHAINING]  15 [SE FAN REHAINING]	0	Drain pump is run during co Drain pump is run during co After cooling is stopped is C After cooling is stopped at After cooling is stopped at C After heating is stopped or I After heating is stopped or I After heating is stopped or During heating is stopped or During heating is stopped or I During heating is stopped or I	oling and dry. oling, dry and healing, oling, dry, healing and fan oling, dry and fan oline, dry and fan oli	orm extra operation operation for half at operation for an ho operation for six ho the fan does not proform ext the fan perform ext the fan perform ext the fan perform ext F, the fan perform in	n hour. ur. urs. erform extra o ra operation for ra operation for tra operation for tra operation for	or half an or two hou or six hou eration fo
15   MODEL TYPE  16   EXTERNAL CONTROL SET    17   ROOF TERP IMMONITION SET	FIL-HUD  J FAN SPEED  APASSITION STOP FREE STOP  HEAT FUP  LINDIVIDUAL FOR ALL UNITS  INDICATION ON  INDICATION ON		Air flow of fan becomes the two speed of **art -**art J. Air flow of fan is fixed at one speed If you change the remote control function "14 *>¬PISSITION", you must change the indoor function "04 *>¬PISSITION", You can select the louver stop position in the four. The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit board from the four of the louver stop position.  If you input signal into CnT of the indoor printed oricuit board from the four of the louver stop position.  If you input signal into CnT of the indoor printed circuit board from the four stop indoor unit libe operated independently according to the input into CNT of the indoor printed circuit board from external, a connect to the same remote control are operated according to the input In normal working indication, indoor unit temperature is indicated in (Only the master remote control can be indicated.)  Heating preparation indication should not be indicated.	y.  m external, the ≯ from external, il units which t from external.  stead of air flow.	13 ORAIN PUMP LINK  14 © FAN REMAINING	GO OMDOS GO	Drain pump is run during co Drain pump is run during co Alher cooling is stopped is C Alher cooling is stopped is C Alher cooling is stopped of a Alher cooling is stopped of a Alher heating is stopped or Alher heating is stopped or Alher heating is stopped or the cooling	oling and dry. oling, dry and healing, oling, dry, healing and fan oling, dry and fan oline, dry and fan oli	orm extra operation operation for half at operation for an ho operation for six ho the fan does not proform ext the fan perform ext the fan perform ext the fan perform ext F, the fan perform in	n hour. ur. urs. erform extra o ra operation for ra operation for tra operation for tra operation for	or half an or two hou or six hou eration fo
15   MODER, TYPE 16   EXTERNAL CONTROL SET   17   ROOR TOPP IMPGENTION SET   18   3999-IMPGENTION	FIL-HUD  J FAN SPEED  APASSITION STOP FREE STOP  HEAT FUP  LINDIVIDUAL FOR ALL UNITS  INDICATION ON  INDICATION ON	O	Air flow of fan becomes the two speed of *And -*And J. Air flow of fan is fixed at one speed.  If you change the remote control function "14 <>¬PISSITION", you must change the indoor function "04 <>¬PISSITION" accordingly You can select the louver stop position in the four.  The louver can stop at any position.  If you input signal into CnT of the indoor printed circuit board fror indoor unit will be operated independently according to the input If you input to '07 of the indoor printed circuit board from existent, a connect to the same remote control are operated according to the input In normal working indication, indoor unit temperature is indicated in (Only the master remote control can be indicated.)	y.  m external, the ≯ from external, il units which t from external.  stead of air flow.	13 [DRAIN PURPLINK]  14 [© FAN REHAINING]  15 [SE FAN REHAINING]	GO O GO ONDOS GO ONDO	Drain pump is run during co Drain pump is run during co Alher cooling is stopped is C Alher cooling is stopped is C Alher cooling is stopped of a Alher cooling is stopped of a Alher heating is stopped or Alher heating is stopped or Alher heating is stopped or the cooling	oling and dry, oling, dry and healing, loing, dry, healing and long, oling, dry, healing and long, oling, dry and lan.  FF, the fain does not justified. FF, the fain perform extra. FF, the fain perform extra. FF, the fain perform extra. eating thermostat is OFF, eating thermostat is OFF, eating thermostat is OFF, eating thermostat is OFF, the failing	orm extra operation. operation for half an operation for an an operation for an an operation for six ho the fan does not pi the fan perform ext the fan perform ext the fan perform ex F, the fan perform in	n hour. ur. urs. erform extra o ra operation fo tra operation fo tra operation fo tra operation fo ntermittent op	or half an or two hou or six hou eration fo

#### How to set function


Stop air-conditioner and press (SET) (MODE) buttons at the same time for over three seconds, and the
"FUNCTION SET ▼" will be displayed.



- 2. Press (SET) button.
- Make sure which do you want to set, "

  FUNCTION ▼"

  (remote control function) or "I/U FUNCTION ▲" (indoor unit function).
- Press ▲ or ▼ button.
   Selecct <sup>®</sup> FUNCTION ▼ " (remote control function) or "I/U FUNCTION ▲ " (indoor unit function).




5. Press O (SET) button.

- 6. [On the occasion of remote control function selection]

  - Press ▲ or ▼ button. \*No. and function\*are indicated by turns on the remote control function table, then you can select from them. (For example)



Press ()(SET) button. The current setting of selected function is indicated. (for example) "AUTO RUN ON" — If "02 AUTO RUN SET" is selected



Press or button. Select the setting.




⑤ Press 〇 (SET)

"SET COMPLETE" will be indicated, and the setting will be completed.

Then after "No. and function" indication returns, Set as the same procedure if you want to set continuously ,and if to finish, go to 7.



7. Press ON/OFF button. Setting is finished.



#### [On the occasion of indoor unit function selection]

"DATA LOADING" (Blinking for 2 to 23 seconds to read the data)
 Indication is changed to "02 FAN SPEED SET".
 Go to ②.

#### [Note]

 If plural indoor units are connected to a remote control, the indication is "I/U 000" (blinking) ← The lowest number of the indoor unit connected is indicated.




- (2) Press ▲ or ▼ button. Select the number of the indoor unit you are to set If you select "ALL UNIT ▼", you can set the same setting with all unites.
- (3) Press (SET) button.
- ② Press ▲ or ▼ button.

"No. and function" are indicated by turns on the indoor unit function table, then you can select from them.
(For example)



③ Press O (SET) button.

The current setting of selected function is indicated. (For example) "STANDARD" ← If "02 FAN SPEED SET" is selected.



- ④ Press ▲ or ▼ button. Select the setting.
- Press (SET) button. "SET COMPLETE" will be indicated, and the setting will be completed.

Then after "No. and function" indication returns, set as the same procedure if you want to set continuously , and if to finish, go to 7.



When plural indoor units are connected to a remote control, press the AIR CON No. button, which allows you to go back to the indoor unit selection screen. (example ¹I/U 000 ▲¹)

- It is possible to finish by pressing ON/OFF button on the way, but unfinished change of setting is unavailable.
- During setting, if you press (RESET) button, you return to the previous screen.
- Setting is memorized in the control and it is saved independently of power failure.

#### [ How to check the current setting ]

When you select from "No. and function" and press set button by the previous operation, the "Setting" displayed first is the current setting.

(But, if you select "ALL UNIT f v", the setting of the lowest number indoor unit is displayed.)

#### (c) Operation and setting from wired remote control

Blank: Not compatible

- : No function on remote control

○ : Correspondence
 △ : Corresponding part

Setting & display item RC-EX3A RC-E5 1.Remote control network 1 Control plural indoor units by a single remote control A remote control can control plural indoor units up to 16 (in one group of remote control network). An address is set to each indoor unit. 2 Main/sub setting of remote controls A pair of remote controls (including optional wireless remote control) can be connected within the remote control network. Set one to "Main" and the other to "Sub". 2.TOP scrren, Switch manipulation "Control", "State", or "Details" can be selected. (3-8) 1 Menu "Cooling", "Heating", "Fan", "Dry" or "Auto" can be set "Set temperature" can be set by 0.5°C interval. 2 Operation mode 3 Set temp. "Air flow direction" [Individual flap control] can be set Select Enable or Disable for the "3D AUTO". 4 Air flow direction 5 Fan speed "Fan speed" can be set. 6 Timer setting "Timer operation" can be set. 7 ON/OFF "On/Off operation of the system" can be done 8 F1 SW The system operates and is controlled according to the function specified to the F1 switch 9 F2 SW The system operates and is controlled according to the function specified to the F2 switch .Useful functions The moving range (the positions of upper limit and lower limit) of the flap for individual flap can be set.

When the panel with the anti draft function is assembled, select to Enable or Disable the anti draft setting for each 1 Individual flap control Anti draft setting When the panel with the anti-draft function is assembled. operation mode and for each blow outlet. The period of time to start operation after stopping can be set.

• The period of set time can be set within range of 1hour-12houres (1hr interval).

• The operation mode, set temp. and fan speed at starting operation can be set. 3 Timer settings Set On timer by hour Δ Set Off timer by hour The period of time to stop operation after starting can be set.

• The period of set time can be set within range of 1hour-12houres (1hr interval). Set On timer by clock The clock time to start operation can be set. The set clock time can be set by 5 minutes interval. 0 [Once (one time only)] or [Everyday] operation can be switched. The operation mode, set temp and fan speed at starting operation can be set. The clock time to stop operation can be set.

• The set clock time can be set by 5 minutes interval.

• [Once (one time only)] or [Everyday] operation can be switched. Set Off timer by clock 0 Status of timer settings can be seen. Confirmation of timer settings 4 Favorite setting [Administrator password] Set the operation mode, setting temperature, air flow capacity and air flow direction for the choice setting operation Set them for the Favorite set 1 and the Favorite set 2 respectively. On timer and Off timer on weekly basis can be set.

• 8-operation patterns per day can be set at a maximum.

• The setting clock time can be set by 5 minutes interval. 5 Weekly timer 0 Holiday setting is available. The operation mode, set temp and fan speed at starting operation can be set. When leaving home for a long period like a vaction leave, the unit can be operated to maintain the room temperature not to be hotter in summer or not to be colder in winter.

• The judgment to switch the operation mode (Cooling ⇔ Heating) is done by the both factors of the set temp. and outdoor 6 Home leave mode [Administrator password] air temp. The set temp. and fan speed can be set. On/Off operation of the external ventilator can be done. It is necessary to set from [Menu]  $\Rightarrow$  [Service setting]  $\Rightarrow$  [R/C function settings]  $\Rightarrow$  [Ventilation setting].

• If the "Independent" is selected for the ventilation setting, the ventilator can be operated or stopped. 7 External Ventilation When the ventilator is combined. Select the language to display on the remote control.

• Select from English, German, French, Spanish, Italian, Dutch, Turkish, Portuguese, Russian, 8 Select the language 0 Polish, Japanese and Chinese. 9 Look, look Indoor temperature, outdoor temperature and power consumption are indicated. 10 Power consumption indication The power consumption of today, this week and this year is indicated by a chart. It is possible to compare with vesterday, last week and last year · This item may not indicate depending on indoor and outdoor units which are combined 4.Energy-saving setting Administrator password To prevent the timer from keeping ON, set hours to stop operation automatically with this timer.

• The selectable range of setting time is from 30 to 240 minutes. (10 minutes interval)

• When setting is "Enable", this timer will activate whenever the ON timer is set. 1 Sleep times 2 Peak-cut timer Power consumption can be reduced by restructing the maximum capacity rower consumption can be reduced by restructing the maximum capacity. Set the [Start time], the [End time] and the capacity limit % (Peak-cut %).

4-operation patterns per day can be set at maximum.

The setting time can be changed by 5-minutes interval.

The selectable range of capacity limit % (Peak-cut %) is from 0% to 40-80% (20% interval).

Holiday setting is available. After the elapse of the set time period, the current set temp. will be set back to the [Set back time.] 3 Automatic temp. set back The setting can be done in cooling and heating mode respectively. Selectable range of the set time is from 20 min. to 120 min. (10 min. interval). Set the [Set back temp.] by 1 °C interval. When the infrared sensor (motion sensor) is used, it is necessary to set Enable or Disable for the "Power control" 4 Infrared sensor control (Motion sensor control) nd the "Auto-off" When the panel with the infrared sensor (motion sensor) is assembled 1 Filter sign reset Filter sign reset The filter sign can be reset. Setting next cleaning date The next cleaning date can be set. 6.User setting Clock setting The current date and time can be set or revised 1 Internal settings If a power failure continues no longer than 80 hours, the clock continues to tick by the built-in power source [Display] or [Hide] the date and/or time can be set, and [12H] or [24H] display can be set. Date and time display When select [Enable], the +1hour adjustment of current time can be set. When select [Disable], the [Summer time] adjustment can be reset. The contrast of LCD can be adjusted higher or lower Contrast Switching on/off a light can be set and period of the lighting time can be set within the range of 5sec-90 sec (5sec interval). It can set with or without [Control sound (beep sound)] at touch panel. Backlight Control sound This is used to adjust the luminance of operation lamp Operation lamp luminance

Setting & di	<u> </u>	Description	RC-EX3A	RC-E5
2 Administrator settings [Administrator password]	Permission/Prohibition setting	Pownission/Prohibition setting of operation can be set. [On/Off] [Change et temp] [Change operation mode] [Change flap direction] [Change fan speed] [High power operation] [Energy-saving operation] [Timer]  Request for administrator can be set. [Individual flap control] [Weekly timer] [Select the language] [Anti draft setting]	0	-
	Outdoor unit silent mode timer	The period of time to operate the outdoor unit by prioritizing the quiteness can be set.  The [Start time] and the [End time] for operating outdoor unit in silent mode can be set.  The period of the operation time can be set once aday by 5 minutes interal.	0	0
	Setting temp. range	The upper/lower limit of temp. setting range can be set.  The limitation of indoor temp. setting range can be set for each operation mode in cooling and heating.	0	0
	Temp increment setting Set temp. display	The temp increment setting can be changed by 0.5°C or 1.0°C.  Ways of displaying setting temperatures can be selected.	0	0
	R/C display setting	Register [Room name] [Name of I/U] Display [Indoor temp. display] or not. Display [Error code display] or not. Display [Heating stand-by display] [Defrost operation display] [Auto cooling/heating display] [Display temp of R/C, Room, Outdoor] or not	0	_
	Change administrator password	The administrator password can be changed. (Default setting is "0000") The administrator password can be reset.	0	-
	F1/F2 function setting	Functions can be set for F1 and F2. Selectable functions: [High power operation], [Energy-saving operation], [Silent mode cont.], [Home leave mode], [Favorite set 1], [Favorite set 2] and [Filter sign reset].	0	-
Service setting 1 Installer settings	To at 11 at a state	The Heat Ration day I have been started		
[Service password]	Installation date	The [Installation date] can be registed.  • When registering the [Instaration date], the [Next service date] is displayed automatically.  (For changing the [Next service date], please refer the item of [Service & Maintenance])	0	-
	Company information	The [Company information] can be registed and can be displayed on the R/C.  • The [Company] can be registered within 26 characters.  • The [Phone No.] can be registed within 13 digits.	0	_
	Test run Cooling test run	On/Off operation of the test run can be done. The [Cooling test run] can be done at 5°C of set temp. for 30 minutes.	0	0
	Drain pump test run Static pressure adjustment	Only drain pump can be operated.  In case of combination with only the ducted indoor unit which has a function of static pressure adjustment, the static pressure is adjustable.  • It can be set for each indoor unit individually.		_
	Change auto-address Address setting of main IU	The set address of each indoor unit decided by auto-address setting method can be changed to any other address.  Main indoor unit address can be set.  Only the Main indoor unit can change operation mode and the Sub indoor units dominated by the Main indoor shall follow.  The Main indoor unit can domain 10 indoor units at a maximum.		_
	IU back-up function	When a pair of indoor units (2 groups) is connected to one unit of remote control, it can be set Enable or Disable for the [IU rotation], [IU capacity back-up] and [IU fault back-up]	0	-
	Infrared sensor setting (Motion sensor setting) When the panel with the infrared sensor (motion sensor) is assembled.	Set Enable or Disable for the infrared sensor detectors of indoor units connected to the remote control.  If Disable is selected, it cannot be control the infrared sensor control for the energy-saving setting.	0	-
	Grill lifting operation	Set enable for automatic lifting panel operation. When automatic lifting panel is assembled.		
2 R/C function setting	Main/Sub R/C	The R/C setting of [Main/Sub] can be changed.	0	_
[Service password]	Return air temp.	When two or more indoor units are connected to one unit of remote control, suction sensors, which are used for the judgement by thermostat, can be selected.  It can be selected from [Individual], [Master IU] and [Average temp].	0	-
	R/C sensor	It can be set the mode to switch to the remote control sensor. It can be selected from cooling and heating.  The offset value of [R/C sensor] sensing temp, can be set respectively in heating and cooling.	0	Δ
	R/C sensor adjustment Operation mode	Enable or Disable can be set for each operation mode.	0	Δ
	°C / °F	Set the unit for setting temperatures.  • °C or °F can be selected.	0	0
	Fan speed External input	Fan speeds can be selected.  When two or more indoor units are connected to one unit of remote control, the range to apply CnT inputs can be set.	0	-
	Upper/lower flap control	[Stop at fixed position] or [Stop at any position] can be selected for the upper and lower louvers.	0	Ō
	Left/right flap control Ventilation setting	[Fixed position stop] or [Stop at any position] can be selected for the right and left louvers.  Combination control for ventilator can be set.	0	-
	Auto-restart	The operation control method after recovery of power failure happened during operation can be set.	0	Ŏ
	Auto temp. setting	[Enable] or [Disable] of [Auto temp. setting] can be selected.	0	_
IU settings	Auto fan speed Fan speed setting	[Enable] or [Disable] of [Auto fan speed] can be selected.  The fan speed for indoor units can be set.	0	-
1-0 0000000	Filter sign	The setting of filter sign display timer can be done from following patterns.		_
[Service password]	External input 1	The connect of control by external input 1 can be changed.	Δ	Δ
	External input 1 signal External input 2	The type of external input 1 signal can be changed.  The connect of control by external input 2 can be changed.	0	
	External input 2 signal	The type of external input 2 signal can be changed.		-
		The judgement temp. of heating themo-off can be adjusted within the range from 0 to +3°C (1°C interval).		_
	Return temperature adjustment	The sensing temp. of return air temp. sensor built in the indoor unit can be adjusted within the range of ±2°C.  Fan control, when the cooling thermostat is turned OFF, can be changed.		<b>—</b>
		Fan control, when the beating thermostat is turned OFF, can be changed.	Δ	Δ
	Anti-frost temp.	Judgment temperature for the anti-frost control during cooling can be changed.		$\vdash$
	Anti-frost control Drain pump operation Keep fan operating after cooling	When the anti-frost control of indoor unit in cooling is activated, the fan speed can be changed.  In any operation mode in addition to cooling and dry mode, the setting of drain pump operation can be done.  The time period residual fan operation after stopping or thermo-off in cooling mode can be set.		
	is stopped	The time period residual fan operation after stopping or thermo-off in heating mode can be set.		
	Intermittent fan operation in heating Fan circulator operation Control pressure adjust	The fan operation rule following the residual fan operation after stopping or themo-off in heating mode can be set.  In case that the fan is operated as the circulator, the fan control rule can be set.  When only the OA processing units are operated, control pressure value can be changed.		
	Auto operation mode Thermo. rule setting	The [Auto rule selection] for switching the operation mode automatically can be selected from 3 patterns.  When selecting [Outdoor air temp. control], the judgment temp can be offset by outdoor temp		
	Auto fan speed control IU overload alarm	Auto switching range for the auto fan speed control can be set.  If the difference between the setting temperature and the suction temperature becomes larger than the temperature difference set for the overload alarm, at 30 minutes after the start of operation, the overload alarm signal is transmitted from the external	0	_
	External output setting *1	output (CnT-5). Functions assigned to the external outputs 1 to 4 can be changed.	Δ	_

Setting & d	isplay item	Description	RC-EX3A	RC-E5
4 Service & Maintenance [Service password]	IU address	Max 16 indoor units can be connected to one remote control, and all address No. of the connected indoor units can be displayed.  The indoor unit conforming to the address No. can be identified by selecting the address No. and tapping [Check] to operate the indoor fan.	0	-
l l	Next service date	The [Next service date] can be registered.  • The [Next service date] and [Company information] is displayed on the message screen.	0	-
	Operation data	The [Operation data] for indoor unit and outdoor unit can be displayed.	0	0
	Error display			
	Error history	The error history can be displayed.		
	Display anomaly data	The operation data just before the latest error stop can be displayed.	0	Δ
	Erase anomaly data	Anomaly operation data can be erased.		
	Reset periodical check	The timer for the periodical check can be reset.		
	Saving IU settings	The I/U settings memorized in the indoor PCB connected to the remote control can be saved in the memory of the remote control.	0	_
	Special settings	[Erase IU address] [CPU reset] [Restore of default setting] [Touch panel calibration]	0	Δ
	Indoor unit capacity display	Address No. and capacities of indoor units connected to the remote control are displayed.	0	-
8.Contact company		Shows registered [Contact company] and [Contact phone].	0	_
9.Inspection				
Confirmation of Inspection		This is displayed when any error occurs.	0	_
10.PC connection	·			
USB connection		Weekly timer setting and etc., can be set from PC.	0	_

<sup>♦</sup> Listed items may not function depending on the specifications of indoor and outdoor units which are combined.

<sup>\*1</sup> It supports only following functions.

Operation output / Heating output / Compressor ON output / Inspection (Error) output / Cooling output / Fan operation output 1 / Fan operation output 2 / Fan operation output 3 / Defrost/oil return output

#### (2) Interface kit (SC-BIKN2-E)

\* When RC-EX3A is connected, please use SC-BIKN2-E by all means.

RKZ012A099

#### Accessories included in package

Be sure to check all the accessories included in package.

No.	Part name	Quantity
1	Indoor unit's connection cable (cable length: 1.8m)	1
2	Wood screws (for mounting the interface: $\phi 4 \times 25$ )	2
3	Tapping screws (for the cable clump and the interface mounting bracket)	3
4	Interface mounting bracket	1
⑤	Cable clamp (for the indoor unit's connection cable)	1
6	CnT terminal connection cable (total cable length: 0.5m)	1

#### Safety precautions

Before use, please read these Safety precautions thoroughly before installation.

• All the cautionary items mentioned below are important safety related items to be taken into consideration, so be sure to observe them at all times.

⚠Warning Incorrect installation could lead to serious consequences such as death, major injury or environmental destruction.

Symbols used in these precautions



Always go along these instruction.

After completed installation, carry out trial operation to confirm no anomaly, and ask the
user to keep this installation manual in a good place for future reference.

## $\overline{\mathbb{N}}$

## Warnings



- ●Installation must be carried out by a qualified installer.
- If you install it by yourself, it may cause an electric shock, fire and personal injury, as a result of a system malfunction.
- ●Install it in full accordance with the installation manual.

Incorrect installation may cause an electric shock, fire and personal injury.

• Electrical work must be carried out by a qualified electrician in accordance with the technical standard for electrical equipment, the indoor wiring standard and this installation manual.

Incorrect installation may cause an electric shock, fire and personal injury.

• Use the specific cables for wiring. And connect all the cables to terminals or connectors securely and clamp them with cable clamps in order for external forces not to be transmitted to the terminals directly.

Incomplete connection may cause malfunction, and lead to heat generation and fire.

Use the original accessories and specified components for installation.


If the parts other than those prescribed by us are used, it may cause an electric shock, fire and sersonal injury.

#### Connecting the indoor unit's connection cable to the interface

- ①Remove the upper case of the interface.
  - Remove 2 screws from the interface casing before removal of upper casing.
- 2 Connect the indoor unit's connection cable to the interface.
  - Connect the connector of the indoor unit connection cable to the connector on the interface's circuit board.
- (3) Fix the indoor unit's connection cable with the cable clamp.
  - Cable can be brought in from the top or from the back.
  - Cut out the punch-outs for the connection cables running into the casing with cutter.
- (4) Connect the indoor unit's connection cable to the indoor control PCB.
  - Connect the indoor unit's connection cable to the indoor control PCB securely.
  - Clamp the connection cable to the indoor control box securely with the cable clamp provided as an accessory.
  - Regarding the cable connection to the indoor unit, refer to the installation manual for indoor unit.

# TRemove the upper case Wiring inlet (top or back) Wiring inlet (top or back)

#### Name of each part of the interface



\*Either the connection cables of Superlink E board (SC-ADNA-E) or of wired remote control is connectable.

Switch	Setting	Function	Switch	Setting	Function	
SW2-1	ON**	CnT level input	SW2-3	ON**	** External input (CnT input)	
SW2-1	OFF	CnT pulse input	3 W 2-3	OFF	Operation permission/prohibition (CnT input)	
SW2-2	ON**	Wired remote control : Enable	SW2-4	ON**	Annual cooling : Enable***	
3 W 2-2	OFF	Wired remote control : Disable	3 W Z-4	OFF	Annual cooling : Disable***	

<sup>\*\*</sup> Factory setting

\*\*\* Indoor fan control at low outdoor air temperature in cooling

Wiring inlet


0

#### Installation of the interface

- Install the interface within the range of the connection cable length (approximately 1.3m) from the indoor unit.
- Be sure not to extend the connection cable on site. If the connection cable is extended, malfunction may occur.
- Fix the interface on the wall, pillar or the like.
- Don't install the interface and wired remote control at the following places.
  - OPlaces exposed to direct sunlight
  - OPlaces near heating devices
  - OHigh humidity places
  - OSurfaces where are enough hot or cold to generate condensation
  - OPlaces exposed to oil mist or steam directly
  - OUneven surface


#### Mounting the interface directly on a wall

- ①Mount the lower casing of the interface on a flat surface with wood screws provided as standard accessory.
- 2 Mount the upper casing.



#### Recessing the interface in the wall


- ①Recess the electrical box (procured locally) and connection cables in the wall.
- ②Mount the lower casing of the interface to the electrical box with M4 screws (procured locally).
- 3 Mount the upper casing.



Connection cable

#### Mounting the interface with the mounting bracket

- 1)Mount the upper casing.
- ②Mount the mounting bracket to the interface with tapping screws provided as standard accessory.
- 3Mount the mounting bracket on wall or the like with wood screws provided as standard accessory.




#### Installation check items

- ☐ Are the connection cables connected securely to the terminal blocks and connectors?
- ☐ Are the thickness and length of the connection cables conformed with the standard?

#### **Functions of CnT connector**

It is available to operate the air-conditioner and to monitor the operation status with the external control unit (remote display) by sending the input/output signal through CnT connector on the indoor control PCB.

- ①Connect a external remote control unit (procured locally) to CnT terminal.
- ②In case of the pulse input, switch OFF the DIP switch SW2-1 on the interface PCB.
- When setting operation permission/prohibition mode, switch OFF the DIP switch SW2-3 on the interface PCB.




Input/	F	Function Output signal Relay ON/OFF		Gtt	
Output	runction			Content	
Output 1	Operation output	XR1	ON	During air-conditioner operation	
Output 2	Heating output	XR2	ON	During heating operation	
Output 3	Compressor operation output	XR3	ON	During compressor running	
Output 4	Malfunction output	XR4	ON	During anomalous stop	

- ■XR<sub>1-4</sub> are for the DC 12V relay
- XR5 is a DC 12/24V or AC 220-240V relay
- ●CnT connector (local) maker, model

Connector	Molex	5264-06
Terminals	Molex	5263T

Immust/			SW2-1			SW2-3		Air-	Operation by			
Input/ Output	Function	Cattina		Catting	Input signal		Contont	conditioner	remote control			
Output			Setting	Setting	Level/Pulse	XR5	Content	Conditioner	Temote control			
				ON*		OFF→ON	External input	ON				
		ON*	Level input		Level	$\text{ON} {\rightarrow} \text{OFF}$		OFF	Allowed			
	T . 1	OIN	ON Level input	OFF	Level	OFF→ON	Operation permission	OFF				
Input	External control							OFF		ON→OFF	Operation prohibition	OFF
	input			ON*	Dulas	OFF→ON	External input	OFF→ON				
	1		OFF Pulse input	ON*	Pulse	OFF-ON	1	ON→OFF	Allowed			
		Orr	OFF	OFF→ON	Operation permission	ON						
				Orr	Level	ON→OFF	Operation prohibition	OFF	Not allowed			



In case of the remote control (RC-EX3A), the external outputs (1-4) and the external input can be changed using the function setting of remote control. For the setting method, refer to the installation manual.


Also refer to the technical manual to know how it is adapted to the function setting for the external outputs and input, at the indoor unit side.

#### Connection of Superlink E board


Regarding the connection of Superlink E board, refer to the installation manual of Superlink E board. For electrical work, power source for all of units in the Superlink system must be turned OFF.

①Switch ON the DIP switch SW2-2 (Factory setting: ON) on the interface PCB.

Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, temperature setting, etc. may not work properly and may have a mismatch between the display and the actual behavior.



2 Wiring connection between the interface and the Superlink E board.



3 Clamp the connection cables with cable clamps.

No.	Names of recommended signal wires
1	Shielded wire
2	Vinyl cabtyre round cord
3	Vinyl cabtyre round cable
4	Vinyl insulated wire vinyl sheathed cable for control

Within 200m 0.5mm<sup>2</sup> × 2 cores

Within 300m 0.75mm<sup>2</sup> × 2 cores

Within 400m 1.25mm<sup>2</sup> × 2 cores

Within 600m 2.0mm<sup>2</sup> × 2 cores

<sup>\*</sup> Factory setting

0

DIP switch

(SW2-2)

#### Connection of wired remote control

Regarding the connection of wired remote control, refer to the installation manual of wired remote control. ①Switch ON the DIP switch SW2-2 (Factory setting: ON) on the interface PCB.

Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, temperature setting, etc. may not work properly and may have

a mismatch between the display and the actual behavior. ②Wiring connection between the interface and the wired remote control.

#### Installation and wiring of wired remote control

- (A) Install the wired remote control with reference to the attached installation manual of wired remote control.
- $\bigcirc 0.3$  mm<sup>2</sup>  $\times$  2 cores cable should be used for the wiring of wired remote control.
- © Maximum length of wiring is 600m.

If the length of wiring exceeds 100m, change the size of cable as mentioned below.

100m-200m:  $0.5\text{mm}^2 \times 2$  cores, 300m or less:  $0.75\text{mm}^2 \times 2$  cores, 400m or less:  $1.25\text{mm}^2 \times 2$  cores, 600m or less:  $2.0\text{mm}^2 \times 2$  cores However, cable size connecting to the terminal of wired remote control should not exceed 0.5mm<sup>2</sup>. Accordingly if the size of connection cable exceeds 0.5mm<sup>2</sup>, be sure to downsize it to 0.5mm<sup>2</sup> at the nearest section of the wired remote control and waterproof treatment should be done at the connecting section in order to avoid contact failure.

- Don't use the multi-core cable to avoid malfunction.
- (E) Keep the wiring of wired remote control away from grounding (Don't touch it to any metal frame of building, etc.).
- © Connect the connection cables to the terminal blocks of the wired remote control and the interface securely (No polarity).
- (3) Clamp the connection cables with cable clamps.

#### Control of multiple units by a single wired remote control

Multiple units (up to 16) can be controlled by a single wired remote control. In this case, all units connected with a single wired remote control will operate under the same mode and same setting temperature.

- ①Connect all the interface with 2 cores cables of wired remote control line.
- ②Set the address of indoor unit for remote control communication from "0" to "F" with the rotary switch SW1 on the interface PCB.
- 3 After turning the power ON, the address of indoor unit can be displayed by pressing AIR CON No. button on the wired remote control. Make sure all indoor units connected are displayed in order by pressing ▲ or ▼ button.

#### Master/Slave setting wired when 2 of wired remote control are used

Maximum two wired remote control can be connected to one indoor unit (or one group of indoor units)


- ①Set the DIP switch SW1 on the wired remote control to "Slave" for the slave remote control. (Factory setting: Master)
- O Caution: Remote control sensor of the slave remote control is invalid.
- When using the wireless remote control in parallel with the wired remote control; Since temperature setting range of wired remote control is different from that of wireless remote control, please adjust the setting range of wired remote control to be the same setting range of wireless remote control by following procedure. (The set temperature may not be displayed correctly on the wireless remote control, unless change of temperature setting range is done.) Changing procedure of temperature setting range is as follows.

#### How to set upper and lower limit of temperature setting range

- 1. Stop the air-conditioner, and press (SET) and (MODE) button at the same time for 3 seconds or more.
  - The indication changes to "FUNCTION SET▼"
- Press **▼**button once, and change to the "TEMP RANGE **▲**" indication.
- Press (SET) button, and enter the temperature range setting mode.
- Confirm that the "Upper limit ▼" is shown on the display.
- Press (SET)button to fix.
- ①Indication: "ⓑ∨∧SET UP"→"UPPER 28°C ∨∧"
  - ②Select the upper limit value 30°C with temperature setting button △."UPPER30°C∨"
  - ③Press (SET) button to fix. "UPPER 30°C" (Displayed for two seconds) After the fixed upper limit value displayed for two seconds, the indication will returm to"UPPER LIMIT ▼'
- 7. Press **▼**button once, "LOWER LIMIT ▲" is selected, press (SET) button to fix. ①Indication: " $^{\bullet} \lor \land SET UP" \rightarrow "LOWER 20^{\circ} C \lor \land '$ 
  - ②Select the lower limit value 18°C with temperature setting button ☑."LOWER18°C∧"
  - ③Press (SET) button to fix. "LOWER 18°C" (Displayed for two seconds) After the fixed lower limit value displayed for two seconds, the indication will returm to"LOWER LIMIT
- 8. Press ON/OFF button to finish.

Temperature setting range

Mode	Temperature setting range
Cooling, Heating, Dry, Auto	18-30°C




• It is possible to quit in the middle by pressing ON/OFF button, but the

Previous button

ШШ

previous screen

TEMP RANG



#### (3) Superlink E board (SC-ADNA-E)



- Read and understand the instructions completely before starting installation.
- Refer to the instructions for both indoor and outdoor units.

#### Safety precautions

- Carefully read "Safety precautions" first. Follow the instructions for installation.
- Precautions are grouped into "Warning 🕰 " and "Caution 🖈". The "Warning 🛧 " group includes items that may lead to serious injury or death if not observed. The items included
- in the "Caution A" group also may lead to serious results under certain conditions. Both groups are crucial for safety installation. Read and understand them carefully.

  After installation, conduct the test operation of the device to check for any abnormalities. Describe how to operate the device to the customer following the installation instruction manual. Instruct the customer to keep this installation instruction for future reference.

#### **∴** Warning

- This device should be installed by the dealer where you purchase the device or a licensed professional shop. If the device is incorrectly installed by the
- customer, it may result in electric shock or fire.

  Install the device carefully following the installation instruction. If the device is incorrectly installed, it may result in electric shock or fire.
- Use the accessory parts and specified parts for installation. If any parts that do not match the specifications are used, it may result in electric shock or fire.
- A person with the electrical service certification should conduct the service based on the "Technical standards for electrical facilities", "Electrical Wiring Code", and the installation instruction. If the work is done incorrectly, it may result in electric shock or fire.
- Wiring should be securely connected using the specified types of wire. No external force on the wire should be applied to any terminals. If a secure connection is not achieved, it may result in electric shock or fire.

#### 1 Application

Indoor-to-outdoor three core communication specification type 3 (since

#### Accessories

SL E board	Metal box	Metal cover	Screw for ground
	[8]	· ·	M4×8 2 pieces
Pan head screws	Locking supports	Binding band	Grommet
φ4×8 2 pieces	To secure the print board and the metal box Made of nylon 4 pieces	68	

#### 3 Function

Allowing the central control SL1N-E, SL2NA-E, and SL4-AE3/BE3 to control and monitor the commercial air-conditioner unit.

#### Control switching

Settings can be changed by the DIP switch SW3 on the SL E board as in the following

Switch	Symbol	Switch	Remark
	,	ON	Master
	ļ	OFF (default)	Slave
		ON	Fixed previous protocol
	2	OFF (default)	Automatic adjustment of Superlink protocol
SW3	3	ON	Indicates the forced operation stop when abnormality has occurred.
	3	OFF (default)	Indicates the status of running/stop as it is, when abnormality has occurred.
	4	ON	The hundredth address activated "1"
	4	OFF (default)	The hundredth address activated "0"

#### **∴**Caution


- Provide ground connection.
- The ground line should never be connected to the gas supply piping, the water supply piping, the lightning conductor rod, nor the telephone ground. If the grounding is improper, it may result in electric shock.
- Do not install the device in the following locations.
  - 1.Where there is mist/spray of oil or steam such as kitchens. 2.Where there is corrosive gases such as sulfurous acid gas.

  - 3. Where there is a device generating electromagnetic waves These may interfere with the control system resulting in the device becoming uncontrollable.
  - 4.Where flammable volatile materials such as paint thinner and gasoline may exist or where they are handled. This may cause a fire.

#### 5 Connection outline

Note for setting the address

- Set the address between 00 and 47 for the previous Superlink connection and between 000 and 127 for the new Superlink connection. (\*1)
- Do not set the address overlapping with those of the other devices in the network. (The default is 000)




(\*1) Whether the actual link is either the new Superlink or the previous Superlink depends on the models of the connected outdoor and indoor units. Consult the agent or the dealer.

#### Signal line specification

Communication method	Previous Superlink	New Superlink
Line type	MVVS	MVVS
Line diameter	0.75 - 1.25mm <sup>2</sup>	0.75/1.25mm <sup>2</sup>
Signal line (total length)	up to 1000m	up to 1500/1000m (*2)
Signal line (maximum length)	up to 1000m	up to 1000m

- (\*2) Up to 1500m for 0.75mm<sup>2</sup>, and up to 1000m for 1.25mm<sup>2</sup>. Do not use 2.0mm<sup>2</sup>. It may cause an error.
- (\*3) Connect grounding on both ends of the shielding wire. For the grounding method, refer to the section "6 Installation".


- Set the Superlink network address with SW1 (tens place), SW2 (ones place), and SW3 (hundreds place).
- (2) Set the SL E board SW3-1 to be ON (Master) when using this without any remote control (no wired remote controller nor wireless remote control).
- (3) Set up the plural master/slave device using the DIP switches on the indoor unit board.
- (4) Set up the remote control master/slave device using the slide switch on the remote control board.
- (5) Set up "0" to "F" using the address rotary switch on the indoor unit board when controlling the indoor unit with the multiple remote control.



#### 6 Installation

- 1. When using the metal box (mounted on the indoor unit / mounted on the back of the remote control):
  - (1) Mount the SL E board in the metal box using the locking supports.
  - (2) Wiring should go through the provided grommet since then through the wiring to the hole on the Metal box.


Secure the grommet after inserting the grommet into the Metal box as shown in below figure, then tie the wiring at the outlet of the unit using a binding band.




▲ When installed outside the indoor unit, put the metal cover on.




▲ When installed on the back of the remote control, mount it directly on the remote control bottom case.



Connect grounding. Connect grounding for the power line to Ground ①, and grounding for the signal line to Ground ② or to the Ground on the indoor unit control box.



- 2. When connecting to the indoor unit control box (ceiling-concealed type and FDT type only):
  - (1) Mount the SL E board in the control box using the locking supports.
  - (2) Remove 6 bands from the box and put the wiring through the bands to be secured.



Electrical shock hazard make sure to turn the power off for servicing. Be cautious so that no abnormal force should be applied to the wiring. Do not let the SL E board hung by the wiring. Do not damage the board with a screwdriver.

The board is sensitive to static electricity. Release the static electricity of your body before servicing.

(You can do this by touching the control board which is grounded).

#### Location of installation

Install the device at the location where there are no electromagnetic waves nor where there is water and dust. The specified temperature range of the device is 0 to 40°C. Install the device at the location where the ambient temperature stays within the range. If it exceeds the specification, make sure to provide solution such as installing a cooling fan. When used outside of the range, it may cause abnormal operation.

#### 7 Indicator display

Check the LED 3 (green) and LED 2 (red) on the SL E board for flashing.

SL E boa	ard LEDs		Display on the
Red	Green	Inspection mode	integrated network control device
Off	Flashing	Normal communication	
Off	Off	Disconnection in the remote control communication line (X or Y)     Short-circuit in the remote control communication line (between X and Y)     Faulty indoor unit remote control power     Faulty remote control communication circuit     Faulty CPU on SL E board	No corresponding unit number
One flash	Flashing	Disconnection in the Superlink signal line (A or B)     Short-circuit in the Superlink signal line (between A and B)     Faulty Superlink signal circuit	
Two flashes	Flashing	Faulty address setting for the SL E board (Set up the address for previous SL E board : more than 48 new SL E board : more than 128)	
Three flashes	Flashing	SL E board parent not set up when used without a remote control     Faulty remote control communication circuit	E1
Four flashes	Flashing	Address overlapping for the SL E board and the Superlink network connected indoor unit	E2
Off	Flashing	Number of connected devices exceeds the specification for the multiple indoor unit control	E10

## 10. TECHNICAL INFORMATION

#### Model SRK20ZTX-WA

Information to identify the model(s) to which the information relates to: Indoor unit model name Outdoor unit model name  Function(indicate if present) cooling heating  Ves  Item  Symbol Design load cooling heating / Average heating / Average heating / Average heating / Colder Heating / Colder  Pdesignh heating / Colder Pdesignh Pdesignh Pdesignh Average Pdesignh Pdesignh Average Pdesignh Average Pdesignh Pdesignh Average Pdesignh Average Pdesignh Pdesignh Average Pdesignh Pdesignh Pdesignh Average Pdesignh	elate to one eating season 'Average 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6
Neating season at a time. Include at least the here	eating season 'Averages  6 6 6 ol value class
Function(indicate if present) cooling heating  Yes  Item symbol value unit Design load cooling heating / Average heating / Average heating / Average heating / Colder Pdesignh - kW heating / Colder heating / Colder Pdesignh - kW Design load cooling heating / Average heating / Average heating / Colder Pdesignh - kW Declared capacity at outdoor temperature Tdesignh Declared capacity at outdoor temperature  Average(mandatory) Warmer(if designated) No Colder(if designated) No Seasonal efficiency and energy efficiency class cooling heating / Average heating / Average heating / Warmer SCOP heating / Colder  Back up heating capacity at outdoor temperature	s s ol value class
cooling heating	s ol value class
cooling heating	ol value class
Item	ol value class
Design load cooling	
Design load cooling	
Cooling   Pdesignc   Z.00   kW     Cooling   SEER   Reating / Average   Pdesignh   Z.80   kW   heating / Average   SCOP   heating / Colder   Pdesignh   Leating / Colder   Pdesignh   Leating / Colder   Pdesignh   Leating / Colder   Pdesignh   Leating / Colder   SCOP   Heating / Colder   SCOP   Leating / Colder	
heating / Average   Pdesignh   2.80   kW   heating / Average   SCOP   heating / Warmer   Pdesignh   - kW   heating / Warmer   SCOP   heating / Colder   Pdesignh   4.00   kW   heating / Colder   SCOP   heating / Colder   heating /	9.60   A++-
heating / Warmer heating / Colder Pdesignh - kW heating / Colder SCOP  Declared capacity at outdoor temperature Tdesignh Back up heating capacity at outdoor temperature Tdesignh Capacity According to the capacity at outdoor temperature Tdesignh Capacity According to the capacity at outdoor temperature Tdesignh Capacity According to the capacity According to the capacity at outdoor temperature Tdesignh Capacity According to the c	
heating / Colder Pdesignh 4.00 kW heating / Colder SCOP  Declared capacity at outdoor temperature Tdesignh Back up heating capacity at outdoor temperature	
Declared capacity at outdoor temperature Tdesignh Back up heating capacity at outdoor temperature	
	unit e Tdesignh
heating / Average (-10°C) Pdh   2.80  kW    heating / Average (-10°C) elbu	0 kW
heating / Warmer (2°C) Pdh - kW heating / Warmer (2°C) elbu	- kW
heating / Colder (-22°C) Pdh 3.50 kW heating / Colder (-22°C) elbu	0.5 kW
Declared capacity for cooling, at indoor temperature 27(19)°C and Declared energy efficiency ratio, at indoor temperature	erature 27(19)°C and
outdoor temperature Tj outdoor temperature Tj	
Tj=35°C Pdc <b>2.00</b> kW   Tj=35°C EERd	6.25 -
Tj=30°C Pdc <b>1.47</b> kW Tj=30°C EERd	9.30 -
Tj=25°C Pdc 1.44 kW Tj=25°C EERd	13.20 -
Tj=20°C Pdc <b>1.63</b> kW Tj=20°C EERd	19.60 -
Declared capacity for heating / Average season, at indeer	season at indeer
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj   Declared coefficient of performance / Average stemperature 20°C and outdoor temperature Tj	cason, at mooor
Ti=-7°C Pdh 2.35 kW Ti=-7°C and outdoor temperature 17	3.15 -
Ti=2°C Pdh 1.51 kW Ti=2°C COPd	
Ti=7°C Pdh 0.97 kW Ti=7°C COPd	
Ti=12°C Pdh 1.15 kW   Ti=12°C COPd	
Ti=bivalent temperature Pdh 2.80 kW Ti=bivalent temperature COPd	
Tj=operating limit Pdh 2.80 kW Tj=operating limit COPd	
Declared capacity for heating / Warmer season, at indoor Declared coefficient of performance / Warmer s	eason, at indoor
temperature 20°C and outdoor temperature Tj temperature 20°C and outdoor temperature Tj	
$T_{j=2}^{\circ}$ Pdh - kW $T_{j=2}^{\circ}$ COPd	
$T_{j=7}^{\circ}$ Pdh	
Tj=12°C Pdh - kW   Tj=12°C COPd	
Tj=bivalent temperature Pdh - kW Tj=bivalent temperature COPd	
Tj=operating limit Pdh - kW Tj=operating limit COPd	
Declared capacity for heating / Colder season, at indoor Declared coefficient of performance / Colder se	acon at indoor
temperature 20°C and outdoor temperature Tj	ason, at muoor
Ti=-7°C COP4	3.15 -
Ti=2°C Pdh 1.51 kW   Tj=2°C COPd	
Ti=7°C Pdh 0.97 kW   Ti=7°C COPd	
Ti=12°C Pdh 1.15 kW Ti=12°C COPd	
Tj=bivalent temperature Pdh 3.26 kW Tj=bivalent temperature COPd	2.37 -
Tj=operating limit Pdh 3.50 kW Tj=operating limit COPd	1.70 -
Tj=-15°C Pdh 3.26 kW   Tj=-15°C COPd	
Bivalent temperature Operating limit temperature	
heating / Average Tbiv -10 °C heating / Average Tol	-10 °C
heating / Warmer Tbiv - °C heating / Warmer Tol	- °C
heating / Colder Tbiv -15 °C heating / Colder Tol	<b>-22</b> ℃
Oveling interval expecity	
Cycling interval capacity  for cooling  Cycling interval efficiency  for cooling  EERc	/C
for heating Pcych - kW   for heating COPc	
J, on	<u>,                                     </u>
Degradation coefficient Degradation coefficient	
	0.25 -
cooling Cdc 0.25 - heating Cdh	
Electric power input in power modes other than 'active mode'  Annual electricity consumption	<b>73</b> kWh/a
Electric power input in power modes other than 'active mode' off mode Poff 4 W Annual electricity consumption cooling Qce	
Electric power input in power modes other than 'active mode' off mode	<b>755</b> kWh/a
Electric power input in power modes other than 'active mode' off mode Poff 4 W standby mode Psb 4 W thermostat-off mode Pto(cooling) 11 W Annual electricity consumption cooling Qce heating / Average heating / Warmer Qhe	<b>755</b> kWh/a - kWh/a
Electric power input in power modes other than 'active mode' off mode Poff 4 W cooling Qce standby mode Psb 4 W thermostat-off mode Pto(cooling) 11 W Pto(heating) 14 W heating / Older Qhe	<b>755</b> kWh/a
Electric power input in power modes other than 'active mode' off mode Poff 4 W standby mode Psb 4 W heating / Average heating / Warmer Qhe	<b>755</b> kWh/a - kWh/a
Electric power input in power modes other than 'active mode' off mode standby mode Psb 4 W thermostat-off mode Pto(cooling) Pto(heating) 11 W crankcase heater mode Pck 0 W	<b>755</b> kWh/a - kWh/a
Electric power input in power modes other than 'active mode' off mode standby mode Psb 4 W thermostat-off mode Pto(cooling) 11 W Pto(heating) 14 W crankcase heater mode Pck 0 W	<b>755</b> kWh/a - kWh/a
Electric power input in power modes other than 'active mode' off mode standby mode Psb 4 W thermostat-off mode Plo(cooling) Pto(heating) Pto(heating) T4 W Capacity control(indicate one of three options)  Capacity control(indicate one of three options)  Annual electricity consumption cooling heating / Average heating / Warmer Qhe heating / Warmer Qhe heating / colder Qhe	755 kWh/a - kWh/a 2048 kWh/a
Electric power input in power modes other than 'active mode' off mode	755 kWh/a - kWh/a 2048 kWh/a
Electric power input in power modes other than 'active mode' off mode	755 kWh/a  - kWh/a  2048 kWh/a  52 dB(A) 55 dB(A)
Electric power input in power modes other than 'active mode' off mode	755 kWh/a  - kWh/a  2048 kWh/a  52 dB(A)  55 dB(A)  675 kgCO2
Electric power input in power modes other than 'active mode' off mode standby mode Poff 4 W thermostat-off mode Pto(cooling) 11 W Pto(heating) 14 W Pro(heating) 14 W Crankcase heater mode Pck 0 W	755 kWh/a  - kWh/a  2048 kWh/a  52 dB(A)  55 dB(A)  675 kgCO2  642 m³/h
Electric power input in power modes other than 'active mode' off mode	755 kWh/a  - kWh/a  2048 kWh/a  52 dB(A)  55 dB(A)  675 kgCO2  642 m³/h
Electric power input in power modes other than 'active mode' off mode	755 kWh/a  - kWh/a  2048 kWh/a  52 dB(A)  55 dB(A)  675 kgCO2  642 m³/h  1860 m³/h
Electric power input in power modes other than 'active mode' off mode standby mode Psb 4 W heating / Average Qce heating / Average heating / Werage heating / Warmer Qhe heating / Colder Qhe crankcase heater mode Pck 0 W	755 kWh/a  - kWh/a  2048 kWh/a  52 dB(A)  55 dB(A)  675 kgCO2  642 m³/h  1860 m³/h
Electric power input in power modes other than 'active mode' off mode	755 kWh/a  - kWh/a  2048 kWh/a  52 dB(A)  55 dB(A)  675 kgCO2  642 m³/h  1860 m³/h

#### Model SRK25ZTX-WA

Information to identify the model(s) to			If function includes heating: Indicate t		
door unit model name SRK25ZTX-WA utdoor unit model name SRC25ZTX-WA		information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Outdoor unit model name   SRG25Z1X-WA		Theating season at a time. Motade at it	ast the neat	ng scason Average.	
Function(indicate if present)	_		Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	Yes	
Item	symbol	value unit	Item	symbol	value class
Design load			Seasonal efficiency and energy efficiency	ency class	
cooling	Pdesigno		cooling	SEER SCOR/A	9.50 A+++ 5.20 A+++
heating / Average heating / Warmer	Pdesignh Pdesignh		heating / Average heating / Warmer	SCOP/A SCOP/W	
heating / Colder	Pdesignh		heating / Colder	SCOP/C	
					unit
Declared capacity at outdoor temperat			Back up heating capacity at outdoor to		
heating / Average (-10°C) heating / Warmer (2°C)	Pdh Pdh	3.00 kW kW	heating / Average (-10°C) heating / Warmer (2°C)	elbu elbu	0 kW - kW
heating / Colder (-22°C)	Pdh	3.90 kW	heating / Colder (-22°C)	elbu	<b>0.5</b> kW
					•
Declared capacity for cooling, at indoo	r temperatur	e 27(19)°C and	Declared energy efficiency ratio, at in-	door tempera	ature 27(19)°C and
outdoor temperature Tj Tj=35°C	Pdc	2.50 kW	outdoor temperature Tj Tj=35°C	EERd	5.56 -
Tj=30°C	Pdc	1.84 kW	Tj=30°C	EERd	8.80 -
Tj=25°C	Pdc	1.43 kW	Tj=25°C	EERd	12.60 -
Tj=20°C	Pdc	1.49 kW	Tj=20°C	EERd	17.60 -
Declared capacity for heating / Average	le season of	indoor	Declared coefficient of performance /	Average sea	ison at indoor
temperature 20°C and outdoor temper		indoor	temperature 20°C and outdoor temper		oon, at muuul
Tj=-7°C	Pdh	<b>2.65</b> kW	Tj=-7°C	COPd	3.10 -
Tj=2°C	Pdh	1.62 kW	Tj=2°C	COPd	5.40 -
Tj=7°C Ti=12°C	Pdh Pdh	1.04 kW 1.16 kW	Tj=7°C Ti=12°C	COPd COPd	6.50 - 8.20 -
Tj=bivalent temperature	Pdh	3.00 kW	Tj=bivalent temperature	COPd	2.60 -
Tj=operating limit	Pdh	3.00 kW	Tj=operating limit	COPd	2.60 -
			7 (		
Declared capacity for heating / Warme temperature 20°C and outdoor temper		indoor	Declared coefficient of performance / temperature 20°C and outdoor temperature		son, at indoor
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature Tj=operating limit	Pdh Pdh	- kW kW	Tj=bivalent temperature Tj=operating limit	COPd COPd	
1j-operating limit	i uii	- 1744	1)-operating limit	COLU	1 - 1-
Declared capacity for heating / Colder	season, at ir	ndoor	Declared coefficient of performance /	Colder seaso	on, at indoor
temperature 20°C and outdoor temper			temperature 20°C and outdoor temperature		
Tj=-7°C Ti=2°C	Pdh Pdh	2.65 kW 1.62 kW	Tj=-7°C   Tj=2°C	COPd COPd	3.10 - 5.40 -
Tj=7°C	Pdh	1.04 kW	Ti=7°C	COPd	6.50 -
Tj=12°C	Pdh	1.16 kW	Tj=12°C	COPd	8.20 -
Tj=bivalent temperature	Pdh	3.59 kW	Tj=bivalent temperature	COPd	2.35 -
Tj=operating limit Ti=-15°C	Pdh Pdh	3.90 kW 3.59 kW	Tj=operating limit	COPd COPd	1.70 - 2.35 -
1j=-15 C	Pan	3.59 KVV	[]=-15 C	COPa	2.35 -
Bivalent temperature			Operating limit temperature		
heating / Average	Tbiv	-10 °C	heating / Average	Tol	-10 °C
heating / Warmer	Tbiv Tbiv	- °C -15 °C	heating / Warmer	Tol Tol	- °C -22 °C
heating / Colder	IDIV	-15 C	heating / Colder	101	-22 0
Cycling interval capacity			Cycling interval efficiency		
for cooling	Pcycc	- kW	for cooling	EERcyc	
for heating	Pcych	- kW	for heating	COPcyc	-  -
Degradation coefficient			Degradation coefficient		
cooling	Cdc	0.25 -	heating	Cdh	0.25 -
Electric power input in power modes o off mode	ther than 'ac Poff	tive mode' 4 W	Annual electricity consumption	Qce	93 kWh/a
standby mode	Poli	4 W	cooling   heating / Average	Qce Qhe	808 kWh/a
thermostat-off mode	Pto(cooling)	11 W	heating / Warmer	Qhe	- kWh/a
	Pto(heating)	14 W	heating / colder	Qhe	<b>2252</b> kWh/a
crankcase heater mode	Pck	0 W	_		
Capacity control(indicate one of three	options)		Other items		
, and a state of the control of the control	ر ۵۰۰۰۰۰		Sound power level(indoor)	Lwa	<b>54</b> dB(A)
			Sound power level(outdoor)	Lwa	<b>55</b> dB(A)
fixed	No No		Global warming potential	GWP	675 kgCO2eq.
staged variable	Yes		Rated air flow(indoor) Rated air flow(outdoor)	-	1860 m <sup>3</sup> /h
	1 100				, .000 Jill/III
Contact details for obtaining Name and address of the manufacturer or of its authorised representative.					
	HIAE SERVIC		I CM Amotordom, Notherlands/D O Barr 2000	12 1100 DW A	motordom Nathaulau da
		238, Luna ArenA, 1101 y Industries Air-Conditi	I CM Amsterdam, Netherlands/P.O.Box 2339 oning Europe. Ltd.	O TIOU DW AI	materuarri, ivetheriands
` '		,	e, Middlesex,UB11 1ET, United kingdom		
				-	

#### Model SRK35ZTX-WA

Information to identify the model(s) to	which the infor	mation relates to:	If function includes heating: Indicate	e the heating se	ason the	
Indoor unit model name	SRK35ZTX		information relates to. Indicated value			
Outdoor unit model name	SRC35ZTX	-WA	heating season at a time. Include at			'Average'.
Function(indicate if present)	Vaa		Average(mandatory)	Yes		
cooling heating	Yes Yes		Warmer(if designated) Colder(if designated)	No Yes		
neating	162		Colder(II designated)	162		
Item	symbol v	alue unit	Item	symbol	value	class
Design load			Seasonal efficiency and energy efficiency			
cooling	Pdesignc	3.50 kW	cooling	SEER	9.50	A+++
heating / Average	Pdesignh	<b>3.40</b> kW	heating / Average	SCOP/A	5.10	A+++
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	- 440	-
heating / Colder	Pdesignh	<b>4.90</b> kW	heating / Colder	SCOP/C	4.10	A+
Declared capacity at outdoor tempera	turo Tdooianh		Back up heating capacity at outdoor	r tomporatura T	dooianh	unit
heating / Average (-10°C)	Pdh	3.40 kW	heating / Average (-10°C)	elbu	0	lkW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	<b>4.20</b> kW	heating / Colder (-22°C)	elbu	0.7	kW
	·	•			,	•
Declared capacity for cooling, at indoo	or temperature	27(19)°C and	Declared energy efficiency ratio, at	indoor tempera	ture 27(19	9)℃ and
outdoor temperature Tj	D.I.	0.50 1.34/	outdoor temperature Tj	EED.	4.70	7
Tj=35°C	Pdc Pdc	3.50 kW 2.58 kW	Tj=35°C	EERd	4.73	<b>-</b>
Tj=30°C Tj=25°C	Pdc	2.58 kW 1.66 kW	Tj=30°C  Tj=25°C	EERd EERd	7.24 13.05	
Tj=20°C	Pdc	1.57 kW	Tj=20°C	EERd	17.79	+[
1]-20 0	1 00	1.07	1]=20 0	LLING	17.75	
Declared capacity for heating / Average	ge season, at in	door	Declared coefficient of performance	/ Average sea	son, at inc	door
temperature 20°C and outdoor temper			temperature 20°C and outdoor temp			_
Tj=-7°C	Pdh _	3.00 kW	Tj=-7°C	COPd	3.10	]-
Tj=2°C	Pdh	1.83 kW	Tj=2°C	COPd	5.30	<u></u>  -
Tj=7°C	Pdh	1.18 kW	Tj=7°C	COPd	6.20	<b></b> -
Tj=12°C	Pdh Pdh	1.14 kW 3.40 kW	Tj=12°C	COPd COPd	8.20 2.50	<b>-</b>  -
Tj=bivalent temperature Tj=operating limit	Pdh	3.40 kW	Tj=bivalent temperature Tj=operating limit	COPd	2.50	
Tj-operating limit	Full	3.40	IJ-operating limit	COFU	2.50	<u> </u> -
Declared capacity for heating / Warme	er season at in	door	Declared coefficient of performance	/ Warmer seas	son at ind	loor
temperature 20°C and outdoor temper		4001	temperature 20°C and outdoor temp		on, at me	1001
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	-	<b></b>
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	-	<b>-</b>
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	-	<b>-</b>
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	-	<b>-</b>
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	-	-
Declared capacity for heating / Colder temperature 20°C and outdoor temper Tj=-7°C Tj=2°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit	Pature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	3.00 kW 1.83 kW 1.18 kW 1.14 kW 4.00 kW	Declared coefficient of performance temperature 20°C and outdoor tempTj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit	oerature Tj COPd COPd COPd COPd COPd COPd	3.10 5.30 6.20 8.20 2.50 1.90	- - - - - - - - - -
Tj=-15°C	Pdh	<b>4.00</b> kW	Tj=-15°C	COPd	2.50	-
D: 1			16			
Bivalent temperature heating / Average	Thiv	-10 °C	Operating limit temperature heating / Average	Tol	-10	T°c
heating / Average	Tbiv Tbiv	-10 °C	heating / Warmer	Tol	-10	÷ c
heating / Colder	Tbiv	-15 °C	heating / Colder	Tol	-22	- c
	I					
Cycling interval capacity	_		Cycling interval efficiency			_
for cooling	Pcycc	- kW	for cooling	EERcyc	-	
for heating	Pcych	- kW	for heating	COPcyc	-	-
Degradation apofficient			Degradation adofficient			
Degradation coefficient cooling	Cdc	0.25 -	Degradation coefficient heating	Cdh	0.25	<b>⊤</b> _
- Cooling	ouo	0.20	modulig	Oun	0.20	
Electric power input in power modes of	ther than 'activ	e mode'	Annual electricity consumption			
off mode	Poff	4 W	cooling	Qce	129	kWh/a
standby mode	Psb	<b>4</b> W	heating / Average	Qhe	934	kWh/a
thermostat-off mode	Pto(cooling)	11 W	heating / Warmer	Qhe	-	kWh/a
	Pto(heating)	14 W	heating / colder	Qhe	2510	kWh/a
crankcase heater mode	Pck	<b>0</b> W	J			
Canadity assumed line disaster and of the can			Oth an itama			
Capacity control(indicate one of three	options)		Other items Sound power level(indoor)	Lwa	57	dB(A)
			Sound power level(indoor)	Lwa	59	dB(A)
fixed	No		Global warming potential	GWP	675	kgCO2eq.
staged	No		Rated air flow(indoor)	-	792	m³/h
variable	Yes		Rated air flow(outdoor)	-	2148	m³/h
			or of its authorised representative.		· <u></u>	
	HIAE SERVICES		CM Ameterdam Netherland 175 C.D. CC	200 4400 5141	antol-	Nath
		8, Luna ArenA, 1101 ndustries Air-Conditi	CM Amsterdam, Netherlands/P.O.Box 23	393 TIUU DW An	nsterdam,	ivetnerlands
			oning Europe, Ltd. , Middlesex,UB11 1ET, United kingdom			
1 3	5 5 4 4 4 1 5 , 5 10 1	, Oxbridge	, soon, ob 1. 121, ontoo kingdom			

#### 11. REFERENCE

#### (1) Outline

#### 1-1) R32 as the alternative refrigerant for residential air-conditioners

As for the R410A refrigerant which we have been usually using for air-conditioners, in case of emissions into the atmosphere, we have been adopting the collection of refrigerant etc. in order to restrain the world from global warming.

Based on the 4th basic ecological plan, it is said that the amount of emission of the green house effect gases including the refrigerants which are being used for air-conditioners shall be reduced 80% by 2050, emissions of any kind of freon gases which have especially high global warming coefficient must be reduced much more.

Hence, it is required to converted the freon gases we are using for air-conditioners into the refrigerants which have lower global warming even though they are exhausted into the atmosphere.

On the other hand, the refrigerants for air-conditioners, lower effect of global warming, to secure its performance and high energy efficiency and safety are required, however, the refrigerants which satisfy all of them have not been announced yet.

For this purpose, we have been studying to make use of the refrigerant like R32 which has short life in the atmosphere, even though it has low global warming but low combustibility under the practical use for safety.

In 2004, IEC, international electrical safety for air-conditioners had been corrected, the regulation for safety of air-conditioners which use the combustible refrigerant have been issued, in 2010, the regulation adopting the degree which is considered to be damaged slightly because of difficulty of ignition due to its low combustion speed was issued in ANSI/ASHRAE34 regulations.

R32 has been approved as the refrigerant whose combustion speed degree is lower than 10cm/sec, the standardization for safety use is being proceeded so that R32 can be used more widely.

Although all the air-conditioners which use R32 have been designed with deep consideration in order to guarantee the safety, some cautions which are mandatory to be kept during its installation and services are shown as follows.

#### 1-2) Chemical characteristics of R32

#### (i) Chemical charactaristic

R32 is one of an ingredient which composes R410A, without toxicity, the chemically stable compound which consists of carbon and fluorine.

Life of R32 after diffusing in the atmosphere is very short, approximately 4.9 years, as a result, although the effect to global warming can be reduced, there are little combustible due to large ratio of hydrogen.

	R32	R410A	R22
Chemical formation	CH <sub>2</sub> F <sub>2</sub>	CH <sub>2</sub> F <sub>2</sub> /CHF <sub>2</sub> CF <sub>3</sub>	CHCLF <sub>2</sub>
Composition (Mixture ratio weight%)	Single composition	R32/R125 (50/50 weight%)	Single composition
Boiling point	-51.7℃	-51.5℃	-40.8°C
Pressure at 50°C	3.14	3.07	1.94
Performance at 0/50°C	160	141	100
COP at Te/Tc/SC/SH=5/50/3/0°C	95	91	100
ODP(Ozone Depletion Potential)	0	0	0.055
GWP(Global Warming Potential)	675	2090	1810
Combustible charactaristic	A2L	A1	A1
Toxicity	No	No	No

Table1 Chemical charactaristic

#### (ii) Pressure charactaristic

As mentioned in table 2, vapor pressure of R32 is almost same as R410A under the identical refrigerant temperature, and it has 1.6 times of high performance comparision with R22.

Therefore, tool and apparatus which are intended to be used under high pressure condition shall be required same as R410A when service and installation are implemented.

Table2 Comparison of saturated vapour pressure (MPa)

Refrigerant Temperature [°C]	R32	R410A	R22
-20	0.30	0.30	0.14
0	0.71	0.70	0.40
20	1.37	1.35	0.81
40	2.38	2.32	1.43
60	3.84	3.73	2.33
65	4.29	4.17	2.60

#### 1-3) Combustion characteristic

R32 is possible to combust slightly when following conditions (gas density and ignition energy) coincide.

#### a) Combustible gas density by mixture with the air

In the event that if the ignition source which is possible to ignite is within the gas density mentioned in table 3, R32 might combust.

However, the combustible gas density of R32 is higher than that of propane's one.

In addition, since the combustible gas density condition of R32 is possible to cause hypoxia (density of oxygen in the air is less than 18%), this is not the environment where people can work normally.

Table3 Combustible density range

	R32	Propane (Reference)
Density upper limit (vol%)	29.3	9.5
Density lower limit (vol%)	13.3	1.8

#### b) Energy necessary for ignition.

It is said that R32 is less combustible gas than propane, since the energy which enables to combust is big, for example, static electricity around the human body and electric lighter (few mJ) can not make it ignite.

Table4 Minimum energy to ignite

	R32	Propane
Minimum energy to ignite (mJ)	15	0.246

#### c) Combustion speed

Since the combustion speed of R32 is low, it never combusts explosively like propane.

Table5 Combustion speed

	R32	Propane
Combustion speed (cm/s)	6.7	38.7

Consequently, although the ignition never happens under the conditions of usual use and work, however, in the event of the ignition, please handle with great care because the fire might extend once the ignition occurs.

#### 1-4) Refrigerant oil for R32

The refrigerant oil for R32 differs from the mineral oil which is being used for R22, since it is based on the synthetic oil for R32, please ensure to use the designated one.

#### (2) Cautions for safety

#### 2-1) Transport of equipment containing flammable refrigerants

It is necessary to follow the applicable transport regulations during the transportation with respect to equipment containing flammable gas.

#### 2-2) Marking of equipment using signs

All required signs are to be maintained and employers should ensure that employees receive suitable and sufficient instruction and training on the meaning of appropriate safety signs and the actions that need to be taken in connection with these signs.

#### 2-3) Disposal of equipment using flammable refrigerants

National Regulations shall be followed.

#### 2-4) Symbols

The following symbols and the information of the warning marking shall be provided as follows:



Symbol ISO 7010-W021 (2011)

Warning; Risk of fire / Flammable materials



A2L symbol

Warning; Low burning velocity material



Symbol ISO 7000-1641 (2004-01)

Operator's manual; operating instructions



Symbol ISO 7000-1659 (2004-01)

Service indicator; read technical manual

#### (a) WARNING

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

- (b) The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.
- (c) Do not pierce or burn.
- (d) Be aware that refrigerants may not contain an odour.

#### (3) General

- 3-1) The following information shall be specified in the manual where the information is needed for the function of the manual and as applicable to the appliance:
  - (a) Information for spaces where refrigerant pipes are allowed, including statements
    - that the installation of pipe-work shall be kept to a minimum;
    - that pipe-work shall be protected from physical damage and, in the case of flammable refrigerants, shall not be installed in an unventilated space, if that space is smaller than Amin in Annex GG;
    - that compliance with national gas regulations shall be observed;
    - that mechanical connections made in accordance with 22.118 shall be accessible for maintenance purposes;
    - that, for appliances containing flammable refrigerants, the minimum floor area of the room shall be mentioned in the form of a table or a single figure without reference to a formula;
  - (b) The maximum refrigerant charge amount (M);
  - (c) The minimum rated airflow, if required by Annex GG;
  - (d) Information for handling, installation, cleaning, servicing and disposal of refrigerant;
  - (e) The minimum floor area of the room or the special requirements for the room in which an appliance containing flammable refrigerants can be located as defined in Annex GG, except where the refrigerant charge (M) is less than or equal to m1 (M ≤ m1);
  - (f) A warning to keep any required ventilation openings clear of obstruction;
  - (g) A notice that servicing shall be performed only as recommended by the manufacturer.

#### 3-2) Qualification of workers

Every working procedure that affects safety means shall only be carried out by competent persons according to Annex HH. Examples for such working procedures are:

- Breaking into the refrigerating circuit;
- Opening of sealed components;
- Opening of ventilated enclosures.

#### ► Checks to the area

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised.

For repair to the refrigerating system, following precautions shall be taken prior to conducting work on the system.

#### ► Work procedure

Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

#### ► General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.

Work in confined spaces shall be avoided.

The area around the workspace shall be sectioned off.

Ensure that the conditions within the area have been made safe by control of flammable materials.

#### ► Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres.

Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

#### ▶ Presence of fire extinguisher

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO<sub>2</sub> fire extinguisher adjacent to the charging area.

#### ► No ignition sources

No person carrying out work in relation to a refrigeration system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.

All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space.

Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.

"No Smoking" signs shall be displayed.

#### ► Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out.

The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

#### ► Checks to the refrigeration equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance.

The following checks shall be applied to installations using flammable refrigerants including R32:

- The charge size is in accordance with the room size within which the refrigerant containing parts are installed;
- The ventilation machinery and outlets are operating adequately and are not obstructed;
- If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

#### ► Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.

If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.

If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used

This shall be reported to the owner of the equipment so all parties are advised.

Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding.

#### ► Repairs to sealed components

During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.

If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

▶ Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.

This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

Ensure that the apparatus is mounted securely.

Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres.

Replacement parts shall be in accordance with the manufacturer's specifications.

#### ► Repair to intrinsically safe components

(1) Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

#### **►** Cabling

(1) Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

#### ▶ Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

#### ► Leak detection methods

The following leak detection methods are deemed acceptable for all refrigerant systems.

- (1) Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
  Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
  - Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.
- (2) Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- (3) If a leak is suspected, all naked flames shall be removed/extinguished.
- (4) If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.
  - For appliances containing flammable refrigerants, oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

#### ► Removal and evacuation

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is followed since flammability is a consideration.

The following procedure shall be adhered to:

- remove refrigerant;
- purge the circuit with inert gas;
- evacuate;
- purge again with inert gas;
- open the circuit by cutting or brazing.

The refrigerant charge shall be recovered into the correct recovery cylinders.

For appliances containing flammable refrigerants, the system shall be "flushed" with OFN to render the unit safe.

This process may need to be repeated several times.

Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.

This process shall be repeated until no refrigerant is within the system.

When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

This operation is absolutely vital if brazing operations on the pipe-work are to take place.

Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation is available.

#### ► Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
- Cylinders shall be kept upright.
- Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the refrigeration system.

Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas.

The system shall be leak-tested on completion of charging but prior to commissioning.

A follow up leak test shall be carried out prior to leaving the site.

#### **▶** Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that:
  - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - all personal protective equipment is available and being used correctly;
  - the recovery process is supervised at all times by a competent person;
  - recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

#### **►** Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant.

The label shall be dated and signed.

For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

#### **►** Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.

Ensure that the correct number of cylinders for holding the total system charge are available.

All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).

Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.

Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants.

In addition, a set of calibrated weighing scales shall be available and in good working order.

Hoses shall be complete with leak-free disconnect couplings and in good condition.

Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.

Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.

Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.

The evacuation process shall be carried out prior to returning the compressor to the suppliers.

Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

# INVERTER WALL MOUNTED TYPE RESIDENTIAL AIR-CONDITIONERS



#### MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.

2-3, Marunouchi 3-chome, Chiyoda-ku, Tokyo, 100-8332, Japan http://www.mhi-mth.co.jp/en/